



Apollo 718 H13 True HEPA Air Purifier

User Manual



Grab your big smile!



Needs Support?

Please feel free to reach our support@okaysou.com



THANKS FOR YOUR PURCHASE

Hello Guys,

Thanks for your purchase from Okaysou. It is our great honor to meet you in Okaysou Big Family.

We value your suggestion and feedback. If there is anything that we can do for you, please feel free to reach us at support@okaysou.com or find us on social media. We will be there with you all the time!

Facebook: @Okaysou.okay

Instagram: @okaysousmile

Tiktok: okaysougloba

We sincerely hope you enjoy your new air purifier!

Best Wishes,
Okaysou Support

CONTENTS

●	SPECIFICATIONS	2
●	PACKAGE CONTENTS	3
●	SAFETY PRECAUTIONS	4
	GENERAL SAFETY	4
●	PRODUCT INTRODUCTION	6
	REMOVAL AND INSTALLATION OF FRONT COVER PLATE	7
	WHERE TO PLACE	7
	FILTER INSTALLATION	8
	UNIQUE 3-STAGE PURIFICATION TECHNOLOGY	9
●	GETTING TO KNOW YOUR AIR PURIFIER	10
	CONTROL PANEL	10
	CONTROLS	11
●	MAINTENANCE AND CLEANING	12
	CLEAN AIR PURIFIER	12
	WHEN TO CHANGE FILTER	12
	LONG IDLE	13
●	TROUBLESHOOTING	14
●	OTHER INFORMATION	16
	RECYCLING	16
	WHERE TO ORDER	16
●	WARRANTY	17

SPECIFICATIONS

Voltage	120 V / 60 HZ
Rated Power	55 W
Air Changes Per Hour	Circulates air 2x in rooms of 500 sq.ft./ 4x in rooms of 300 sq.ft.
Optimal Cover Range	300 sq.ft./28m ²
CADR	130 CFM / 220 m ³ /h
Noise Level	23-50 dB
Standby Power	0.5 W
Dimensions	13.78*8.47*17.32 INCHES
Weight	7.98 LBS

PACKAGE CONTENTS

- 1 x Apollo 718 Air Purifier
- 1 x H13 True HEPA 3-Stage Original Filter
- 1 x User Manual
- 1 x Warranty Card



SAFETY PRECAUTIONS

To reduce the risk of fire, electric shock, or other injury, follow all instructions and safety guidelines.

READ AND SAVE THESE INSTRUCTIONS

GENERAL SAFETY

- ⚠ Do not touch the power plug with wet hands. Otherwise, electric shock may be caused.
- ⚠ It is forbidden to use power supply or linked equipment outside the specified value. The use of universal socket or equipment beyond the specified value may cause overheating and fire accidents.
- ⚠ Plug in before starting the air purifier. If the plug is not fully inserted into the socket, it may cause electric shock and overheating, and even cause fire accident.
 - Do not use damaged plugs or loose power outlets.
- ⚠ Do not damage the power cord and socket. When using the machine, do not bind the wires. Using the damaged wires may lead to electric shock, short circuit or fire accident.
 - It is forbidden to cut, refit, over twist, twist, poke and pull wires, or place heavy objects on wires or sockets.
- ⚠ Please clean the power plug regularly. If dust accumulates on the power plug, the insulation part of the plug may be damaged, resulting in a fire accident.
 - Pull out the power plug and clean it with a dry cloth (do not use a wet cloth!).
 - If the appliance is not used for a long time, the power plug should be removed.
- ⚠ It is forbidden to disassemble or refit the air purifier without authorization. Unauthorized disassembly or modification of electrical appliances may lead to electric shock, failure or fire accident.
- ⚠ It is forbidden to place rods or other metal objects at the air outlet or opening. Otherwise, it may touch the internal parts and cause electric shock or damage.
- ⚠ It's forbidden to use benzene or thinner and other solvents. Otherwise, the air purifier may break and cause damage, even short circuit, resulting in electric shock or fire accident.
- ⚠ Hold the plug when pulling it out instead of pulling the wire. If the wire is pulled directly, it may be damaged or cause short circuit, leading to fire or electric shock.

- ⚠ It is forbidden to use this air purifier in places with greasy particles. For example, in the kitchen, the air purifier may break and cause damage.
 - The air purifier shall not be used as ventilation or air extraction equipment.
- ⚠ It is forbidden to use this air purifier in places with high temperature, humidity or wet body, such as bathroom. The air purifier may leak electricity and cause electric shock or fire accident.
- ⚠ It's forbidden to use the air purifier in the room with chemicals. Chemical residues may accumulate in the unit and then be released from the air outlet, thus endangering health.
 - After using chemicals, the room should be thoroughly ventilated before using the air purifier.
- ⚠ Do not let volatile substances or combustible materials, such as tobacco and sparks, into the air purifier. Otherwise, fire accidents may occur.
- ⚠ Do not wet the machine body. Otherwise, electric shock and fire accidents may occur due to short circuit.

WARNING

- Unplug the air purifier before moving it.
- Be sure to move the air purifier slowly.
- Do not move the air purifier by pulling the power cord.
- Do not move the air purifier while it is running.

WARNING



Unplug the air purifier immediately in case of any of the following conditions.

- If a switch does not work.
- If the circuit breaker works or the fuse burns out.
- If the power cord or plug is abnormally heat.
- If burnt odor, abnormal sound or vibration is found.
- If there is any other abnormal phenomenon or fault.

This appliance has a polarized plug(one blade is wider than the other). To reduce the risk of electric shock,this plug is intended to fit in a polarized outlet only one way.If the plug does not fit fully in the outlet,reverse the plug.If it still dode not fit, contact a qualified electrician.Do not attempt to defeat this safety feature.




PRODUCT INTRODUCTION



REMOVAL AND INSTALLATION OF FRONT COVER PLATE


1 Removal of front cover plate

Press the groove of the front cover plate with your fingers and pull it out at the same time.



2 Installation of front cover plate

Reinsert the front cover plate into the fixed groove and push it into the slot of the machine.




WHERE TO PLACE

In order to achieve good air circulation effect in your room, make sure that the air inlet and outlet of the machine are not less than 20 cm away from the obstacles.

Please use it at least 1m away from TV, radio and other electrical appliance.
Please do not put its power plug into the same socket as that of TV, radio and other electrical appliances.


- Use the air purifier in the same place for a long time may cause the surrounding walls contaminated.
- Keep the air inlet and outlet unblocked to ensure adequate ventilation and maximum efficiency of the air purifier.




FILTER INSTALLATION

When using the air purifier for the first time, please follow the steps below to install the filter correctly.


- 1 Remove all packages of the machine and place it on a dry and flat surface.




- 2 Press the filter cover, pull it out according to the unlocking direction and take out the base upward at the same time.



- 3 Remove the package of the filter and put it into the air purifier.



- 4 Reinsert the front cover plate into the fixed groove and push it into the slot of the machine.




The Obverse Side

WARNING

- When installing the filter cover, please install it carefully to prevent hand clamping.
- Ensure that the power plug is installed, repaired and transported when the power supply is disconnected.
- Do not run the air purifier without filter.
- Remove the plastic packaging of the filter before use.

UNIQUE 3-STAGE PURIFICATION TECHNOLOGY




Washable Pre-filter: Captures large particles such as dust, lint, fibers, hair. Maximizes the filter's life by protecting it.

H13 True HEPA Filter: Efficiently removes at least 99.9% of dust, fiber and any airborne particles with a size of 0.1 microns.

High-Efficiency Activated Carbon Filter: Physically absorbs unwanted odors and fumes. Filters compounds such as formaldehyde, benzene, ammonia, hydrogen sulfide, and volatile organic compounds (VOCs).


GETTING TO KNOW YOUR AIR PURIFIER

CONTROL PANEL



- 1** Timer Button
- 2** Filter Reset Indicator
- 3** On/Off Button
- 4** Display Off Button


- 5** Fan Speed Button
- 6** Timer Indicator
- 7** Fan Speed Indicator



CONTROLS


Fan Speed Setting

Press the fan speed button to choose from Low, Medium, High, and Sleep mode.



Sleep Mode

When choosing the "sleep mode", the sleep indicator will light up and then go out after a period of time. In the sleep mode, the fan runs in a low speed, and other indicators turn off. Press any button (except the power button) to exit the sleep mode.




Display Off Button

The ambient light will light up when running the air purifier. Press the "display off" button to turn off all the light.



Timer Setting

Cycle through 2/4/6/8 hours based on different needs.



Filter Reset Indicator

Press the "filter reset" button for 3 seconds after replacing the filter, and the indicator light for filter reset will turn off.



MAINTENANCE AND CLEANING

CLEAN AIR PURIFIER

- Unplug before cleaning.
- Wipe the outside of the air purifier with a soft, dry cloth. If necessary, wipe the housing with a damp cloth, then immediately dry.
- Vacuum the inside of the air purifier.
- Do not immerse the product in water or any other liquid.
- Do not use abrasives, corrosive or flammable cleaning agents (such as bleach or alcohol) to clean any parts of the air purifier.
- The original filter is not washable.

WHEN TO CHANGE FILTER

The filter should be replaced every 6–8 months. You may need to replace your filter sooner or later depending on how often you use your air purifier. Using your air purifier in an environment with relatively high pollution may mean you will need to replace the filter more often, even if is off.

You may need to replace your filter if you notice:

- Increased noise when the air purifier is on
- Decreased airflow
- Unusual odors
- A visibly clogged filter

NOTE

- The air purifier can still work normally when the indicator light for replacing the filter flashes and the buzzer sounds “Ding Ding” alarm.
- Please shut down and unplug the air purifier before replacing the filter.
- If the filter reset indicator still lights up after replacing the filter, please press the filter reset button for 3 seconds to reset the filter.
- Remove the plastic packaging of the filter before putting it into the air purifier.

To maintain the performance of your air purifier, only use official Okaysou filters. You can check our official website, [@okaysou.com](https://okaysou.com), for more information.

LONG IDLE

Unplug the air purifier (because the standby mode also consumes power) and wrap both the air purifier and the filter in plastic packaging and store in a dry and ventilated place to avoid moisture damage (keeping the air purifier flat or upside down may lead to product failure).



TROUBLESHOOTING

The common problems that may be encountered when using this air purifier are listed here. If you are unable to solve them according to the information below, please feel free to reach our support@okaysou.com.

PROBLEM	POSSIBLE REASON	POSSIBLE SOLUTION
Air purifier will not turn on or respond to button controls.	The air purifier is not powered on.	Plug in the air purifier.
	The power cord or wire is damaged.	Stop using the air purifier and contact support@okaysou.com .
	The socket is damaged.	Plug the air purifier into a different socket.
	The air purifier is malfunctioning.	Stop using the air purifier and contact support@okaysou.com .
Fan is not working.	The air purifier is not powered on.	Plug in the air purifier.
	The motor is damaged.	Stop using the air purifier and contact support@okaysou.com .
	Motor loose or foreign particles inside the air purifier.	Stop using the air purifier and contact support@okaysou.com .
Airflow is significantly reduced or air purification quality is poor.	The filter is not unpacked.	Make sure the filter is removed from its packaging and properly in place.
	The fan runs at low speed.	Tap the fan speed button to increase the fan speed.
	The air purifier is placed in a narrow space.	Make sure there are at least 20 cm of clearance to allow air to pass through the air inlets on the sides.
	The Pre-Filter may be clogged by large particles, such as hair or lint, blocking air flow.	Clean the Pre-Filter.
	The filter need to be replaced.	Replace the filter.
	The air inlet or outlet of the machine is blocked.	Remove obstacles in the air inlet and outlet.
	The windows or doors are open.	Close windows and doors while using the air purifier.

	More than expected room coverage.	Make sure that the room area is consistent with the specified area of the air purifier.
Air purifier makes an unusual noise while the fan is on.	The filter is not in place.	Make sure the filter is properly in place with plastic packaging removed.
	The air purifier is tilted.	Make sure the air purifier is operating on a hard, flat and even surface.
	The filter needs to be replaced.	Replace the filter.
	The air purifier may be damaged or a foreign object may be inside.	Stop using the air purifier and contact support@okaysou.com .
Strange smell coming from the air purifier.	The filter needs to be replaced.	Replace the filter.
	The motor is damaged.	Stop using the air purifier and contact support@okaysou.com .



OTHER INFORMATION

RECYCLING



When discarding products, please do not stack them with general domestic waste. Please understand the local regulations on classifying mobile phone electronic or electrical products.

Proper disposal of the product helps to avoid potential negative effects on the environment and human health.

WHERE TO ORDER

If you need to replace parts or purchase additional parts, please feel free to reach our support@okaysou.com.

WARRANTY

Okaysou warrants all products to be of the highest quality in material, craftsmanship, and service, effective starting from the date of purchase.

Okaysou will replace any product found to be defective due to manufacturer flaws based on eligibility. Refunds are available within the first 30 days of purchase. Refunds are only available to the original purchaser of the product.

This warranty is non-transferrable. Okaysou is not responsible in any way for any damages, losses, or inconveniences caused by equipment failure by user negligence, abuse, or use noncompliant with the user manual or any additional safety, use, or warnings included in the product packaging and manual.

This warranty does not apply to the following:

- Damage due to abuse, accident, alteration, misuse, tampering or vandalism.
- Improper or inadequate maintenance.
- Damage in return transit.

Register your 2-year warranty

Please enter <https://www.okaysou.com/pages/warranty> to gain your 2 years product warranty to purchase confidently.

If you are unable to register the warranty successfully, please contact Okaysou customer support to ask for help.

If you need information or have any questions, please feel free to reach our support@okaysou.com.

