


H26 ANC
TRUE WIRELESS EARBUDS USER MANUAL

Please read the Manual before use.



Lindero

Product Structure Description



Picture only for reference!

Packing List

1 pair of earbuds, 1 charging case, 4 pairs of tips (size: XS, S, L, M tips already on the earbuds), 1 USB cable, 1 User Manual.



Use Instructions

Bluetooth pairing

Method 1

Take out two earbuds, they will turn on and enter pairing mode automatically with orange and white indicator lights twinkling alternately, which enable the bluetooth of your phone to search "H26" and then click it for pairing, it will be connected.

Method 2

When the earbuds are turned on and not connected, double-tap the left or right MFB to enter pairing mode with orange and white indicator lights twinkling alternately. Which enable the bluetooth of your phone to search "H26" and then click it for pairing, it will be connected. (Note: If the earbuds have been connected to device 1, please turn off the bluetooth function of device 1 and then try to pair with device 2.)


Power On

The earbuds will turn on automatically when taken out from the charging case, with orange and white light is on for 1s; When the earbuds shut down, press the left or right MFB for 4s to boot up.

Power O

The earbuds will turn off automatically when put back into the charging case, with the orange light always on; When the earbuds is on and out of the charging case, long press the left or right MFB for 5s, then the orange light is on for 1s, that means the earbuds shut down.

Use of MFB



Reset

Put the earbuds back into the charging case with orange light on, long press the left and right MFB for 5s, the orange light turns off. Then wait the left and right earbuds pairing again (this operation takes about 10s), finally take out the earbuds to finish resetting.

ANC Mode

In standby state/music state:

<Active Noise Cancellation (ANC) Mode>

When using in binaural mode, long press the left MFB for 2s to hear the HearThrough mode turned on, then press for 2s more to turn on ANC; and press for another 2s to turn off ANC.

<HearThrough mode>

You can capture surrounding sounds by turning on the HearThrough mode. When you want to pay attention to the environment or have a conversation, this function is very convenient.

Operation method: long press the left MFB for 2s to enter the HearThrough mode; switch in the order: HearThrough mode → ANC On → ANC Off.

Note: The noise reduction function (ANC) is only available when both earbuds are used at the same time. You cannot use ANC when only using one earbud. In addition, ANC will be turned off when the power of the earbud is off.

Common questions

Q: Unable to connect to phone:

1. Ensure that the product has sufficient battery, has been turned on, and has been paired with the phone to establish connection.

2. The phone's Bluetooth activates.

3. Whether the distance between the product and the phone is more than 10 meters (about 30 feet), and whether there are walls, other obstacles or other electronic devices between them.

4. Please reset to factory settings and then re-pair.

Q: No voice heard

Please try to turn up the phone's volume.

Q: Have noise

Bluetooth is a wireless technology, which means it is very sensitive to objects between the product and the device it is paired with. The design conditions for use are: the distance between the product and the matching device is no more than 10m, and there is no big obstacle (such as wall) between the two. Note: The sound effect may be affected in noisy outdoor environment.

Battery Information

● This product is powered by rechargeable battery. A new battery will performance better after two or three complete charge and discharge cycles. The battery can be charged and discharged repeatedly, but it will eventually fail.

● If this product is placed in a over hot or over cold place, such as in a closed car in summer or winter, the capacity and life of the battery will be reduced. It is recommended to store in 15℃ to 20℃ environments. It may not work in extreme cold or hot environment even if it is fully charged. The battery's performance will be restricted when the temperature is far below freezing.

● Do not throw the battery into fire to prevent it from exploding. Damaged battery may also explode. Please follow the local regulations to deal with the battery. Please recycle the battery when possible, and do not dispose of it as household garbage.

Warm Tips: If this product is not used frequently, please regularly recharge and discharge it every three months, to avoid battery damage caused by unused for too long time.