

2.4G+Bluetooth+Bluetooth Wireless Rechargeable RGB Trackball Mouse

EM01

[illegible]

- | | |
|-----------------------------------|-------------------------------|
| A Left Button | S Right Button |
| C Forward Button | D Backward Button |
| E Trackball | F Led Rim Light |
| G Light Switch Button | H DPI Button |
| I Charging / DPI Indicator | J Scroll Wheel |
| K Switch Device Button | L 2.4G Indicator |
| M Wireless 1 Indicator | N Wireless 2 Indicator |
| O TYPE-C Charging Port | P Power Switch |
| Q USB Receiver | |

Light mode: 1. Streamer mode (Default) 2. Breathing mode
3. Mixed color breathing mode 4. Neon mode

A diagram of a shoe sole cross-section. The sole is shown at a 20-degree angle, indicated by a curved arrow and the text "20°". A downward-pointing arrow is positioned above the sole, indicating a direction of force or movement.

-
3. Press the mode switch button until the white light ③ is on and enter 2.4G mode.
4. Insert the usb receiver into your computer's USB port.

- mode, the white light flashes slowly.
- 1 2
- 3
- 
3. Press and hold the mouse switch button for 3-5 seconds until the white light flashes quickly, then the mouse enters the Bluetooth pairing mode.

4 Click "Bluetooth device"

A screenshot of the Windows 8 Start screen. A white callout bubble with a gear icon inside points to the Settings icon (a gear) in the bottom-left corner of the Start screen. The Start screen shows various app tiles like Photos, Music, and Mail, and the Windows logo in the bottom-left corner.

5 Click "Add or remove a Bluetooth device"

A screenshot of the Windows 8 Settings app. A white callout bubble with a Bluetooth icon inside points to the Bluetooth icon in the left-hand navigation pane. The main area of the app shows the 'Bluetooth' settings page.

-
- 6 Your computer will automatically search for * ProtoArc EM01 and then click "pair"

Your PC is searching for and can be discovered by Bluetooth devices.

*** *

	ProtoArc EM01 Connected
	Unknown Ready to pair

Please complete the Bluetooth mode installation step 123 before pairing.

6 Your computer will automatically find "ProtoArc EM01", then click "pair", and you can use it after installation.

Please complete the Bluetooth mode installation step 123 before pairing.

5 Click Touch

8 Your computer will automatically find "ProtoArc EM01", then click "Pair", complete pairing.

The screenshot shows the 'Settings' app with the 'Bluetooth' option selected. The Bluetooth toggle switch is turned on. Under the 'DEVICES' section, 'ProtoArc EM01' is listed with a status of 'Connected' and an information icon.

before pairing.

4 Click Settings on the device, then turn on Bluetooth

The screenshot shows the 'Settings' app on an Android device. The 'Bluetooth' option is highlighted with a blue circle, and the toggle switch next to it is turned on. Below the Bluetooth section, there are options for 'Share storage' and 'Security'.

corresponding channel indicator flash until it is turned off. Please connect the power supply for charging in time, and use the USB cable to connect the TYPE-C charging Port.

mode switch button on the top of the mouse to switch between multiple devices.

Wireless 1 Device Connection

The diagram illustrates a 'Wireless 1 Device Connection' setup. At the top, a laptop icon is shown inside a circle. Below this circle is a central hub icon, which is a circle containing a sun-like symbol. From the bottom of this central hub, three lines extend downwards to three numbered circles labeled ①, ②, and ③. This represents a single device (the laptop) connected to a central hub, which then connects to multiple devices (1, 2, and 3).

Chip: Nordic NRF51802W
Movement Detection Technology: Optical
Lithium battery Capacity: 900mA
DPI: 1000-1600-2400
Click life: 3 million+
Dimension: 133*101*51mm
Weight: 190g

Bluetooth transmission parameters:
Transmission distance: 10m
Working Voltage: 3.7V
Working current: 4mA
Reaction rate: 125KHz

System requirement:

- ▶ 1 x Wireless Mouse
- ▶ 1 x USB Receiver
- ▶ 1 x Type C Charging Cable
- ▶ 1 x User Manual

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

