



Razor®

POWER A5 COLLAR CLAMP REPLACEMENT PROCEDURES PART # W13113202178

Required Tools: (Not included)

A. 5 mm Allen wrench

WARNING

 CAUTION: To avoid potential shock or other injury, turn power switch OFF and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Using a 5 mm Allen wrench, loosen the bolt from the collar clamp. Slide the stem off from the fork.



Step 2

Slide collar clamp off from the stem and remove the bolt from the collar clamp completely. This will allow you to pass the collar clamp through the throttle cable.



Step 3

Reverse the steps.

ATTENTION: Charge battery 10 hours before using.

