


Instruction Contents:

- Step 1 - What's Included
- Step 2 - Warnings & Precautions
- Step 3 - Electrical Wiring
- Step 4 - Mounting Methods & Instructions
- Step 5 - LED Controller Specifications
- Step 6 - Warranty

Step 1 - What's Included:

- 1 - Cannon 80 LED Module w/multichip LED & snoot (A)
- 1 - Swivel bracket with T-Slot mounting hardware (B)
- 1 - 15 Ft. (3M) 100-130VAC Power Cord (C)

**Step 2 - Warnings & Precautions**

This Luminaire **MUST** be plugged into a GFCI

To Avoid injury and possible electric shock it is imperative you:
READ AND FOLLOW ALL SAFETY INSTRUCTIONS AND WARNINGS

Important Warnings

This is NOT a page of legalese. It contains important safety information that you should read and save for future reference. Remember you can always quickly reference instructions for all Ecoxotic products on our website.



Cannon 80 LED Module

Product Manual & Safety Instructions

ecoxotic

To Avoid injury and possible electric shock it is imperative you:
READ AND FOLLOW ALL SAFETY INSTRUCTIONS AND WARNINGS

- Never attempt repairs yourself; return the appliance to an authorized service facility for service, or discard the appliance.
- Carefully examine the fixture after installation and BEFORE plugging into a GFCI, dimmer or power.
- Never operate a fixture that is damaged or malfunctioning. Discontinue use immediately and return to an authorized service facility.
- Close supervision is necessary when an appliance is used by or near children.
- Always unplug the fixture when not in use, before putting on or taking off parts, and before cleaning. Never yank the cord to pull plug from the GFCI. Grasp the plug and pull to disconnect.
- Do not use the fixture other than for intended use. The use of attachments not recommended or sold by the fixture manufacturer may cause an unsafe condition and will void your warranty.
- Do not use or store the fixture where it will be exposed to the weather or to temperatures below 0 degrees Celsius or 32 degrees Fahrenheit.
- Do not operate at temperatures above 50 degrees Celsius or 122 Degrees Fahrenheit.
- Ensure the fixture is securely installed before supplying power to the unit.
- Read and observe all important notices and warnings on the fixture and power cord.
- If an extension cord is necessary, a cord with a rating at least 15 Amperes should be used. A cord rated for less Amperes or watts than the fixture rating may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
- **DO NOT** look directly into the LEDs.

Step 3 - Electrical Wiring

Warning: This product must be installed by a licensed electrician

Before beginning any work on the electrical installation, be sure that the main breaker panel is "OFF" to avoid any danger of electric shock. All mounting of the unit must be completed before proceeding with electrical hook-up. Where required by local, state or National Electric Codes the circuit should be equipped with a ground fault interrupter. As with any electric appliance, failure to electrically ground unit may result in serious injury or death.

Grounding Instructions

This appliance must be connected to a GFCI plug then to a grounded wall outlet to minimize the possibility of electric shock. This plug must be plugged into an outlet that is installed and grounded in accordance with all appropriate codes and ordinances.

This appliance must be installed on a grounded circuit 120VAC.

If you do not have an available grounded outlet, you must have one installed by a qualified electrician.



Warning: This product must be installed by a licensed electrician



Electrical Requirements

- The LED driver must be supplied with 120VAC, per product label and connected to an individual properly grounded branch circuit, protected by a 15 or 20 ampere circuit breaker.




Grounding Instructions

- The grounding and bonding of the overall system shall be done in accordance with National Electric Code (NEC) Article 600 and local codes.

Wiring Instructions

Attach power cord at quick disconnect by connecting and hand-tightening the disconnect plug. Plug into appropriate voltage outlet and test lamp before installation. Please use the wiring diagram below.

Connect Plug & Tighten




Step 4 - Mounting Instructions

The Cannon 80 LED includes an adjustable swivel bracket for easy installation to standard 1" T-Slot aluminum. Swivel bracket can also be installed to aluminum tubing, wood beams, and track style lighting (hardware for these installs not included and dependent upon your application.)

Swivel Bracket Assembly

1. Place bracket around light, install flat washer (A) between bracket and light to ensure swivel action. Thread hex screw (B) with lock washer (C) thru bracket hole and light, tighten using allen wrench provided.

Slightly thread T-Slot nuts (F) to bracket, ensuring hex screw (D) and lock washer (E) are on internal side of bracket. T-Slot nut round side should face outside. Slide T-Slot nuts into T-Slot aluminum as shown, position into place and tighten using allen wrench.



Swivel light to optimal position and tighten swivel bracket.

Plug light into GFCI (or Smartplug dimmer) for operation.

Step 5 - LED Control Specifications

Cannon 80 LED lights feature a dimmable COB LED chip with integrated Smart IC driver and is compatible with most AC LED lighting dimmers, smartplugs and controllers. Specs:

Voltage Input: 100-130VAC

Max. Watts: 81.2

Max. Current: 0.8A



Warranty

This limited warranty applies only to products that are manufactured by or for Ecoxotic and can be identified by trade name or logo affixed to it, and sold by an authorized Ecoxotic retailer in the United States to you, the original purchaser of such products ("Products"). Ecoxotic hereby warrants that Products will be free from defects in materials and workmanship for a period of one (1) year from the date of original retail purchase (the "Warranty Period"). This warranty does not apply to any product that is not an Ecoxotic Product.

This warranty does not apply to Products (i) that have been damaged by accident, abuse, misuse or misapplication, improper installation, saltwater corrosion, electrical surges, (ii) that have been modified without the written permission of Ecoxotic or, (iii) for which any Ecoxotic logos have been removed or defaced.

US and Canadian residents can contact Ecoxotic directly if you discover a defect in any Product. In the event that such Product is defective, as determined by Ecoxotic in its sole discretion, Ecoxotic's sole obligation, and your exclusive remedy, shall be for Ecoxotic, at its option, to repair or replace such Product at no charge to you, provided that you (i) return such Product to Ecoxotic during the Warranty Period, and (ii) provide proof of purchase and registration of such Product. If the returned Product is not defective or is returned after the Warranty Period, Ecoxotic shall have no obligation to repair or replace the Product. Residents outside the US and Canada should contact the place of purchase for warranty issues.

EXCEPT AS EXPRESSLY PROVIDED ABOVE OR AS REQUIRED BY LAW, ECOXOTIC PRODUCTS ARE PROVIDED "AS IS," WITHOUT WARRANTY OF ANY KIND. THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS, WHETHER ORAL OR WRITTEN. ALL WARRANTIES IMPLIED BY STATE LAW, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY LIMITED TO THE LESSER OF THE DURATION UNDER STATE LAW OR THE DURATION OF THE LIMITED WARRANTY SET FORTH ABOVE. IN NO EVENT SHALL ECOXOTIC BE RESPONSIBLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPLACEMENT OF OTHER EQUIPMENT OR PROPERTY, COSTS OF RECOVERING OR REPLACING ANY ANIMALS, FISH, PLANTS, TANKS OR OTHER AQUARIUM RELATED ITEMS AND/OR EQUIPMENT, OR PERSONAL INJURY. Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on the duration of implied warranties, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

This warranty is not transferable. No person is authorized to change, modify or extend the terms of this warranty in any manner. This warranty is governed by the laws of the State of California, excluding conflicts of laws principles. Ecoxotic reserves the right to make changes, additions and improvements to its products from time to time, and has no obligation to replace the exact same model of Product.

