

BE.sports

使用指南

使用产品前请仔细阅读本说明书，并妥善保管。

简介

运动蓝牙耳机是一款真正的无线蓝牙耳机，它采用Open Ear Audio设计，让您在进行锻炼时能享受音乐和感知周围环境；镜腿中嵌入了两个专门设计的扬声器，可产生更响亮、更深沉的声音。

配件

1. 运动蓝牙耳机*1

5. 眼镜布*1

2. USB 磁吸充电线*1

6. 眼睛盒*1

3. 额外镜片*3

7. 收纳袋*1

4. 鼻托S,M,L

8. 说明书*1

规格参数

蓝牙版本:	Bluetooth V5.1
蓝牙协议:	HFP、HSP、A2DP、AVRCP
有效距离:	10mm
工作时间:	About 5 hrs (最大音量) About 6.5 hrs (50%音量)
充电输入:	DC 5.0V --- 500mA
充电时间:	About 2 hrs
尺寸:	眼镜: 162.9*162.8*53.4mm 充电线: 500mm
重量:	眼镜: 43.3g; 充电线: 11.8g

产品概览

1	镜腿	7	主麦克风
2	副麦克风	8	充电磁吸触点
3	压感按键	9	指示灯 (红色, 蓝色)
4	镜片	10	左喇叭
5	右喇叭		
6	鼻托		

快速使用

根据您的鼻梁骨的高低，选择最合适的一款鼻托安装到眼镜架上。

更换镜片

1. 用手捏住镜片的一端，先将一端的鼻托支架从外往下按压，使镜片与支架分离，另一端重复步骤。

2. 镜片往下拉出。

3. 选好镜片后，将镜片左右两端卡入镜框内。

4. 将鼻托支架从外往上按压，使镜片与支架结合。

镜片透光度

灰色: 10-11.5%
橙红色: 11-19.5%
蓝色: 11-19.6%

首次连接

1. 开机: 镜腿打开自动开机，蓝灯闪烁10秒，眼镜提示“开机”。

2. 与手机配对

1) 眼镜开机后自动进入配对模式，同时眼镜提示“蓝牙配对”。

2) 眼镜在配对模式时，从手机蓝牙列表搜索 BE.sports 点击连接，配对连接成功后，眼镜提示“蓝牙连接”。

若您所在区域电磁波干扰信号较强，可能影响蓝牙的连接，而出现眼镜无声或者断连的情况

功能说明

音乐/通话控制

功能	(右) 操作	提示音
暂停/播放	●	1 响声
上一曲	●●●	3 响声
下一曲	●●	2 响声
取消呼叫	●	1 响声
接听来电	●	1 响声
拒接来电	●● 长按2s	1 响声
结束通话	●	1 响声
进入语音助手	●● 长按2s	1 响声
退出语音助手	●● 长按2s	1 响声

充电指示

在使用过程中，当红灯连续闪烁时表示电池电量低，您需要对眼镜充电。将眼镜连接充电线，确保眼镜与充电线的磁吸接触到位，看到眼镜红色指示灯长亮即开始充电。

眼镜充满电时间: 约2小时。

正在充电: 红灯长亮
已充满电: 红灯熄灭

注意: 长时间未使用眼镜时，建议至少3个月为眼镜充一次电，以免电池耗尽而未进入休眠模式。

电量显示

本眼镜与iOS手机或部分Android手机连接时，可在手机上实时显示眼镜当前电量，且眼镜低电量时，电量符号内显示为红色，可提示用户为眼镜充电。对于不同的手机，可能手机上电量显示的方式会有所不同，以下是以iOS手机的电量显示截图。

压感按键: ● 单击 ●● 双击 ●●● 三击 ● 长按

恢复出厂设置

眼镜处于配对模式时，四击压感按键，看到红蓝灯同时长亮2秒时即已恢复出厂设置。

压感按键: ●●●● 四击

注意: 恢复出厂设置后将眼镜与手机的配对记录清除，打开镜腿开机会自动进入与手机的配对模式 (红蓝灯交替快闪)，您需要与手机重新配对连接。

保养与维护

- 在使用时，请阅读以下建议，有助于您遵守保修条款，并延长产品的使用寿命。
- 保持产品干燥，勿将放在潮湿的地方，以免影响产品内部电路。需避免在激烈运动或出汗较多时使用本产品，防止汗水渗透到产品内部损坏本产品。
- 将收起产品之前，请清洁产品，以免汗液腐蚀产品。
- 勿将产品放置在温度高的地方。高温会缩短电子部件的使用寿命、损坏电池、使某些塑料部件变形。
- 勿将产品放在过冷的地方，以免损坏内部电路板。
- 勿试图拆开产品。如果非专业人员，可能会损坏产品。
- 不要跌落、强烈抖动、用硬体撞击产品，以免会损坏内部电路。
- 勿使用腐蚀性化学制品、清洁剂清洗耳机。
- 不要使用尖体在产品表面上乱划，以免损坏外壳和影响外观。
- 如果产品不能正常工作，请将其送至您的合格维修机构，工作人员会热心帮您解决问题的。

3. 充电时，红灯不亮。

- 可能充电线磁吸与镜腿磁吸接触不到位。
- 请确保眼镜以及充电线的金属触点无障碍物。
- 长时间不使用眼镜，电池会进入休眠状态。此时需要充电大约30分钟红灯才会亮。

4. 眼镜听不到声音。

- 确认手机的音量大小是否合适。
- 确认眼镜是否与手机正常连接。
- 确认眼镜是否与手机距离过远或周边有干扰物。

5. 眼镜通话效果不好。

- 确认手机是否在信号强的地区。
- 眼镜的有效使用距离为10米，请确认眼镜在有效使用距离内，且眼镜与手机间无障碍物阻隔。

6. 为什么播放音乐时，眼镜不能进行暂停、恢复和下曲控制。

- 此功能需要与眼镜配对的手机支持AVRCP(Audio/Video Remote Control Profile)协议。

⚠ 警告: 为本产品提供电源的可充电电池必须妥善处置，以便回收利用。请与当地的回收中心联系获取妥善处置的办法。不要将电池放入火中，以免引起爆炸。

感谢您的购买

感谢您购买本公司的蓝牙产品。为了更好的为您提供使用体验和安全保护，请在使用本产品前仔细阅读本说明书。并保存这本手册，以备将来参考。

BE.sports

User Manual

Please read this manual carefully before using the product and keeping properly.

Introduction

Sports Bluetooth glasses are truly wireless Bluetooth glasses. It is designed with Open Ear Audio, allowing you to enjoy music and perceive the surrounding environment while exercising; two specially designed speakers are embedded in the frames to produce louder, and deeper voice.

Accessories

1. Bluetooth eyewear*1

5. Glasses cloth*1

2. USB Magnetic charging cable*1

6. Eye box*1

3. Extra lens*3

7. Storage bag*1

4. Nose pads S, M, L

8. Manual*1

Specifications

Bluetooth version:	Bluetooth V5.1
Bluetooth protocol:	HFP、HSP、A2DP、AVRCP
Effective distance:	10mm
Operating hours:	About 5 hrs (Maximum volume) About 6.5 hrs (50% volume)
Charging input:	DC 5.0V --- 500mA
Charging time:	About 2 hrs
Size:	Glasses: 162.9*162.8*53.4mm Charging Cable: 500mm
Weight:	Glasses: 43.3g; Charging Cable: 11.8g

Product overview

1	Glasses frame	7	Main microphone
2	Secondary microphone	8	Charging magnet contact
3	Pressure sensitive buttons	9	Indicator light (red, blue)
4	Lens	10	Left speakers
5	Right speakers		
6	Nose pads		

Quick to use

According to the height of your nose bridge, choose the most suitable nose pad to install on the glasses frame.

Replace the lens

1. Grasp one end of the lens with your hand, first press the nose support bracket at one end from the outside to separate the lens from the bracket, and repeat the steps with the other end.

2. The lens is pulled down.

3. After selecting the lens, snap the left and right ends of the lens into the frame.

4. Press the nose support bracket from the outside up to combine the lens with the bracket.

Lens transmittance

Grey: 10-11.5%
Orange red: 11-19.5%
Blue: 11-19.6%

Connect for the first time

1. Power on: When the frames are turned on, it automatically turns on, the blue light flashes for 10 seconds, and the glasses prompt "power on".

2. Pair with your phone

1) After the glasses are turned on, they automatically enter the pairing mode, and the glasses prompt "pairing".

2) When the glasses are in the pairing mode, search BE.sports from the phone's Bluetooth list and click connect. After the pairing is successful, the glasses will prompt "Connected".

3. Power off: When the frames are folded and closed, it will automatically shut down, the red light will be on, and the glasses will prompt "Power off".

Note: 1. When the glasses are not connected to the device state, they will automatically enter the pairing mode after 10 seconds.

2. The pairing mode will be maintained for 5 minutes, and the glasses will automatically shut down if they are not paired with any mobile phones for more than 5 minutes.

If the electromagnetic interference signal is strong in your area, it may affect the Bluetooth connection, and the glasses may be silent or disconnected.

Function Description

Music/call control

Function	(Right) Operation	Beep
Pause playback	●	1 Beep
Previous song	●●●	3 Beep
Next song	●●	2 Beep
Cancel call	●	1 Beep
Answer the call	●	1 Beep
Reject call	●● Press2s	1 Beep
End the call	●	1 Beep
Enter the voice assistant	●● Press2s	1 Beep
Exit voice assistant	●● Press2s	1 Beep

Charging instructions

During use, when the red light flashes continuously, it means that the battery is low and you need to charge the glasses. Connect the glasses to the charging cable, ensure that the magnetic contact of the glasses and the charging cable is in place, and start charging when the red indicator light of the glasses is on. Full charge time for glasses: about 2 hours.

Charging: the red light is on
Fully charged: the red light is off

Note: When the glasses have not been used for a long time, it is recommended to charge the glasses at least once in 3 months to avoid the battery from running out and entering the sleep mode.

Power display

When the glasses are connected to an iOS phone or some Android phones, the

current battery level of the glasses can be displayed on the phone in real time, and when the battery is low, the battery symbol is displayed in red, which can prompt the user to charge the glasses. For different mobile phones, the battery display method on the mobile phone may be different. The following is a screenshot of the battery display of the iOS mobile phone.

Reset

When the glasses are in the pairing mode, click the pressure-sensitive button four times, and the red and blue lights will be on for 2 seconds at the same time to restore the factory settings.

Pressure sensitive buttons: ●●●● Four clicks

Note: After restoring the factory settings, clear the pairing record of the glasses and the phone, turn on the frames and automatically enter the pairing mode with the phone (the red and blue lights flash alternately), and you need to re-pair and connect with the phone.

Care and maintenance

- When using it, please read the following suggestions to help you comply with the warranty terms and extend the life of the product.
- Keep the product dry and do not place it in a damp place, so as not to affect the internal circuit of the product. Avoid using this product during intense exercise or sweating a lot to prevent sweat from penetrating into the product and damaging the product.
- Please clean the product before putting it away to prevent sweat from corroding the product.
- Do not place the product in a cold place to avoid damage to the internal circuit board.
- Do not try to disassemble the product. If you are not a professional, the product may be damaged.
- Do not drop, vibrate strongly, or hit the product with hard objects, so as not to damage the internal circuit.
- Do not use harsh chemicals or detergents to clean the glasses.
- Do not scratch the surface of the product with a sharp object, so as not to damage the shell and affect the appearance.
- If the product does not work normally, please send it to your qualified maintenance organization, and the staff will be eager to help you solve the problem.

FAQs

1. The glasses cannot be connected to the device.

Please check the following steps in order

- Whether the Bluetooth of the device is turned on.
- Whether the glasses have been connected back to other devices.
- At this time, the glasses cannot be found on the Bluetooth of the new device. Turn off the Bluetooth or move away from the connected device, restart the glasses, and enter the pairing mode.

2. The red light flashes 4 times a minute.

- The glasses battery is low and you need to charge the glasses again.

3. When charging, the red light is off.

- The magnetic attraction of the charging cable may not be in contact with the magnetic attraction of the glasses.
- Please make sure that the metal contacts of the glasses and the charging cable are free of obstructions.
- If the glasses are not used for a long time, the battery will enter a sleep state. At this time, it needs to charge for about 30 minutes before the red light turns on.

4. No sound can be heard through the glasses.

- Confirm that the volume of the phone is appropriate.
- Confirm whether the glasses are properly connected with the mobile phone.
- Check if the glasses are too far away from the mobile phone or there are interference objects around them.

5. The glasses call is not good.

- Check if the mobile phone is in an area with strong signal.
- The effective use distance of the glasses is 10 meters. Please confirm that the glasses are within the effective use distance and that there is no obstacle between the glasses and the mobile phone.

6. Why the glasses can't control pause, resume and next song when playing music.

- This function requires the mobile phone paired with the glasses to support the AVRCP (Audio/Video Remote Control Profile) protocol.

⚠ Warning: The rechargeable battery that provides power to this product must be properly disposed of for recycling. Please contact your local recycling center for proper disposal methods. Do not put the battery in the fire, so as not to cause an explosion.

感谢您的购买

Thank you for purchasing our company's Bluetooth products. In order to provide you with a better user experience and safety protection, please read this manual carefully before using this product. And save this manual for future reference.