



Instruction Manual

Please read before operating product

Basic Operation

1. Power On: Remove the earbuds from the charging case. In one second, earbuds will automatically power on and blue light will illuminate.
2. Power Off: Place the earbuds into the charging case, or press and hold the earbuds to power off.
3. After startup, hold the earbuds near each other to allow for a connection between the two to establish automatically.
4. Earbuds turn off automatically when powered on for 3 minutes without connecting to any devices.

Bluetooth® Operation

To use your Bluetooth ® headset, you must first pair the TWS with a mobile phone. Once your Bluetooth® headset is paired with a mobile phone, they will remain paired and automatically recognize each other whenever they are within range.

1. Turn on your phone and ensure the Bluetooth function is activated.

Table of Contents	
Introduction.....	3
Package Contents.....	3
Safety Instructions.....	4
Product Breakdown.....	6
How to Use.....	7
Specifications.....	12
Support.....	14

2. Turn on the earbuds, they will flash red and blue to signify discovery mode, and initiate a device search on your phone via the Bluetooth settings menu.
3. Search the Bluetooth® devices on your phone by following the phone's instructions. Refer to your phone's user manual for more information.
4. After a few seconds the phone will list the "NAXA NE-983 as a discovered device. Select it and follow your phone's instructions to establish a connection.

Playback

1. To play/pause a song through your bluetooth earbuds from your mobile phone, briefly press the MF button. To skip to the previous song, double click MF button on L/C. To skip to the next song, double click MF button on R/C.
2. To operate earbuds via Siri, press the multi-function button three times of L/C or R/C.

Introduction

Congratulations, and thank you for choosing Naxa's True Wireless Bluetooth® Earbuds & Charging Case. This manual will help you operate your new device, but first you should familiarize yourself with the Bluetooth functionality of your mobile phone or other external devices before using the Naxa True Wireless Bluetooth® Earbuds & Charging Case.

Package Contents

- NE-983
- USB Charging Cable
- Instruction Manual

Answering Calls

1. To answer incoming calls, briefly press the multi-function button.
2. To end a call, briefly press the multi-function button again.
3. To reject an incoming call, press and hold the multi-function button for 2 seconds.

Earbud Settings

1. In order to restore the earbuds back to factory settings, rapidly press the multi-function button 2 times when earbuds taken out of the charging case and not connect to bluetooth device.

Charging Earbuds

1. Place earbuds into charging case, indicator light will turn bright red to signify that they are charging.
2. Charging status will display on the screen of the charging case for the L and R earbuds.
3. Once charging is complete, the lights will turn off.

Safety Instructions

Before using the device, read the operating instructions very carefully. Keep this operation manual for later reference.

1. Do not use an appliance for any purpose other than its intended use.
2. Warning: Do not expose the appliance to extreme temperatures, to strong temperature fluctuations, direct sunlight or humidity.
3. To prevent any potential auditory damage, do not listen to music at high volumes for long periods.
4. No naked flame sources, such as lit candles, should be placed on the appliance.
5. This appliance should be used in temperate climate only.
6. Electric and electronic equipment should be disposed of separately. Do not discard used electric and electronic equipment with unsorted municipal waste but have them collected separately.
7. Attention should be drawn to the environmental aspects of battery disposal.
8. The appliance contains a battery or batteries that are non-replaceable.

Charging Case

1. Insert the Micro USB end of the included charging cable into the input of the charging case.
2. Insert the other end of the charging cable into an external power source.
3. Charging case will illuminate and power percentage will be displayed on screen and begin flashing.
4. Once completed, 100% charged will be displayed on the digital display.

9. Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
10. The battery must be removed from the appliance before it being disposed of properly.
11. Only remove the rechargeable battery when you intend to dispose of the appliance. Have the rechargeable battery removed by trained professionals.
12. **CAUTION!** Risk of explosion if battery is replaced by an incorrect type of battery.
13. Dispose of used batteries according to the instructions


Specifications

Bluetooth® Version: 5.0
Charging Interface: Type-C
Power Input: DC/5V
Earbuds Battery Capacity: 40mAh/3.7V
Support: A2DP/AVCTP/AVDTP/AVRCP/HFP
Music Time: About 3.5 Hours (80% Volume)
Talk Time: 2.5 Hours (90% Volume)
Rechargeable Battery: 300 mAh/3.7V

FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.


Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment



generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference, will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION ON MODIFICATIONS
Any changes or modifications not expressly approved by the grantee of this device may void the authority granted by the FCC to operate the equipment.



Support

If you have problems with your device, please consult the instructions in this manual. Please also visit us on the web at www.naxa.com to get up to the minute news, alerts, and documentation for your device. For additional assistance, please contact Naxa Technical Support.

NAXA Technical Support
2320 East 49th St.
Vernon, CA 90058

http://www.naxa.com/naxa_support/
MADE IN CHINA