



GETTING TO KNOW YOUR CURLING IRON



AVAILABLE IN THE FOLLOWING SIZES



USER MAINTENANCE CAUTION

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

When not in use, your appliance is easy to store. Allow appliance to cool, then simply store out of reach of children in a safe, dry location. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

KEEP AWAY FROM WATER BEFORE USING

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

1. **Never operate this appliance if it has a damaged cord or plug, it is not working properly or if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.**
2. **Keep the cord away from heated surfaces.**
3. **Never use while sleeping.**
4. **Never drop or insert any object into any opening or hose.**
5. **Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.**
6. **Unit is hot when in use. Do not let heated surface touch eyes or bare skin.**
7. **Do not place the heated unit directly on any surface while it is hot or plugged in.**
8. **Never block the air openings of the appliance or place on a soft surface such as a bed or couch, where the air openings may be blocked. Keep the air opening free of lint and other debris.**
9. **Do not use an extension cord with this appliance.**
10. **Do not touch hot surfaces of the appliance.**
11. **Do not attempt to touch the housing of your appliance near the barrel, as it is hot when in use.**

SAVE THESE INSTRUCTIONS

LED TEMP. CONTROL	HAIR TYPE
High/Max 360°F - 400°F	Hard-to-curl hair
Med-High 330°F	Thick or wavy hair
Medium 310°F	Average-to-thick or treated hair
Power/Low 285°F	Delicate, thin, easy-to-curl hair

Temperature Setting Guide

The iron's unique 5 high heat temperature settings and Instant Heat technology provide styling versatility for all hair types. If you have fine hair, a low temperature will provide the best results. If you have thick, wavy or hard-to-curl hair, keep the heat setting on high. You can vary the iron's temperature according to your particular need!

GETTING STARTED

For best results, use a light styling product before blow-drying hair. Start curling with a hair section that is 1 inch wide and no more than 1/2 inch thick. Open the spoon and place a hair section on the barrel, rolling up, close to the scalp. Release the pressure on the handle and allow the hair section to slide out. Repeat process on additional sections of hair until you achieve the hair style you desire. It may be necessary to repeat process on certain areas, depending on the texture of your hair.

Some experience is necessary when learning to use this curling iron. After using the iron several times, you will learn the ideal way to curl and style your hair.

A bonus protective heat shield has been included to safely store product away when hot. Great for use at home or when traveling. Do not leave unit plugged in when not in use.

TO CURL HAIR

OPERATING INSTRUCTIONS


This curling iron is intended for household use. Use on Alternating Current (60 hertz) only. This unit is designed to be operated at 120V AC.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

WARNING: The curling iron's tourmaline ceramic-coated barrel will get very hot within a few seconds and should not be placed in contact with the skin after the curling iron has been turned on.

ALWAYS UNPLUG SMALL APPLIANCES

Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.



KEEP AWAY FROM WATER

WARNING: IF YOU THINK THE POWER IS OFF WHEN THE SWITCH IS OFF, YOU'RE WRONG.

LIMITED FIVE YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 60 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed on back, together with your purchase receipt and \$5.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 60 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED IN DURATION TO THE 60 MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR OTHER WARRANTY, EXPRESS OR IMPLIED, TOTAL DAMAGES FOR BREACH OF THIS OR ANY ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES. Some states do not allow this warranty to give you other rights, which vary from state to state.

Please register this product at:
www.conair.com/registration

©2011 Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

For info on any Conair or Infiniti by Conair product call: 1-800-3-CONAIR or visit us on the web at: www.conair.com/infiniti

11PA119473
IB-10538A

Models CD107TP and CD109BP



INFINITI PRO CON
nano tourmaline ceramic curling iron

This styling iron features a ceramic heater that maintains constant temperature during use for precision styling.

This Instant Heat technology has 5 high heat glides easily over the surface of the barrel as you're curling. The tourmaline ceramic surface also helps smooth down flyaways and frizzies. It evenly distributes heat so that the style you create has a salon-perfect, silky smooth, resistant, and helps you create the look you want. And that's not all. Conair's professional salon standards of engineering provide you with a uniform and improved heat recovery system that maintains the iron at constant temperature. There is a constant surge of power to ensure that heat is continuously and quickly delivered for optimal styling results, unlike other units, which lose heat during use. This provides consistent styling power so that every strand of your hair is set with the same level of heat and comes out the same way for a perfect finish.

STYLING WITH THE NEW TOURMALINE CERAMIC EASY-GLIDE BARREL

The barrel of your new curling iron has a newest technology. This means it's not only simpler to clean off styling product residue, etc., after each use, but you'll find that hair glides easily over the surface of the barrel as you're curling. The tourmaline ceramic surface also helps smooth down flyaways and frizzies. It evenly distributes heat so that the style you create has a salon-perfect, silky smooth, resistant, and helps you create the look you want. And that's not all. Conair's professional salon standards of engineering provide you with a uniform and improved heat recovery system that maintains the iron at constant temperature. There is a constant surge of power to ensure that heat is continuously and quickly delivered for optimal styling results, unlike other units, which lose heat during use. This provides consistent styling power so that every strand of your hair is set with the same level of heat and comes out the same way for a perfect finish.

Never leave your curling iron on and unattended. However, should you fail to turn the iron off, it will shut itself off automatically within 60 minutes.

3. This appliance should not be used by, on or near children or individuals with certain disabilities.

2. Do not pull, twist, or wrap line cord around appliance.

1. This appliance should never be left unattended when plugged in.

WARNING - To reduce the risk of burns, electrocution, fire, or injury to persons:

1. **Always unplug appliance immediately after using.**
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into, water or other liquids.
5. If an appliance falls into water, unplug it immediately. Do not reach into the water.

DANGER - Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

KEEP AWAY FROM WATER

Diagrama detallado de un secador de pelo profesional con sus componentes etiquetados:

- Punta aislante
- Revestimiento de mano cerámica/turmalina
- 5 ajustes de temperatura con indicadores LED
- Sistema de conservación del calor
- Calentamiento en 30 segundos
- Apagado automático
- Botones de ajustar temperatura
- Soporte
- Botones de encendido y apagado
- Acabado de acero inoxidable
- Cable giratorio profesional
- Protector térmico

Modelo CD109BP

1 1/2 pulgadas (38 mm)

Modelo CD107TP

1 pulgada (25 mm)

necesita lubricación. Mantenga todas las aberturas libres de polvos y pelusas. Cuando sea necesario limpiarlo, desenchúfelo, permita que entre y limpie la superficie exterior con un paño húmedo. En caso de mal funcionamiento, desconecte el aparato, permita que entre y regrese a un centro de servicio autorizado. No trate de repararlo.

Todos sabemos que no se debe mezclar la electricidad y el agua. Pero ¿Sabe usted que un aparato eléctrico permanece bajo tensión aunque esté apagado? Si está conectado, hay corriente. Por lo tanto, siempre desenchufe los aparatos eléctricos después de usarlos.

Constar reparatura o reemplazamiento (a su opción) su aparato sin cargo por un periodo de 60 meses a partir de la fecha de compra si presenta defectos de materiales o fabricación.

Para obtener servicio técnico bajo esta garantía, regístrese sin cargo al Centro de Servicio Indicado al dorso, junto con su recibo de compra y un cheque o giro postal de US\$5.00 por gastos de manejo y envío. Los residentes de California sólo necesitan dar una prueba de compra y deben llamar al 1-800-3-COMPRA para recibir

COMARCA NO SERÁ RESPONSABLE, EN NINGÚN CASO, POR NINGÚN DAÑO ESPECIAL, INCIDENTAL O CONSECUENTE DEBIDO AL INCUMPLIMIENTO DE ESTA O CUALQUIER OTRA GARANTÍA, EXPRESA O IMPLÍCITA. Algunos Estados no permiten la exclusión o limitación de datos especiales, incidentales o consecuentes de modo que las limitaciones

específicos y usted puede tener otros derechos

Este aparato ofrece 5 opciones de temperatura,

Alto/Max (360 °F–400 °F)	Cabello resistente
Medio-Alto (330 °F)	Cabello grueso u ondulado
Medio (310 °F)	Cabello normal, espeso o tratado
Encendido/Bajo (285 °F)	Cabello delicado, fino o débil
TIPO DE CABELLO	
AJUSTES DE TEMPERATURA	

de caballo entre la pinta y el tupo. Enrolle el caballo alrededor del tubo, hacia el curoo cabelludo. Presione la manija para aflojar el caballo. Repita el proceso con cada sección de caballo. Según la textura del caballo, puede que sea necesario repetir el proceso varias veces en cada sección.

Será necesario experimentar un poco al principio. Con práctica, encontrará la manera perfecta para rizar su cabello fácil y rápidamente.

**LEA TODAS LAS
INSTRUCCIONES
ANTES DE USARLO
MANTÉNGALO
ALEJADO DEL AGUA**

heridas:

1. Siempre desconecte el aparato inmediatamente-

(spray) o donde se esté administrando oxígeno.
10. ste aparato se vuelve muy caliente.
Mantenga los ojos y la piel alejados de las
superficies calientes.
11. No coloque el aparato en ninguna
superficie mientras esté caliente o conecta-
do.
12. Nunca bloquee las aberturas de aire ni
coloque el aparato en una superficie blanda,
como una cama o un sofá, donde se puedan

obstruir. Mantenga las aberturas libres de pelusas, cabellos y elementos similares.

aire se vuelve muy caliente durante el uso. No lo

GUARDE ESTAS INSTRUCCIONES

FUNDAMENTOS DEL RIZADO

ADVERTENCIA: El tubo se volverá extremadamente caliente en segundos. Evite todo contacto con la piel después de encender el aparato.

tenacillas con revestimiento de nano cerámica/turmalina

Para su seguridad y para disfrutar plenamente de este producto, siempre lea las instrucciones cuidadosamente antes de usarlo.

www.conair.com/registration

www.conair.com/infinite

11PA119473

IB-10538A

Modelos CD107TP y CD109BP