



VeriFire™

Medium Systems

Document 51249
11/09/2000 Rev:
ECN 00-478

A





VeriFire™

Medium Systems

Overview

VeriFire™ Medium Systems software lets you upload or download programs between a PC and the following devices: AFP-100, AFP-200, AFP-300, AFP-400, AFC-600, and UZC-256.

Note: VeriFire™ is not intended for permanent connection to the fire control system.

This document contains instructions for installing VeriFire software and running the program's help files. The help files contain instructions for connecting a PC to the fire control device.

Minimum System Requirements

- Windows® 95, 98 or NT
- PC with a 200 MHz MMX processor and 32MB RAM (minimum)
- 256 color monitor (VGA or better)
- CD-Rom drive

VeriFire™ is a trademark of NOTIFIER Fire Systems.
Windows® is a registered trademark of Microsoft Corporation.





Installing the Software

1. Insert the *VeriFire* CD into your PC's CD-Rom drive.
2. From the Windows® Explorer, view the contents of the CD-Rom.
3. Read any *readme* files on the program disk.
4. Open the folder for the upload/download utility to be installed:

AFP100—*VeriFire* 100 for the AFP-100

AFP200—*VeriFire* 200 for the AFP-200

AFP400—*VeriFire* 400 for the AFP-400

AFC600—*VeriFire* 600 for the AFC-600

UZC256—PK UZC-256 for the UZC-256

Note: The directory named "CR" is for internal use only.

5. In the selected folder, double-click on *setup.exe* and follow the on-screen instructions.

Running the Program

From the Windows *Start* menu, select *Programs* and click on the appropriate icon.

Once running the program, press *F1* on your keyboard to access on-line help for details on operating the software.

51249:A 11/09/2000





World Headquarters
12 Clintonville Road, Northford, CT 6472-1653 USA
203-484-7161 • Fax 203-484-7118
www.notifier.com

