




DISPLAYS2GO
CONNECTING PEOPLE & BRANDS WITH THE WORLD



OUTDOOR SIDEWALK SIGN WITH WATER-FILLED BASE

User Manual

SKUs: PS1536BLK, PS1528BLK, PS1540BLK



PARTS LIST






Scan QR code
to visit product
page



PART

QUANTITY

A: Water-Fill Base.....	1
B: Poster Frame.....	1
C: Wingnut Screw.....	2




1. Insert signage frame
into base.


2. Flip unit onto its side,
then insert wingnut
screw with washer and
nut through the holes on
the bottom of the base.

If you have any questions regarding our products, please visit us at www.displays2go.com or
contact Displays2go customer service at 844-221-3388.





3. Snap frame open and remove the poster cover from the frame.




4. Insert desired poster into frame, then replace the poster cover. Snap the frame closed.



5. Move unit to desired location, then fill base with either water or sand.

NOTE: Empty base before storing or moving again.



Enjoy your new sidewalk sign!

CONTACT INFORMATION:
www.displays2go.com
 PHONE: 844-221-3388

