




GEbruikSAANWIJZING

PROFESSIONELE MAGNETISCHE RUITENREINIGER


OVER

Bedankt voor het kiezen voor ons Cleanly product! Lees voor gebruik de handleiding aandachtig door, voor een correcte en veilige werking van het product. Volg altijd deze instructies voor veilig gebruik. Als u vragen heeft over het product of problemen ondervindt, kunt u contact met ons opnemen via e-mail: hello@shopkeepr.nl

VERPAKKINGSINHOUD


10x Grote reinigingspads	4x Wissers
20x Kleine reinigingspads	1x Veiligheidskoord
30x Bevestigingsbuttons	1x Opbergbeugel

STAP 01




Scheidt de 2 ruitenreinigers van elkaar. LET OP! Houdt de 2 delen niet te dicht bij elkaar. Verwijder de opbergbeugel die voorkomt dat er handen bekneld raken tussen de 2 magneten. (Verlies deze niet!)

STAP 02



Voeg wasmiddel toe in een bak met water en laat de reinigingspads van beide ruitenreinigers dit absorberen.




STAP 03

Bindt het veiligheidskoord om je pols.

STAP 06

Als je merkt dat de magneet te zwak is, kan je de verstelknop een positie hoger instellen. Als de magneet te sterk is voor de dikte van het raam, is het noodzakelijk om beide magneten te scheiden om terug te gaan naar een lagere positie. (Zie stap 07).

STAP 04




Breng de 2 ruitenreinigers binnen en buiten aan op het raam en breng deze horizontaal naar elkaar toe tot ze op elkaar zitten.

TIP


Houdt tijdens het reinigingsproces de ruitenreiniger in een hoek van 30 graden gedraaid, zodat de wissers hoger zitten dan de reinigingspads. Dit zorgt ervoor dat de ruitenreiniger al het residu met zich meeneemt.

STAP 05




Als beide delen op elkaar zitten, kan de juiste magneetsterkte ingesteld worden voor de dikte van het raam.

STAP 07



Zet de magneetsterkte terug op positie 1 door het gedeelte met de verstelknop één kant op te bewegen zoals de linker afbeelding laat zien. Plaats hierna de opbergbeugel terug.



USER MANUAL

PROFESSIONAL MAGNETIC WINDOW CLEANER


ABOUT

Thank you for choosing our Cleanly product! To ensure proper and safe functioning of the product, please read the manual carefully before use. Please always follow these instructions for safe usage. If you have any questions about the product or experience any problems, Please contact us by email: hello@shopkeeper.nl

PACKAGE CONTENTS


10x Big cleaning pads	4x Squeegees
20x Small cleaning pads	1x Safety rope
30x Buttons	1x Storage bracket

STEP 01




Separate the window washers. Pay attention! Do not place the 2 parts too close to each other. Remove the storage bracket that prevents hands from getting caught between the 2 magnets.

STEP 02



Add detergent to a container of water and let both cleaning pads of the window cleaner absorb it.




STEP 03

Tie the safety rope around your wrist.

STEP 06

If you notice that the magnet is too weak, you can turn the adjustment knob one position higher. If you notice that the magnet is too strong, separate both magnets to return to position 1. (See step 07).




STEP 04

Apply the window cleaners inside and outside to the window and bring them together horizontally.

TIP


Keep the window cleaner turned at an angle of 30 degrees during the cleaning process, so that the wipers are higher than the cleaning pads. This way, no residue is left behind.



STEP 05

When both window cleaners are on top of each other, you can adjust the adjustment knob for the right magnetic force for the window thickness.

STEP 07



Return the adjustment knob to position 1 by shaking as shown in the left picture. Then replace the storage bracket.