


RGB LED STRIP LIGHTS

Remote Control


1. Power On and Off
2. Quick/Slow Flash Setting
3. Brightness adjustment (25%, 50%, 75%, Full)
4. Automated or Flash Setting
5. 4 Sound-Syncing Modes
6. Fade Effects (3-Color Fade or 7-Color Fade)
7. Timer Settings (1 hour, 2 hours, 3 hours, 4 hours)
8. Jump Light Effects (3-Color Jump, 7-Color Jump)
9. RGBW color settings with 16 additional color selections
10. Adjust the color saturation

Remote Control Battery

Note: The remote control comes with 3V battery installed.
If you need to replace the battery (CR2025 3V battery) compartment is located on the narrow side of the remote.




IMPORTANT:
Be sure to line-up the arrows on both ends of the 4 pin connector (male to female), otherwise the lights will not work



Installation

1. Be sure to clean the surface you intend to install the strip lights on.
2. Peel off the adhesive backing, making sure to not remove the actual adhesive.
3. Press and firmly hold the light strip in place for 30 seconds.
4. Connect strip lights to IR controller and connect receiver to a power source.
5. Remove the tab from the battery compartment of the remote control.

Notes: Not all surfaces have the same textures, and some surfaces may require additional support to hold up the strip lights.



RGB Strip Light

NEED HELP? EMAIL US:

support@merkuryinnovations.com

Technical Support:

If you are experiencing problems, do not attempt to fix the product yourself or return it to the store you purchased it from. Please refer to the user manual or just contact our helpful tech support team:

