


廠商(Supplier)	Pusher	顏色(Colors)	Front 1 color	日期(Date)	2021.3.9
代號(Item No.)	KT2-CLUBKITQI_A02810	特別色(Pantone)		版本(Version)	S1
品名(Description)	Instruction sheets	4色(CMYK)	K	製稿(DRN)	momo
材質(Material)	Wood Free Paper	 K100		審校(CHD)	
尺寸(Size)	375x260mm(B4)			業務(Sales)	


BOSTITCH


Wireless charging station with pencil cup

Congratulations on the purchase of your Bostitch® product!

Please read these instructions completely and carefully before using this product. Keep this instruction sheet for future reference.



To register your product visit [BostitchOffice.com/New-Product](https://www.bostitchoffice.com/new-product)

Do not return this product to the original place of purchase. For product support visit [www.BostitchOffice.com/support](https://www.bostitchoffice.com/support).

SAFETY GUIDELINES - DEFINITIONS

It is important for you to read and understand this manual. The information it contains relates to protecting YOUR SAFETY and PREVENTING PROBLEMS. The symbols below are used to help you recognize this information.

 **WARNING:** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury and/or property damage.

 **CAUTION:** Indicates an potentially hazardous situation, which if not avoided, may result in minor or moderate injury and/or property damage.

TO REDUCE THE RISK OF INJURY
Before any use, be sure everyone using this product reads and understands all safety instructions and other information contained in this manual.

- ### SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE

 **WARNING:**

 - Electric shock hazard. Do not open!
 - Outlets are not intended to be repaired by service personal in case of failure or component defect
 - The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquid shall be placed on the apparatus
 - RISK OF ELECTRIC SHOCK DRY LOCATION USE ONLY.

 **CAUTION:**

 - Read all instructions before assembly. Failure to assemble properly may result in damage or personal injury
 - When moving, remove all objects to avoid harm or damage
 - Do not expose electrical components to liquids or excessive heat
 - Do not attempt to repair or replace any part of this item on your own
 - Do not use any damaged or corroded charging cords
 - Plug and unplug all cables and adapters slowly and carefully
 - Keep out of reach from children
 - Risk of Electric Shock. Do not plug into another relocatable power tap or an extension cord
 - Maximum environment temperature is 25°C
 - The outlet maximum is 15A/less than 1800W
 - Do not modify or repair this device
 - Remove the credit cards and other cards with magnetic strips to prevent damage to them

NOTICE: Ensure that you have received all parts according to the component checklist prior to installment. If any parts are missing or faulty, contact our customer service team for a replacement at 1-800-343-9329.

FCC STATEMENT

This device complies with Part 15 of the FCC rules. Operation is subject to thefollowing two conditions: 1) this device may not cause harmful interference, and 2)this device must accept any interference received, including interference that maycause undesired operation.Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Radiation Exposure Statement


This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.


CORRECT DISPOSAL OF PRODUCT


This marking indicates that this product should not be disposed with other household wastes to prevent possible harm to the environment or human health from uncontrolled waste disposal. Recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please contact the retailer where the product was purchased.

COMPONENTS AND PRODUCT FEATURES




C


D


E

	Input	Output
Power Hub	120V, 50/60Hz	15A, 1800W (Max Output)
Wireless Charging Base	DC 5V/9V	5W - 10W

INSTRUCTIONS FOR USE

1. Plug the provided cord into the micro USB power input on the base unit.
2. Connect the micro USB cord into a USB power source (wall adapter not included).
3. Plug the Power Hub cord into a wall outlet.
4. Your device is now powered and ready to use.
5. Stack the power hub, pencil cup, and storage tray onto the base as desired or use individually.
6. Wirelessly charge your phone by placing it on the stand upright.
NOTE: Charge time varies by phone type and power adapter. For a faster charge, a Quick Charge™ 3.0 adapter (not included) is recommended.

INDICATOR LIGHT

Blue Light	Power On/Standby
Red Light	Charging
Blue Light	Fully Charged
Alternating Blue/Red	Problem Detected • Foreign object detected • Phone is not compatible with wireless charging • Wireless charging base is defective

TROUBLESHOOTING

- If you are experiencing issues with the wireless charger on your organizer, please review the following:
- Ensure that the USB cord is securely connected to the organizer and plugged into a compatible power source
 - If you have a case on your phone, remove it and see if the charging works. Certain case styles can interfere with the wireless charging and can't be used.
 - Check the placement of your phone and ensure that it is in the center of the charging pad.
 - Ensure that your device is Qi-enabled for wireless charging.

THREE-YEAR LIMITED WARRANTY

Effective January 1, 2021 Goods iQ warrants to the original retail purchaser that the product purchased is free from defects in material and workmanship, and agrees to repair or replace, at Goods iQ's option, any defective Bostitch® Konnect™ branded product three (3) years from the date of purchase. Warranty is not transferable. Proof of purchase date required. This warranty covers only damage resulting from defects in material or workmanship; it does not cover conditions or malfunctions resulting from normal wear, neglect, abuse, accident, or repairs attempted or made by other than our national repair center or authorized warranty service centers. You are responsible for the costs of shipping the defective product to Goods iQ

THIS WARRANTY IS THE EXCLUSIVE WARRANTY OF GOODS IQ, AND IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURCHASE. GOODS IQ SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

Some states and countries do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state and country to country. For information on our warranty claim procedure, please contact us at 1-800-343-9329.

For troubleshooting, questions and customer care, please visit us at [BostitchOffice.com](https://www.bostitchoffice.com) or contact us at 1-800-343-9329.

Bostitch® and the Bostitch® logo are registered trademarks of Stanley, Black & Decker Inc. or one of its affiliates, and used under license.

USA & Canada:
Manufactured under license by: Goods iQ
North Kingstown, RI 02852
800.343.9329
Made in China
Contiene 5 piezas
Copyright © 2021 Goods iQ

