




PXN Sense Elf S2




True Wireless Gaming Earbuds

使用说明书 | User Manual

Overview & Package Contents

Package contents includes PXN Sense Elf S2 Earbuds, 3 sizes of earbuds tips (M size tips are installed in the earbuds), USB-C cable and user manual.



Auto Power ON & OFF

- Open the charging case and the earbuds will power ON automatically.
- Put the earbuds back to the charging case and close the case, the earbuds will power OFF and enter the charging state.
- If no connection to any smart device for more than 3 seconds after removing the earbuds from the charging case, the earbuds will power OFF automatically.

Manual Power ON & OFF

- Under power OFF state, long press the touch sensor area on the L & R earbuds simultaneously for 3 seconds to power ON. (Voice guidance: Power ON.)
- Under power OFF state, long press the touch sensor area on the L & R earbuds simultaneously for 5 seconds to power ON. (Voice guidance: Power OFF.)

Connect Smart Device in Dual Earbud Mode

- For the first use, the earbuds indicator will keep on White for 2 seconds after removing from the charging case. (Voice guidance: Power ON.) L & R earbuds will pair automatically. (Voice guidance: Beep.) After successful pairing, the White and Blue indicator will flash alternately and enter the Bluetooth Search state. (Voice guidance: Pairing.) Now can connect with the smart device.
- Open the Bluetooth on the smart device and search "PXN Sense Elf S2" to pair. The earbuds will be paired with the smart device successfully. (Voice guidance: Connected.)

Connect Smart Device in Mono Earbud Mode

- Remove the L / R earbuds from the charging case and pair it according to the above dual earbud mode to complete the connection.

Auto-Reconnection

- Open the charging case, and the earbuds will automatically connect back to the last successfully connected smart device.
- The earbuds will be disconnected with the smart device when they are beyond the effective distance. (Voice guidance: Disconnected.) Return to the effective distance within 3 minutes, the earbuds and smart device will reconnect automatically.

TWS Pairing Connection of L & R Earbuds

When the earbuds leave the factory, the L & R earbuds have successfully completed TWS pairing under normal conditions, and the earbuds can be used normally after connecting with the smart device.

If you need to re-pair under special circumstances, please follow these steps:

- Double click the earbuds simultaneously when L & R earbuds enter to the search state. The White indicator on the earbuds will enter the breathing flash state and start to pair.
- The indicator on the earbuds will flash in White and Blue alternately after successful pairing. (Voice guidance: Beep.) Now can connect with the smart device.

Indicator State

Earbuds Mode	Play Mode	Game Mode	Music Mode	Standby Mode	Incoming call Mode
Indicator State	Blue/White light Breathing cycle flashing	Blue light flashes	White light flashes	Blue/White light flashes 4s/time(under Game mode/Music mode)	White light flashes quickly

Function Touch Operation Instruction Gesture

Play/Pause ▶/	Click 2 times (L/R)	Double-click L/R
Volume 🔊	Click 1 time (L-/R+)	Single-click L-/R+
Previous song ◀◀	Hold press for 2s (L)	Hold press for 2s (L)
Next song ▶▶	Hold press for 2s (R)	Hold press for 2s (R)

Answer a call	Click 2 times (L/R)	Double-click L/R
End call	Two-way voice	

Reject call	Hold press for 2s (L/R)	Hold press for 2s
-------------	-------------------------	-------------------

Game mode	Click 3 times (R) (Voice guidance: Game Mode)	Click 3 times (R)
-----------	---	-------------------

Music mode	Click 3 times (R) (Voice guidance: Music Mode)	
------------	--	--

Activate voice assistant ON/OFF	Click 3 times (L)	Click 3 times (L)
---------------------------------	-------------------	-------------------

Earbuds RGB mode ON/OFF	Click 4 times (L/R)	Click 4 times (L/R)
-------------------------	---------------------	---------------------

Charging

When using the charging case for charging at the first time, please put the earbuds back into the charging case and close the cover. Use the data cable included with this product to connect to the power supply for charging.

Earbuds Charging	Put the earbuds into the charging case and close the cover for charging	When the earbuds are charging, the white indicator on the earbuds will remain on for 3 seconds and then the indicator will be off gradually. After fully charged, the corresponding RGB White light will remain ON for 3 second and then OFF.
Charging Case Charging	Use the USB-C cable included for charging	During charging, L/R indicator is red breathing flashing. When fully charged, L/R indicator will remain Green for 1 minute and then OFF

Restore Factory Settings (Operate with Caution)

Restoring the factory settings will clear all pairing information of the earbuds.

- Under Power OFF state, long press the touch sensor area for 10 seconds until the earbuds will remain ON for 2 seconds and power OFF.
- Please follow the steps in "TWS Pairing Connection of L & R Earbuds" to complete the TWS pairing and the connection of smart devices again.

Q: No sound can be heard through the earbuds?

- A :
- a. Make sure the earbuds are under working state.
 - b. Confirm whether the volume of the earbuds is appropriate.
 - c. Check if the earbuds are connected successfully with the phone.
 - d. Make sure the earbuds are in the normal working range.
 - e. Confirm whether there is foreign matter blocking at the position of earbuds horn net.

Q: Bad signal in call when using the earbuds?
A: a. Confirm whether the smart device is in the area with strong signal.
b. The effective distance of the earbuds is 10m, please make sure that the earbuds are within the effective distance and there is no obstacle between the earbuds and the smart device.

Q: Unable to pause, resume, previous song and next song control when using the earbuds to play music?
A : This function requires that the device paired with the earbuds supports the AVRCP protocol. (Audio/Video Remote Control Profile.)

Product Specification

Product Name	PXN Sense Elf S2
Connection	Wireless connection
Input	DC 5V = 1A
Frequency Response	20HZ - 20KHZ
Maximum Wireless Range	10 m (Barrier-free)
Battery Life	About 5 hours
Charging Method	About 1.5 hours (earbuds charging) About 2 hours (charging case + USB-C cable charging)
Product Size	About 61.5 * 61.4 * 32 mm (charging case)

Attention

- Avoid placing in humid, high temperature or soot place.
- Prevent water or other liquids from entering the inside of the earbuds.
- Avoid using the earbuds at a high volume for a long time. If tinnitus or earache occurs, please stop using.
- If you have any problems or suggestions about the product, please contact the seller or the after-services.
- **Warning:** The rechargeable battery of this product must be disposed of properly for recycling, please do not put the battery into the fire to avoid cause an explosion.
- **Advise:** If not use the earbuds for a long time, please store it in a dry place. The earbuds need to be charged at least once a month to extend the battery life.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please read the manual carefully before using, and keep this manual for future reference

PXN Sense Elf S2