






COMPONENT CHECKLIST




A
Shelf
(x1)



B
Shelf Clamp
(x1)



C
Shelf Connectors
(x2)



D
Shelf Lip
(x1)

Floor

REQUIRED TOOLS

- Phillips Head Screwdriver

CAPACITY

0 - 11kg (0 - 24lb)


IMPORTANT INFORMATION

- ! Please ensure this product is installed as per these installation instructions.
- ! The manufacturer accepts no responsibility for incorrect installation.
- ! Failure to mount this product correctly may cause serious injury/death during or following installation.
- ! Do not over tighten screws.
- ! Product not suitable for use outdoors.
- ! After installation is complete, check to verify that Shelf is secure and safe for use.
- ! **WARNING!** Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control or toys placed on the cart may encourage a child to climb on the cart and as a result the cart may tip over on to the child.




1. Install shelf


1.1 Remove screws (x4) from Shelf clamp **B**.




1.2 Attach Shelf Connectors **C** to inner column of AD-TVC-75.




1.3 Insert Shelf Clamp **B** into Shelf Connectors **C**.




1.4 Re-fasten screws through Shelf **A**.



1.5 Slide Shelf lip **D** on the Shelf **A**.




1.6 Rotate the Shelf lip **D** by 90° on Shelf **A** until it clips in.



ADJUSTMENTS

Height Adjustment

To set the height of the shelf, loosen the screws slide shelf to preferred height and re-tighten the screws.



MAINTENANCE

- Tighten fasteners and check the shelf is secure and safe to use at regular intervals (at least every three months.)
- Please contact your distributor if you have any questions.