

INSTRUCTIONS

LED DISCO LIGHT SWAGGER

PACKAGE CONTENTS

- Disco light
- Remote
- Mounting attachment
- 2 plastic screws
- USB charging cable
- Instructions

TECHNICAL SPECIFICATIONS

- Battery: 2000 mAh
- Remote power supply: CR2025 3V battery
- Projection distance: 5–15 m
- Weight: 400 g
- Dimensions: 75 × 73 × 96 mm
- Housing material: plastic



HOW TO USE

- Use the two included plastic screws to screw the mounting attachment onto the disco light. You can use the attachment as a stand or to install the light on the ceiling.
- Adjust the projection angle of your light and tighten the screws to secure it.
- Use the power switch button on the back side of the device to turn it on.
- You can use the mode button on the front side of the device to cycle through different modes or use the included remote to control the light.
- Remove the plastic battery stopper from the remote to use it.
- To charge the device, connect the included USB cable to the plug positioned on the back side of the device.



1. ON/OFF button
2. Motor stop
3. Strobe mode
4. 3 automatic modes
5. 3 sound activation modes
6. Red and green laser
7. Red laser
8. Green laser
9. LED-light automatic mode
10. LED-light color selection
11. Timing function (choose the working time of the disco light – 1, 3, 6, or 8 hours)

WARNINGS

- Always turn off and disconnect the light when not in use.
- Do not submerge the device into the water.
- Do not intentionally shine into the eyes or face.
- Do not disassemble or modify in any way.
- Keep away from children and pets.
- Before each use, check if the light has any visible damage or defects. Do not use it if damaged!

WARRANTY

The warranty is valid for 24 months. You can claim it from DFVU d.o.o., Liparjeva 6a, 1234 Mengeš, Slovenia, for a replacement product or a refund. Send us your order number and purchase date in the email, which is available by clicking on our logo in the bottom right corner. The product has a lifetime of 24 months from the date of collection.



	WEEE disposal and recycling symbol. The WEEE symbol is attached to the product in compliance with the EU directive <i>2012/19/EU</i> on Waste Electrical and Electronic Equipment (WEEE). It is intended to deter the improper disposal of this product and to promote reuse and recycling.
---	--