


# ***KNEADING*** ***MASSAGER***

DEEP - KNEADING RELIEF FOR HARD-TO-REACH MUSCLES



**Operation Instructions**  
Read instructions before using



# SPECIFICATIONS

|                     |         |
|---------------------|---------|
| Rated Voltage ..... | DC 12V  |
| Frequency .....     | 50-60Hz |
| Power .....         | 30W     |

# TABLE OF CONTENTS

|                                     |   |
|-------------------------------------|---|
| Important Safety Instructions ..... | 2 |
| Warning and Caution .....           | 3 |
| Product Introduction .....          | 5 |
| Using Instructions .....            | 6 |
| Product Care and Maintenance.....   | 7 |
| Warranty.....                       | 8 |
| Customer Service.....               | 8 |



## IMPORTANT SAFETY INSTRUCTIONS

All the safety and operating instructions should be read, adhered to and followed before the unit is operated.

When using an electrical appliance, basic precautions should always be followed, including the following.

### **DANGER**

To reduce the risk of electric shock, burns, fire or injury:

1. Always unplug this appliance from the electrical outlet immediately after using and before cleaning.
2. Do not reach for an appliance that is plugged in and has fallen into water. Unplug immediately from the outlet.
3. Do not use while bathing or in a shower.
4. Do not place or store product where it may fall or be pulled into a tub or sink.
5. Never submerge the unit in any liquid.
6. Never use pins or other metallic fasteners with this appliance.
7. Carefully examine the covering before each use. Discard the appliance if the covering shows any signs of deterioration, such as cracking.
8. Keep dry. Do not operate in a wet or moist environment.



## WARNING

1. An appliance should never be left unattended when plugged in. Unplug from the outlet when not in use, and before putting on or taking off parts.
2. Close supervision is necessary when this appliance is used by, on or near children, invalids, or disabled persons.
3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
4. Never operate this appliance if it has a damaged cord or plug. If it is not working properly, if it has been dropped or damaged, or dropped into water, DO NOT attempt to fix it yourself. Return the appliance to a service center for examination and repair.
5. Do not carry this appliance by its supply cord or use the cord as a handle.
6. Do not crush or fold this appliance when storing.
7. Keep the cord away from heated surfaces.
8. Never drop or insert any object into any opening.
9. Do not use outdoors. This appliance is intended for household and indoor use only.
10. To disconnect, set all controls to the off position, then remove plug from the outlet.
11. Do not overload the electrical outlet. Use only the power source as indicated.



12. To avoid the risk of electric shock, do not disassemble or attempt to repair the appliance. The incorrect repair can cause a risk of electric shock or injury to persons when the unit is being used.
13. Never remove the plug from the outlet by pulling the power cord.
14. Do not use the product on head as a head massager.
15. Do not use 3D Massager MORE THAN 20 MINUTES.

## CAUTION

- This product is not intended for medical use, nor shall it be used as a substitute for medical attention. It is intended only to provide a luxurious massage.
- Any individual who may be pregnant, has a pacemaker, suffers from phlebitis and/or thrombosis, is at an increased risk of developing blood clots, or who has pins/screws/artificial joints or other medical devices implanted in his/her body should consult with a physician before using a massaging device designed for home use.
- Do not use on infant.
- To reduce the risk of electric shock, do not remove the cover. There are no serviceable parts inside.
- To reduce the risk of fire or electric shock, do not expose this unit to rain or moisture.






- Do not use the unit directly on swollen, sensitive, inflamed or eczema skin areas.
- If HEAT is too strong for your comfort, please switch the heat off.

## PRODUCT INTRODUCTION

### LOCATION OF PARTS AND CONTROLS

1. Main Unit
2. Shiatsu Nodes
3. Control Panel
4. Power on/off
5. Massage direction
6. Speed Control
7. Heat on/off
8. Adapter
9. Car Power Plug



## USING INSTRUCTIONS

1. For INDOOR use, connect the power adaptor to the massager.  
Plug the adaptor into an outlet. (sit comfortably in a chair and use the massager).
2. For IN-CAR **use**, connect the car power plug to the massager.  
Plug the car power plug into the cigarette lighter in the car. (do not use while driving).
3. Grip the POSITIONING HANDLES and drape the MAIN UNIT around your neck with the MESSAGE NODES in the center of your back.
4. Press the POWER button to turn on/off massage.
5. Press the HEAT button to turn on/off heat.
6. Press the DIRECTION button to change the rotating direction of message nodes, clockwise or counterclockwise.
7. Press speed control to change the speed.

### NOTE:

- The massager will automatically shut off after 15 minutes operation.
- The massage direction changes automatically every minute.







Shiatsu kneading  
massager with heat




Deep tissue massager  
with 8 kneading rollers




Bi-Directional massage



Usable on multiple  
areas of the body



Portable adapters for  
easy traveling



Automatic shutdown  
after 15 minutes

## PRODUCT CARE AND MAINTENANCE

1. Place the massager in a safe, cool and dry place when not in use.
2. After unplugging, wipe with a soft, damp cloth using non-abrasive cleaners.
3. Keep away from all solvents and harsh detergents.
4. DO NOT attempt to repair this massager. There are no user-serviceable parts.



## WARRANTY

We grant 1 year warranty on the product commencing on the date of purchase. Within the guarantee period we will eliminate any defects in the appliance resulting from faults in materials or workmanship, please contact us at: [support@medcursor.com](mailto:support@medcursor.com)

This guarantee does not cover: damage due to improper use, normal wear or use as well as defects that have a negligible effect on the value or operation of the appliance. The guarantee becomes void if repairs are undertaken by unauthorized persons and if original product parts are not used.

## CUSTOMER SERVICE

1. If you have any product questions or concerns, please don't hesitate to contact us directly at: [support@medcursor.com](mailto:support@medcursor.com)
2. We have a hassle-free warranty and customer service team for satisfactory solutions to any issue you might have.







MEDCURSOR



Scan to Follow Us



@Medcursor  
[www.medcursor.com](http://www.medcursor.com)

Ver.220324

