

The wireless headset is made of plastics, metals, and a lithium-ion battery. Follow local regulations when disposing of the wireless headset. Sony products can be recycled for free in the United States and Canada by dropping the product off at a number of nationwide locations. For details, visit www.sony.com/ecotrader.

Input power rating	Wireless headset: 5V = 650 mA Wireless adaptor: 5V = 100 mA
Battery type	Built-in lithium-ion rechargeable battery
Battery voltage	3.65 V
Battery capacity	1000 mAh
Operating environment temperature	5 °C to 35 °C (41 °F to 95 °F)
Dimensions (w/h/d)	Wireless headset: 213 × 190 × 91 mm (8.4 × 7.5 × 3.6 in) Wireless adaptor: 48 × 18 × 8 mm (1.9 × 0.7 × 0.3 in)
Weight	Wireless headset: 292 g (10.3 oz) Wireless adaptor: 6 g (0.2 oz)
Communication system	2.4 GHz RF
Maximum communication range	Approx. 10 m (33 ft)*1
Use time when fully charged	Up to 12 hours at mid volume level*2
Contents	Wireless headset (1) Wireless adaptor (1) Audio cable 1.2 m (3.9 ft) (1) USB cable 1.5 m (4.9 ft) (1) Quick Start Guide (1) Safety and Support Guide (1)


*2 Actual use time varies depending on factors such as the battery charge and ambient temperature.

LIMITED WARRANTY

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES AND NO OTHER REPRESENTATIONS OR CLAIMS OF ANY NATURE SHALL BE BINDING ON OR OBLIGATE SIE LLC. ANY IMPLIED WARRANTIES APPLICABLE TO THIS PRODUCT, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE ONE (1) YEAR PERIOD DESCRIBED ABOVE. IN NO EVENT WILL SIE LLC BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM POSSESSION, USE OR MALFUNCTION OF THE SIE LLC PRODUCT. SOME STATES OR PROVINCES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS AND SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATIONS OF CONSEQUENTIAL OR INCIDENTAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSION MAY NOT APPLY TO YOU.

This warranty is valid only in the United States and Canada.

For more information or assistance with your wireless headset, visit playstation.com/help.



Precautions

Safety/Use and Handling

- Observe all warnings, precautions and instructions.
- **CHOKING HAZARD** - Small parts. Keep out of the reach of small children.
- Keep the product out of the reach of small children. Small children may swallow small parts, may pull on cables and cause the headset to fall, or may wrap the cables around themselves, which may inflict injury or cause an accident or a malfunction.
- Do not use the headset while cycling, driving or engaged in any other activity where your full attention is required. Doing so may result in an accident.
- This product has magnets which may interfere with pacemakers, defibrillators and programmable shunt valves or other medical devices. Do not place this product close to such medical devices or persons who use such medical devices. Consult your doctor before using this product if you use such medical devices.
- Stop using the wireless headset immediately if you begin to feel tired or if you experience discomfort or pain in your head while operating the wireless headset. If the condition persists, consult a doctor.
- Avoid prolonged use of the wireless headset. Take a break at about 30-minute intervals.
- Permanent hearing loss may occur if the headset is used at high volume. Set the volume to a safe level. Over time, increasingly loud audio may start to sound normal but can actually be damaging your hearing. If you experience ringing in your ears or muffled speech, stop listening, and have your hearing checked. The louder the volume, the sooner your hearing could be affected. To protect your hearing:
 - Limit the amount of time you use the headset at high volume.
 - Avoid raising the volume to block out noisy surroundings.
 - Lower the volume if you can't hear people speaking near you.
- If you feel that the headset is irritating your skin, stop using it immediately.
- The battery used in this device may present a risk of fire or chemical burn if mistreated. Do not disassemble, heat above 60 °C (140 °F), or incinerate.
- Do not handle damaged or leaking lithium-ion batteries.

- ## FCC and ISED Canada Notice

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For assistance with this product, visit playstation.com/help. The phone number in the supplier's declaration of conformity is only for FCC electrical interference inquiries.

Supplier's Declaration of Conformity

This device complies with Part 15 of the FCC Rules and Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ICES-003.

The rating label contains specific model, manufacture, and compliance information. It is located under the right earpad.

To remove the earpad and access the rating label:

- 1 Use one hand to hold the headset in place.
- 2 With your other hand, grip the earpad frame.
- 3 Pull the earpad out.

To replace the earpad, align the earpad with the inner frame. Push it back onto the frame until it clicks.

