



User Manual

Bluetooth® PORT SPEAKER FLOATY 42925545

This is a swimming pool Bluetooth® speaker, can use in the swimming pool and bathtub!

Package included:

Inflatable pool floats X1
Speaker X 1
Inflator pump X 1
USB charging cable X 1

Product Overview



Connect your phone:

Long press the on/off button in 3 seconds and the speaker will turn on, open your mobile device and open the Bluetooth® control interface and then turn on the Bluetooth®.

Search the Bluetooth® name "KM42925545", and connect it, the speaker will have voice indicating connected successfully .

Charging the Integrated Battery:

This product is powered by an integrated rechargeable lithium battery, a USB charging cable is included. Charge the battery as follows:

1. Insert the charging cable into the USB socket on the unit.
2. Connect the USB plug into a PC USB Port or USB adaptor 5V d.c.
3. The red LED indicator is on, the battery is being charge, charging will take approximately 2 hours.
4. When the battery is fully charged the LED indicator light will go out, remove charging cable.
5. After charging, secure the charging cover before use in water.



**** Do not expose the speaker to water while charging**

Caution

- No naked flame sources such as lighted candles should be placed on the apparatus
- Attention should be drawn to the environmental aspects of battery disposal
- The use of apparatus in moderate climates
- Battery shall not be exposed to excessive heat such as sunshine, fire or the like.
- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- Do not immerse the speaker into water.
- Close all cover before use.
- **Warning: This item is not a flotation device. Adult supervision is required when using.**

Product Specifications:

Bluetooth®: V5.0

Lithium battery: 300mAh

Playtime: 2-3 hours

Charging time: About 2 hours

DC input: DC 5V 1A

Bluetooth® Distance: ≤ 10m

IPX7

12Month Warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at Kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation

