




8 × 10 ft. Collapsible
Background

INSTRUCTIONS



Introduction

Thank you for choosing Impact.

Thank you for purchasing the Impact Collapsible Background. Impact Collapsible Backgrounds are portable and set up easily. They come in many colors and sizes. Visit our website at impactstudiolighting.com to see them all.

Collapsing a background so it fits into its storage bag can be tricky, and it will take some practice to get it right. Follow these instructions carefully.

Scan for additional video instructions on folding the background into a smaller size, or visit impactstudiolighting.com/r/8x10fold.



Features

- Practical to use in studio or on location.
- Made from: poly cotton to absorb light and help eliminate reflections.
- Collapsible background is stretched on a self-supporting steel frame so no stand is needed.
- Folds into a compact circle for easy transportation.
- Simply lean your Collapsible Background against a wall or use the handy loop at the top to attach to a tripod or other stand.
- Spot washable, cold water, air dry.
- Large and small carry bags included.

Visit impactstudiolighting.com to see additional sizes and colors.

All images are for illustrative purposes only.

Stands are not included with Impact Collapsible Backgrounds unless purchased as a kit.



Folding Instructions



With the background laying flat, grasp the two corners along the 8 ft. side and lift the two corners up to form a big taco. You can use your body to help brace and support the frame.





Lift the frame and move forward so the far end comes underneath.

Fold one corner under the other corner while stepping forward.





Continue stepping forward, and as the circle forms, bring your hands to the ground.





Resize the background and fit it in the carry bag.

For video instructions to fit the background into the smaller carrybag, visit impactstudiolighting.com/r/8x10fold.



One-Year Limited Warranty

This Impact product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Impact Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Impact along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.impactstudiolighting.com or call Customer Service at 212-594-2353.

Product warranty provided by the Gradus Group.

www.gradusgroup.com

Impact is a registered trademark of the Gradus Group.
© 2021 Gradus Group LLC. All Rights Reserved.

