


C270 HD WEBCAM


Complete Setup Guide
Guide d'installation complet



logitech®




KNOW YOUR PRODUCT




WHAT'S IN THE BOX

- 1 Webcam with 5 ft (1.5 m) attached USB-A cable
- 2 User documentation




SETTING UP THE WEBCAM


- 1 Place your webcam on a computer, laptop or monitor at a position or angle you desire.



- 2 Adjust the webcam to make sure the end on the universal mounting clip is flush with the back of your device.




- 3 Manually adjust the webcam up/down to the best position to frame yourself.




CONNECTING THE WEBCAM VIA USB-A

Plug the USB-A connector into the USB-A port on your computer.



SUCCESSFUL CONNECTION

LED activity light will light up when the webcam is in use by an application.



DIMENSIONS

INCLUDING FIXED MOUNTING CLIP:

Height x Width x Depth:

1.26 in (31.91 mm) x 2.87 in (72.91 mm) x 2.62 in (66.64 mm)

Cable Length: 5 ft (1.5 m)

Weight: 2.65 oz (75 g)

www.logitech.com/support/C270

