


Eumspo
Wireless Headset Model: G3



User Manual

Before using this product, please read the instruction manual carefully to use the earbud correctly and safety.

①



WELCOME

Thank you for choosing G3 wireless Stereo Single Earbud. Please read below instructions carefully before use. It will help you set up and operate this product properly and enjoy the advanced features.

PRODUCT LISTS

Product lists



Eum/ps
Bluetooth Earbuds Model G3
User Manual

Before using the product, please read the instruction manual carefully to avoid the incorrect connection and usage.

User Manual *1



Bluetooth Earbud *1



Charger Case *1



Charging Cable



Earbuds*2 (S/M/L)

*If you find any of above product lists damaged or lost when you received, please contact the seller.

(2)

Product lists



Bluetooth Headphone Model S3

User Manual

Before using this product, please read the instruction manual carefully to use the product correctly and safely.

User Manual *1 Bluetooth Earbud *1 Charger Case *1



Charging Cable



Eartips*2 (S/M/L)

*If you find any of above product lists damaged or lost when you received, please contact the seller.

(2)

Product lists

Product lists

*If you find any of above product lists damaged or lost when you received, please contact the seller.

DETAILED DESCRIPTION

- ① Microphone
- ③ Multi-Function Button
- ⑤ Volume-
- ⑦ Charging Port
- ② Angle Adjustment Part
- ④ Volume+
- ⑥ Charging Display
- ⑧ Rotate Eartip

HOW TO WEAR THE EARPEICE

1. Adjust the angle of the earhook and the microphone boom, and then hang the earhook on your auricle.

2. We have update a rotatable earplug to meet your requirements for comfortable angles of wear.

After you adjust the earhook, you can hold on the earplug to adjust the ear tips angle to find a suitable position then you can wear the earpiece in your ear canal comfortably.

③

-
- ① Microphone
③ Multi-Function Button
⑤ Volume-
⑦ Charging Port
② Angle Adjustment Button
④ Volume+
⑥ Charging Display
⑧ Rotate Eartip
1. Adjust the angle of the earhook and the microphone boom ,and then hang the earhook on your auricle.
2. We have update a rotatable earplug to meet your requirements for comfortable angles of wear.
After you adjust the earhook, you can hold on the earplug to adjust the earbuds angle to find a suitable position then you can wear the earpiece in your ear canal comfortably.

PAIRING

Step1

- 1- Open the charging case and take out the earbud Earbud will power on automatically and the light will flash (Ice Blue);
- 2- And will response with a voice prompt "Power on";

It enters the pairing mode and with a voice prompt "Pairing".

Step2

- 1- Turn on Bluetooth function on your phone via 'Setting'>'Bluetooth On';
- 2- Tap on "G3" on the retrieved device to connect;
- 3- After connecting completed, the earbud will response with a voice prompt "Connected";
- 4- You can use the bluetooth headset to listing music or on a call.

At the next time you use this earbud, just need take out the bluetooth earbud from charging case and turn on your bluetooth function of the smart device to automatically connect.

Wireless Headset Connection



The image shows a screenshot of an iPhone's Bluetooth settings. At the top, the 'Bluetooth' toggle switch is turned on. Below it, under the 'MY DEVICES' section, a device named 'G3' is listed as 'Paired'. A white circle with a black border highlights the 'G3' device name. At the bottom of the page, there is a small circle containing the number '4'.

Step1

- 1- Open the charging case and take out the earbud Earbud will power on automatically and the light will flash (Ice Blue);
- 2- And will response with a voice prompt "Power on"; It enters the pairing mode and with a voice prompt "Pairing".

Step2

- 1- Turn on Bluetooth function on your phone via 'Setting'>'Bluetooth On';
- 2- Tap on "G3" on the retrieved device to connect;
- 3- After connecting completed, the earbud will response with a voice prompt "Connected";
- 4- You can use the bluetooth headset to listing music or on a call.

At the next time you use this earbud, just need take out the bluetooth earbud from charging case and turn on your bluetooth function of the smart device to automatically connect.

Wireless Headset Connection



4

Features	Operate
Play/Pause	Click the "MFB" button once
Pre song	Long Press the "-" button once
Next song	Long Press the "+" button once
Volume +/Volume -	Press the +/- button once
Reject call	Long press the MFB button for 3 seconds
Answer call	Press the MFB button once
End call	Press the MFB button twice to end the call
Wake up Siri	Click the "MFB" button for 3 times
Call Mute Mode	Long press the MFB button for 2 seconds to enter/exit when on a call

Please note: When you want to enter a call mute mode, please do not click the button twice or press the button for a long time, it will end the call or turn off the headset.

⑤

Features	Operate
Play/Pause	Click the "MFB" button once
Pre song	Long Press the "-" button once
Next song	Long Press the "+" button once
Volume +/Volume -	Press the +/- button once
Reject call	Long press the MFB button for 3 seconds
Answer call	Press the MFB button once
End call	Press the MFB button twice to end the call
Wake up Siri	Click the "MFB" button for 3 times
Call Mute Mode	Long press the MFB button for 2 seconds to enter/exit when on a call

Please note: When you want to enter a call mute mode, please do not click the button twice or press the button for a long time, it will end the call or turn off the headset.

⑤

HOW TO CHARGE

- ① Charge the charging case
- ② Charger (Just include the charge cable)
- ③ Power Bank

Plug the charge cable into the charging port, the LED light indicator on the power display will flash constantly; Will display 100 when charging case fully charged.

Charge the Headset

You can use the charging case to charge the headset. Put your headset into the charging case (Please make sure the charging box is fully charged). Close the lid of the charge case and it will charge for the headset automatically.

The headset is charging: The charging case indicator (LED indicator) keep lighting. The headset is fully charged: The charging case indicator (LED indicator) is off.

⑥

- ① Charge the charging case
② Charger (Just include the charge cable)
③ Power Bank
- Plug the charge cable into the charging port, the LED light indicator on the power display will flash constantly; Will display 100 when charging case fully charged.
-
- Charge the Headset**
- You can use the charging case to charge the headset. Put your headset into the charging case (Please make sure the charging box is fully charged), Close the lid of the charge case and it will charge for the headset automatically.
- The headset is charging: The charging case indicator (LED indicator) keep lighting. The headset is fully charged: The charging case indicator(LED indicator) is off.
- ⑥

HOW TO TURN ON/OFF THE HEADSET WITHOUT CHARGING CASE

Turn on the headset

Long press on the MFB button for 3 seconds ,a voice prompt"Power on" that the earbud is turn on;

Turn off the headset

Long press on the MFB button for 5 seconds ,a voice prompt"Power off" that the earbud has been closed.



The image shows a black headset resting inside its open charging case. A circular inset on the right side of the case highlights a green LED power display showing the number '100'. The headset has a blue light ring around the earbud.

LED POWER DISPLAY

 ⑦

LED POWER DISPLAY

PRODUCT SPECIFICS	
Model	G3
Bluetooth Version	Bluetooth 5.1
Net of headset	13g
Net of charging case	64g
Size of charging case	103x60x31mm
Battery capacity	110mAh(Earpiece) 400mAh (Charging case)
Charging time	1h-2h
Microphone sensitivity	-42dB±3dB
Usage time	Talk time:About 15 hours Music time:About 12 hours Standby time:About 500 hours (connected with device)
Input	DC4.7~5.7 (V)

TROUBLE SHOOTING	
1.The headset cannot be connected to the smart device	
How to fix it:	
① Confirm the status of the Bluetooth function;	
② Turn off bluetooth function of your device, delete the historical connection and pairing again;	
③ Or please try to connect other accessories device.	
⑧	

Model	G3
Bluetooth Version	Bluetooth 5.1
Net of headset	13g
Net of charging case	64g
Size of charging case	103x60x31mm
Battery capacity	110mAh(Earpiece) 400mAh (Charging case)
Charging time	1h-2h
Microphone sensitivity	-42dB±3dB
Usage time	Talk time:About 15 hours Music time:About 12 hours Standby time:About 500 hours (connected with device)
Input	DC4.7~5.7 (V)

1.The headset cannot be connected to the smart device

How to fix it:

- ①Confirm the status of the Bluetooth function;
- ②Turn off bluetooth function of your device, delete the historical connection and pairing again;
- ③Or please try to connect other accessories device.

(8)

1.The headset cannot be connected to the smart device

How to fix it:

- ①Confirm the status of the Bluetooth function;
- ②Turn off bluetooth function of your device, delete the historical connection and pairing again;
- ③Or please try to connect other accessories device.

(8)

2. The headset can not be charged

How to fix it:

- ① Make sure that the headset is correctly placed/stored in the charging case.
- ② Confirm the battery capacity of the charging case.
- ③ Check whether the charging contact point of charging case or headset have spot or not.

3. The headset does not respond

How to fix it:

Put the headset in the charging case back, close the lid and wait another 1 minute or so, then take out the headset, and try to connect again.

4. The charging case cannot be charged

How to fix it:

- ① Check whether the charging cable is tightly connected with the charging case.
- ② Check the remaining battery capacity.
- ③ Replace another charge cable

5. The headset have no sound

How to fix it:

- ① Check whether the audio track is played via the smartphone application.
- ② Check the headset battery whether was run out of.
- ③ Increase the volume of headset and mobile devices (or music playback applications).
- ④ Make sure that the correct mobile device is connected.
- ⑤ Please try to connect to other mobile devices.

⑨

SAFE PRECAUTIONS

- Please do not place the wireless earbud in humid,dusty,oily, or high temperature environment.Otherwise, it may cause electric shock, heat generation, or fire;
- Do not disassemble or modify. Otherwise it may cause malfunction or electric shock;
- Generally, please do not throw it away with garbage (non-burnable garbage). May cause fire or rupture;
- Please keep this device out of reach of children,infants and babies,that may cause suffocation if swallowed by children;
- Please do not use it at high volume for a long time;
- Please don't increase the volume at the beginning;
- Please do not add water or objects to the charging case;
- Do not touch the liquid with hands when the battery leaks;
- Before charging, keep dry of the earbud and charging case;
- Please do not damage the charging cable;
- Please charge it regularly;
- Do not use if there is any discomfort such as itching.

10

- Please do not place the wireless earbud in humid,dusty,oily, or high temperature environment.Otherwise, it may cause electric shock, heat generation, or fire;
- Do not disassemble or modify. Otherwise it may cause malfunction or electric shock;
- Generally, please do not throw it away with garbage (non-burnable garbage). May cause fire or rupture;
- Please keep this device out of reach of children,infants and babies,that may cause suffocation if swallowed by children;
- Please do not use it at high volume for a long time;
- Please don't increase the volume at the beginning;
- Please do not add water or objects to the charging case;
- Do not touch the liquid with hands when the battery leaks;
- Before charging, keep dry of the earbud and charging case;
- Please do not damage the charging cable;
- Please charge it regularly;
- Do not use if there is any discomfort such as itching.

11

Eumspo

Wireless Headset

G3



EC REP C&E Connection E-Commerce (DE) GmbH
Zum Linnegraben 20, 65933, Frankfurt am Main, Germany
Email: info@ce-connection.de

FC CE RoHS   

MADE IN CHINA

12



FC CE RoHS




MADE IN CHINA

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.