

U-BOAT
ITALO FONTANA

EN

CARE AND MAINTENANCE.

The precision mechanism in your watch will provide long-lasting performance when properly cared for.

We recommend taking your watch to an Authorised Retailer / Authorised Service Centre every 3-4 years for a check-up and to perform ordinary maintenance on all mechanical parts.

We also advise taking your watch to an Authorised Retailer / Authorised Service Centre to change the strap.


Avoid leaving your watch where it is exposed to wide temperature variations, humidity, the sun and strong magnetic fields.

CHRONOGRAPH FUNCTIONS.


1. Press button H (start/stop) to start the chronograph and the hour/minute counters. **2.** Press button H again to stop the chronograph and once more to restart it. **3.** After noting the time measured, press reset button B when the chronograph is stopped to return the chronograph hand and counters to zero.

WATCH FUNCTIONS.


- A** WINDER COVER
- B** RESET THE CHRONO
- C** 24H COUNTER (PM-AM)
- D** CHRONOGRAPH HOUR COUNTER
- E** CHRONOGRAPH SECONDS HAND
- F** WINDER
- G** CHRONOGRAPH MINUTE COUNTER
- H** START/STOP CHRONOGRAPH
- I** SECONDS COUNTER
- L** WINDER EXTRACTION BUTTON
- M** DATE INDICATOR
(Where Available)




POSITION 1 NEUTRAL POSITION



POSITION 2 FIRST CLICK



POSITION 3 SECOND CLICK



INSTRUCTIONS FOR USE.

1. Unscrew the winder cover **A** to access the winder **F**.

POSITION 1 NEUTRAL POSITION

Watch operation position.
Watch winding position.

POSITION 2 FIRST CLICK

Press the button **L** to put winder **F** in the first position for rapid date setting.*

POSITION 3 SECOND CLICK

Press the button **L** for precise time setting. We advise you to turn the minute hand past the desired time and then back to the exact position.

Check the 24 H counter when doing this operation.

2. Close the winder **F** and turn the winder cover **A** to its original position (turn until it stops).

* NB: It is not possible to adjust the date between 9.00 p.m. and 3.00 a.m.

U-BOAT HEAD OFFICE

Via per San Gennaro, 13

Gragnano, Capannori - 55012 Lucca - Italy

Tel: +39 0583 469288 - Fax: +39 0583 462249

info@u-boatwatch.com

