

Jabra Elite 7 Active - Navy (Include wireless charging pad)

Can I use just one of my Jabra earbuds?

Yes, you can use the right or the left earbud individually for playback of music or calls.

To activate mono earbud mode, place the unused earbud in the charging case. When you remove both earbuds from the charging case, the left and right earbuds will automatically relink and enter stereo mode.

Note

For Android devices, stereo mixing must be enabled by selecting the AAC or SBC audio codec in the Developer options on your smartphone.


View the following table for how to manage calls and music in mono earbud mode.

The explanations are in English. For other language versions, refer to the translated user manual in the Product documents section on the support page for your product.

Left button	Left earbud only
Play/pause music	Press the Left button when listening to music
Answer call	Press the Left button
End/Reject call	Double-press the Left button
Mute/unmute microphone	Press the Left button when on a call
Activate Voice assistant or one-touch Spotify playback	Double-press the Left button when not on a call
Adjust volume	Use the volume controls on the paired mobile device



Right button Right earbud only



Play/pause music	Press the Right button when listening to music
Answer call	Press the Right button
End/Reject call	Double-press the Right button
Mute/unmute microphone	Press the Right button when on a call
Next track	Double-press the Right button when listening to music
Restart track or previous track	Triple-press the Right button when listening to music Repeat to skip to the previous track
Adjust volume	Use the volume controls on the paired mobile device



Maßgebliche Produkte



**Jabra Elite 7 Pro -
Titanium Black**



**Jabra Elite 7 Pro -
Black**



**Jabra Elite 7 Pro -
Gold Beige**



**Jabra Elite 7 Pro -
Titanium Black**



**Jabra Elite 7 Active -
Mint**



**Jabra Elite 7 Active -
Black**



**Jabra Elite 7 Active -
Navy**



**Jabra Elite 7 Active -
Navy (Include**

