


TECCPO

Heat Gun

TAHG07P



www.teccpotools.com



TROUBLESHOOTING

Your Warranty Includes

30 Days Money Back Guaranty

With in first 30days of your purchase, you are allowed to return your product for a full refund.

30 Days to 3 Months(6 Months)

We will replace the defective unit due to manufacture fault with a new one.
(You will receive extra 3 months if you register on our website.)

3 Months to 24 Months

Within 24 months, we will provide timely and effective online after-sales service after your purchase.

Please be noted that accesories are free, not included.

How to Return Your TECCPO Products

- Contact support@teccpotools.com with your order number.
- We will issue you RMA# and return address for your return.
- Please fill out RMA info, tear off this page and leave it inside your return package.
We will issue replace/return after receiving your return.

Return Products Details

To get your returns processed as quickly as possible, please fill this form and include it in your return package.

Purchase Name	
Order Number	
Date of Purchase	
Your Email Address	
Where did you buy it	

- If your product is purchased from Amazon Fulfilled channel, please contact Amazon for return within 30 days of purchase.



IMPORTANT SAFETY INSTRUCTIONS

READ THESE INSTRUCTIONS

WARNING: Extreme care should be taken when stripping paint. The peelings, residue and vapors of paint may contain lead, which is poisonous. Any pre-1977 paint may contain lead and paint applied to homes prior to 1950 is likely to contain lead. Once deposited on surfaces, hand to mouth contact can result in the ingestion of lead. Exposure to even low levels of lead can cause irreversible brain and nervous system damage; young and unborn children are particularly vulnerable.

Before beginning any paint removal process you should determine whether the paint you are removing contains lead. This can be done by your local health department or by a professional who uses a paint analyzer to check the lead content of the paint to be removed. Lead-based paint should only be removed by a professional and should not be removed by using a heat gun.

Persons removing paint should follow these guidelines:

1. Indoors, keep the work area well ventilated. Open the windows and put an exhaust fan in one of them. Be sure the fan is moving the air from inside to outside.
2. Remove or cover any carpets, rugs, furniture, clothing, cooking utensils and air ducts.
3. Place drop cloth in the work area to catch any paint chips or peelings. Wear protective clothing such as extra work shirts, overalls and hats.
4. Work in one room at a time. Furnishings should be removed or placed in the center of the room and covered. Work areas should be sealed off from the rest of the dwelling by sealing doorways with drop cloths.
5. Children, pregnant or potentially pregnant women and nursing mothers should not be present in the work area until the work is done and all clean up is complete.
6. Wear a dust respirator mask or a dual filter (dust and fume) respirator mask which has been approved by the Occupational Safety



and Health Administration (OSHA), the National Institute of Safety and Health (NIOSH), or the United States Bureau of Mines. These masks and replaceable filters are readily available at major hardware stores. Be sure the mask fits. Beards and facial hair may keep masks from sealing properly. Change filters often. DISPOSABLE PAPER MASKS ARE NOT ADEQUATE.

7. Use caution when operating the heat gun. Keep the heat gun moving as excessive heat will generate fumes which can be inhaled by the operator.
8. Keep food and drink out of the work area. Wash hands, arms and face and rinse mouth before eating or drinking. Do not smoke or chew gum or tobacco in the work area.
9. Clean up all removed paint and dust by wet mopping the floors. Use a wet cloth to clean all walls, sills and any other surface where paint or dust is clinging. DO NOT SWEEP, DRY DUST OR VACUUM. Use a high phosphate detergent or trisodium phosphate (TSP) to wash and mop areas.
10. At the end of each work session put the paint chips and debris in a double plastic bag, close it with tape or twist ties, and dispose of properly.
11. Remove protective clothing and work shoes in the work area to avoid carrying dust into the rest of the dwelling. Wash work clothes separately. Wipe shoes off with a wet rag that is then washed with the work clothes. Wash hair and body thoroughly with soap and water.

A fire may result if the appliance is not used with care, therefore

- Be careful when using the appliance in places where there are combustible materials;
- Do not apply to the same place for long time;
- Do not use in presence of an explosive atmosphere;
- Be aware that heat may be conducted to combustible materials that are out of sight;
- Do not leave the appliance unattended when it is switched on.

If the supply cord is damaged, it must be replaced by manufacturer, its service agent or similarly qualified persons in order to avoid a

hazard.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

SAVE THESE INSTRUCTIONS

Safety Rules



WARNING: Non-observance of the safety rules while working with the hot air tool can lead to fire, explosion, electric shock or burns. Read the operating instructions before using the tool and always observe the safety rules. Save these instructions and give them to persons that have not been instructed before they use the tool.



WARNING: A damaged casing or an opened unit can lead to a hazardous electric shock. Do not open the unit and do not put a damaged unit into operation. Do not drill into the casing, e.g. to attach a company label. Before any work on the unit, pull the mains plug.



WARNING: A damaged power cord can lead to a hazardous electric shock. Check the power cord regularly. Do not operate the unit when the power cord is damaged. Always have a damaged cord replaced through a specialist. Do not wrap the cord around the unit and protect it from oil, heat and sharp edges. Do not carry the unit by the cord and do not use the cord to pull the plug from the outlet.



WARNING: Do not work in rain or in a moist or wet environment. This can lead to a hazardous electric shock. Keep the unit dry. Store the unit in a dry location when not in use. Consider the weather conditions. Do not work in wet sanitary facilities. Avoid body contact with grounded cables or surfaces, such as pipes,

radiators, ranges and refrigerators.



WARNING: Connect power tools that are used in the open via a residual current circuit breaker (RCCB).



WARNING: Danger of explosion! The hot air tool can explosively ignite combustible fluids and gases. Do not work in a potentially explosive environment. Check the surrounding before starting to work. Do not work on fuels or gas containers or in their vicinity, even when they are empty.



WARNING: Danger of fire! Heat can reach combustible materials that are hidden behind coverings, in ceilings, floors or cavities, and ignite them. Inspect the work area before starting to work and in case of doubt, abstain from using the hot air tool. Do not point the unit at the same spot for extended periods



WARNING: Danger of fire! An unsupervised operating hot air tool can set fire to objects that are close by. The unit must be supervised at all times during operation. When allowing the switched off unit to cool down, always place it down vertical and standing. Allow the unit to cool down completely.



WARNING: Danger of fire! When working plastics varnish or similar materials, gases develop that are easily inflammable and can lead to explosions. Be prepared for flames to develop and keep suitable fire-extinguishing means at hand.



WARNING: Danger of intoxication! When working plastics, varnish or similar materials, gases develop that can be aggressive or toxic. Avoid breathing in vapours, even when they appear to be harmless. Always provide for good ventilation of the work area or wear a respirator.



WARNING: Danger of injury! The hot air jet can injure persons or animals. Touching the hot tube of the heating element or the nozzle leads to skin burns. Keep children and other persons away from the unit. Do not touch the tube of the heating element or the nozzle when they are hot. Do not use the unit as a hair dryer. It develops much more heat than a hair dryer. Do not use the unit to heat up fluids or to dry objects or materials that are destroyed through the influence of hot air.

 **WARNING:**Unintentional starting or unexpected switching on of the heating element after actuation of the thermal relay can lead to injuries. Make sure that the switch is set to OFF when connecting the unit to the mains supply. Switch the unit OFF when the thermal relay has actuated

 **WARNING:**Danger of injury! Using an air flow reflection nozzle that is not suitable for your unit can lead to burns. Use only original accessories for your model that are listed in these operating instructions.


 **WARNING:**Danger of injury and fire. The hot air tool is dangerous for children. Keep the hot air tool out of the reach of children.

 **DANGER:**Danger of lead overheating! Incorrect handling can lead to an accumulation of heat and thus damage the unit. Do not operate the unit when it is placed down horizontally or when pointed downward. The air –intake opening and the nozzle must not be covered. Use only nozzles that are suitable for your unit.



Technical Data

Model		TAHG07P		
Voltage	(V)	120V		
Frequency	(Hz)	60Hz		
Power	(W)	1500W		
Switch position		I	II	III
Temperature	°C	50 °C (Cool Down)	480 °C	600 °C
	°F	122 °F	896 °F	1112 °F
Air flow	L/min	250L/min	250L/min	500L/min
Protection class		II /  Double insulated		

Component Description



1	Barrel	5	Handle
2	Barrel cover	6	Plug clip
3	Housing	7	Coupler
4	Switch (0 -I-II-III)		



1) Mode selector switch

- a) 0 (Power OFF)
- b) I (Cool Down 50 °C / 122 °F)
- c) II (Low 480 °C / 896 °F)
- d) III (High 600 °C / 1100 °F)


2) Rear stabilizer fins (stand)

Fully insert the cord plug into heat gun handle.

NOTE: The power cord is not detachable, once insert do not try to detach it.

Note: Smoke may appear during the initial start up due to the burning of manufacturing oils. The smoke should disappear in less than a minute.


Hands-free operation



The Heat Gun has an integrated stand for bench top applications and cooling down.

The best method of paint removal

Move the Heat Gun slowly and steadily forward at an angle to the surface, pointing the nozzle in the direction of motion. This allows you to scrape safely outside the hot air stream and keeps the scraper and the scraped surface cooler.



- A. Warm air preheats the surface.
- B. Paint is softened by hot air.
 - A + B. Deep penetration of heat over total area.
- C. Paint can be easily scraped off as soon as it is softened and the gun is moved forward.
- D. Stripped surface allowed to cool.

Accessories

The following accessories may come with the Heat Gun or be purchased.

Description	Photo	Applications
Concentrator Nozzle		Directs a concentrated heat flow to the work surface. Ideal for removing paint in awkward corners, crevices, mouldings, beading or architraves.
Glass Protection Nozzle		Deflects the heat away from glass or other fragile areas. Ideal for window sills, ledges, frames and skirting boards.
Wide Concentrator Nozzle		Directs a long, narrow heat pattern to the work surface. Ideal for removing paint or varnish from large, flat surfaces such as skirting boards, doors, stairs, etc. It should be used in conjunction with a flat scraper.
Reflector Nozzle		Disperses the heat flow evenly around the whole work surface. Ideal for thawing frozen pipes, solder pipe work, bending plastics or heat shrinking electrical insulating tubing.
Scraper		Stripping paint, varnish and removing vinyl tiles
Detailed scraper		Stripping paint and varnish from window sills.
BBQ Nozzle		Dry or lighting charcoal for BBQ and fireplace.

Heating Guidelines

TECCPO Heat Gun is one of the most versatile tools you can own. It can be used for a great variety of projects, from big DIY to small Art & Crafts jobs.

	Application	Switch Setting	Nozzle Tip Options
DIY	Stripping paint	HIGH	Concentrator / Wide Concentrator
	Wall repair	LOW	Open
	Drying paint	LOW	Open
	Soften adhesives to remove floor tiles	LOW	Wide Concentrator
	Bend plastic, plexi glass, formica	LOW/HIGH	Reflector
	Removing formica and linoleum	LOW	Wide Concentrator
	Soften paint, caulking and putty for easier removal (use heat deflector)	HIGH	Concentrator / Wide Concentrator
	Shrink plastic film for wrapping or Weatherproofing	LOW	Wide concentrator
Automotive	Removing stickers, emblems and decals	LOW	Open
	Removing dents	HIGH	Open
	Removing paint	HIGH	Concentrator/Wide Concentrator
	Applying and removing window tint	LOW	Open
	Restoring bumpers	HIGH	Open
Electronics	Smart phone & tablet repair	LOW	Concentrator
	PlayStation and Xbox repair	LOW	Concentrator



Art & Crafts	Making soap	LOW	Open
	Shrink wrapping presents	LOW	Open
	Forming foam	LOW	Open
	Cookie decoration	LOW/HIGH	Open
Small jobs (including repair)	Loosen rusted nuts, bolts and fittings	HIGH	Open
	Repairing jeans	LOW	Wide concentrator
	Burning weeds	HIGH	Concentrator
	Removing adhesives	LOW	Open
	Waxing skis/snowboard	LOW	Wide concentrator
	Glass fibre work	HIGH	Concentrator or Wide Concentrator
	Unfreezing pipes and locks	LOW	Open
	Lighting a BBQ grill	HIGH	Concentrator / BBQ Nozzle
	Heat concrete prior to patching	LOW/HIGH	Concentrator
	Defrosting refrigerator / freezer	LOW	Open



Advisable temperature setting and application

Applications	Temperature setting °C / °F
Removing varnish/ softening adhesives	450 / 842
Shaping plastic tubing	
HDPE	300 / 572
PVC	300 / 572
PP	260 / 500
LDPE	250 / 482
ABS	350 / 662
Note: Temperature can be varied according the shape.	
Shrinking	300 / 572
Defrosting water pipes	
Metal	550 / 1022
PVC(hard)	300 / 572
IMPORTANT: Before heating pipes, check to make sure that it is actually a water pipe.	

Meaning of crossed –out wheeled dustbin:



Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact you local government for information regarding the collection systems available.

If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposals at least free of charge.



Shenzhen Allsight E-business Co., Ltd

Website: www.teccpotools.com

E-mail: support@teccpotools.com

ADD: Room 104, Building P09, South China City Electronic
Trading Center, Longgang District, Shenzhen, CHINA

Made in China



www.teccpotools.com

