



SOLT

Heat Pump Dryer 10.0kg Capacity Quick Start Guide

Tips for Using & Operating Your Heat Pump Dryer
Model: GGSHPD100W



Heat Pump Dryer

10.0kg Capacity

Getting Started...

Please follow these steps before using the dryer

- Check the lint filters are clean and the water tank is empty before every load. Ensure both are replaced correctly before using your dryer.
- Sort and load items into the dryer drum, ensuring no items are in the way of the door. Close the door (you will hear it click shut).

Moving the Dryer

If the dryer needs to be placed at an angle for moving, only angle towards the right hand side (when viewed from the front). If the dryer has not been transported as described, leave it standing upright for at least two hours before turning on.

Operating the Dryer

- 1 Press 'On/Off' to activate your dryer.
- 2 Select your desired drying cycle by turning the Program Selection Dial.
- 3 Select your preferred drying options, using the buttons on the right hand side of the panel (if you wish to select options different from the default options for the cycle).
- 4 Touch the 'Start/Pause' button to start the cycle.

HYGIENE+ Function

This function helps to minimise bacteria from producing within your heat pump dryer. After selecting your preferred program cycle, press the HYGIENE+ button to add a sterilising process to your dry cycle.

Anti-Crease Function

This function helps to minimise creasing of your laundry items. The Anti-Crease LED shall light when the function is selected. At the end of the drying cycle, the default anti-crease operation time is 60 minutes but 30 or 90 minutes can be selected. The clothing can be removed during the anti-crease phase and all other drying programs (excluding: Refresh and Wool).