


Installation Guide

This guide will explain how to connect your Rugged Intercom and Mobile Radio inline with our Radio/Intercom Harness with Rocker Switch.

Radio & Intercom Harness with Rocker Switch (P.N. PH-MS and PH-MS-WP)



- Blue wire connects to accessory bus bar.
- Connection source should only be hot when ignition is turned on.

NOTE: Cables and connections are not to scale.




Installation Guide with Active Filter

This guide will explain how to connect your Rugged Intercom and Mobile Radio inline with our Active Filter and Radio/Intercom Harness with Rocker Switch.

Active Filter (P.N. ACTIVE-FILTER)

Radio & Intercom Harness with Rocker Switch (P.N. PH-MS and PH-MS-WP)



NOTE: Cables and connections are not to scale.