


VisionTek®


SOUNDTUBE XL V2

WATERPROOF BLUETOOTH SPEAKER



USER MANUAL

BLUETOOTH PAIRING





STEP 1 POWER ON

Long press the "O" button for 2-3 seconds to power on the speaker. You will hear a power on tone. The speaker will enter Bluetooth pairing mode notated by the blue indicator LED blinking.

01

STEP 2 SELECT THE DEVICE

Find "Soundtube XL V2" in your Bluetooth device list on your mobile phone, tablet or PC.




STEP 3 COMPLETE PAIRING

The LED indicator on the speaker will shine blue once the device is paired followed by a beep. The device is now paired and you can start enjoying your Soundtube XL V2.

02

TWS (TRUE WIRELESS STEREO) PAIRING



Sync Two Soundtube XL V2 Speakers


OPERATING INSTRUCTIONS

Turn on the two speakers, short press the "TWS" buttons on each speaker to enter TWS pairing mode. An indicator sound and the white TWS indicator light will blink. The speakers will pair automatically. Once paired a "du" notification sound will play and the white TWS indicator light will stay on. Once TWS pairing is complete open the Bluetooth settings on your device and select "Soundtube XL V2" from the Bluetooth device list. This will pair the two Bluetooth speakers to your device at the same time. Short pres the "TWS" button of any speaker to disconnect the TWS pairing. The white TWS indicator will turn off once disconnected.

NOTE: For TWS pairing, connect the two speakers together first then connect to your smartphone or device.

03

BASIC OPERATION



POWER BUTTON / MULTI - FUNCTION BUTTON

Long press the "O" button for 2-3sec, Power On/Off
When a call is incoming, short press "O" to answer
When a call is incoming, double press "O" to refuse
During a call, short press "O" to hang up
Short press "O" when playing music to Pause/Play

+ / - VOLUME BUTTONS

Short press - to adjust the volume down, Long press the - for the previous track
Short press + to adjust the volume up, Long press + for the next track

TWS BUTTON

Short press "TWS" to turn on/off TWS
Long press "TWS" for 2-3sec to disconnect from Bluetooth

04

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including the interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy. And, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Where shielded interface cables or accessories have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC. Changes or modification to product not expressly approved by VisionTek Products, LLC could void your right to use or operate your product by the FCC.

IC Statement: CAN ICES-003 (B) / NMB-003 (B)


This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cordless (Radio Transiter) products: Section A.RSS-310 (27 MHz transmitters and receivers): This Category II radio communication device complies with Industry Canada Standard RSS-310. Section B.RSS-210 (2.4 GHz transmitters or transceivers): This Category I radio communication device complies with RSS-210 of Industry Canada.



MADE IN CHINA



LED INSTRUCTION



POWER ON	Blue light flashes
	PLAY/PAUSE: Blue light is on.
BLUETOOTH MODE	When outside of 10m Bluetooth range, the blue light flashes (indicating pairing status). When the speaker is left in pairing mode for over 10 minutes with no changes, the speaker will turn off
AUX IN MODE	Green light is on
CHARGING STATUS	Red light is on when charging Red light turns off once fully charged
LOW BATTERY INDICATOR	Red light flashes when the battery is running low
TWS	The TWS indicator stays white after TWS pairing is complete

05

STRAP INSTALLATION



4. Tighten the straps

5. Repeat the steps for the other side of the strap

06

PRODUCT SPECIFICATIONS

PRODUCT NAME	SOUNDTUBE XL V2
MODEL NAME	901461
BLUETOOTH VERSION	5.0
BATTERY CAPACITY	7200mAh
WORKING TIME	7-8 HOURS (70% VOLUME)
CHARGING TIME	5-6 HOURS
CHARGING CURRENT	5V=1.8A
DRIVER UNIT	40W = 20Wx2
DIMENSION	280mm x 118mm x 120mm
WEIGHT	1730g±10

07

FREQUENTLY ASKED QUESTIONS

Q: What kind of charger should I use for the speaker?

A: All common USB chargers can be used, we recommend chargers above 5V/1.8A.

Q: What is the device priority of the speaker?

A: The speaker priority is AUX IN input, Bluetooth phone call when paired and then music over Bluetooth mode.

Q: The speaker does not turn on.

A: Plug in the charger and try to turn on the speaker after a few minutes.

Q: What if there is a crackeling or distortion of sound when in use.

A: The speaker can be used at distances up to 10m with no environmental obstruction. If used at a distance greater than 10m or with an obstruction between the connected devices there may be distortion or loss of signal.

Q: Why does the speaker shut down automatically when powered on.

A: When there is no Bluetooth device paired or if the speaker is not connected in AUX mode within 10 minutes, the speaker will shut down to reduce power consumption.

Q: The speaker cannot connect to a previously paired device.

A: On your device remove the speaker from the list of Bluetooth devices. On the speaker short press the Bluetooth Disconnect Button to restart pairing mode.

*This speaker supports mobile phones, tablets, PC, etc. Images and steps provided are based on a mobile phone experience.

1 YEAR WARRANTY



1 866 883 5411

08