



GBros. Adapter — instruction manual

GBros. Adapter 接收器 - 使用说明



- wired GameCube controller, wired NES Classic controller, wired SNES Classic controller, wired Wii Classic controller
- third party controller with the same controller port



* 可支持 GameCube / Classic Editions / Wii Classic 手柄, 以及配备有相同端口的第三方手柄。

Switch



- 1 – put the adapter on its **S** mode, gently press the **home** button to turn it on. LED will start to blink
 - 2 – press **pair** button for 2 seconds to enter its pairing mode. LED will start to rapidly blink
 - 3 – go to your Switch Home Page to click on Controllers, then click on Change Grip/Order to pair with the adapter
 - 4 – LED will become solid when connection is successful
- **star** button = Switch screenshot button, **home** button = Switch home button

Windows



- 1 – put the adapter on its **X** mode, gently press the **home** button to turn it on. LED will start to blink
- 2 – Press **pair** button for 2 seconds to enter its pairing mode. LED will start to rapidly blink
- 3 – Go to your Windows device's Bluetooth setting, pair with [8BitDo GBros Adapter]
- 4 – LED will become solid when connection is successful

Turbo functionality



- 1 – hold the button you would like to set turbo functionality to, press the **star** button on GBros. to activate/deactivate the functionality
- analog sticks and Dpad are not included
 - this does not apply to Switch

Switch



1. 将开关置于 S 档位, 轻按 [home] 键开启接收器, 指示灯闪烁。
 2. 按住 [pair] 键 2 秒进入配对状态, 指示灯快速闪烁。
 3. 打开 Switch 主机 Controllers 设置, 进入 Change Grip / Order 界面, 等待接收器连接。
 4. 连接完成后指示灯常亮。
- * 下次连接轻按 [home] 键可自动连接。
 - * 星号键功能为 Switch 截图键home 键功能为 Switch home 键。

Windows



1. 将开关置于 X 档位, 轻按 [home] 键开启接收器, 指示灯闪烁。
 2. 按住 [pair] 键 2 秒进入配对状态, 指示灯快速闪烁。
 3. 打开 Windows 设备蓝牙, 搜索 [8BitDo GBros Adapter] 连接。
 4. 连接完成后指示灯常亮。
- * 下次连接轻按 [home] 键可自动连接。

Turbo 连发功能





- * 按住需要设置连发的功能键, 再按下 GBros. 星号键可开启/关闭按键的连发功能 (摇杆与方向键不支持连发)。
- * 连接 Switch 时不可用。

Hotkey feature





- press and hold L + R + A + B + START to swap button mapping option between GameCube (green LED indication) and Switch Pro (red LED indication)



热键切换



- * 按住热键 (L + R + A + B + START) 绿灯亮表示切换为 GC 布局, 红灯亮表示切换为 Switch Pro 布局。



battery



- two AA batteries with 30 hours of play time
- Auto shut down - 1 minute with no connection

电池



- * 使用 2 节 AA 电池 (5 号电池) 供电, 可持续使用约 30 小时。
- * 开机后 1 分钟无连接或连接后 15 分钟无操作会自动关机。

support



- please visit support.8bitdo.com for further information & additional support

固件升级



- * 请访问 <http://support.8bitdo.cn/> 了解详细信息。

