

AUSTERE

BANANA ADAPTERS \ USER GUIDE



Model numbers:**Banana Adapters \ 5S-BNN1-2P, 5S-BNN2-2P****Speaker Cable \ 5S-12SP1-100, 5S-14SP1-100, 3S-12SP1-50, 3S-14SP1-50**

CAUTION To reduce the risk of electrical shock, only use the banana adapters and speaker cables indoors and in cool dry locations. DO NOT install near any heat-emitting appliances such as radiators or heat registers. DO NOT install where excessive moisture is present.

Product Registration

Prior to using your product, please go to www.austere.com/guarantee to register your product and to access our complete lifetime guarantee statement.

INSTALLATION

Banana Adapters Austere's banana adapters have gold plated connectors to reduce the chance of oxidation and keeping sound quality at its maximum. Additionally, the connectors have been designed with SecureLatch to ensure a strong, consistent connection, preserving signal integrity.

Routing the Speaker Cable Separate the blue Precision Pull Marker away from the cables by approximately 2". Route the cable by using the blue Precision Pull Marker to pull the cable through walls and cabinets. Using this marker removes any unnecessary stress on the speaker cable, keeping it free from potentially unseen damage.

Prepping the Speaker Cable Once the cable has been routed, be sure to leave at least 1-2 feet of slack in the cable. If it is pulled too tight when you plug it in, the pressure could fray the cable or damage your sound equipment. Make sure to use proper wire cutters to clip the speaker wire to the length you need.


Further separate the individual wires away from the blue Precision Pull Marker by approximately 6". If desired, you can cut off the excess Precision Pull Marker. Using wire strippers, strip away 5/8" of cable insulation from each cable end. A total of (4) wire ends should be prepped per speaker. Once the insulation has been stripped away, twist the ends of each wire so they do not spread apart. Do this to all (4) ends of exposed wire. Once all ends of the cable have been twisted, you can install the banana adapters.

Attaching the Banana Adapters Each adapter is color coded to indicate positive and negative. The connector with the red trim ring is typically used for the positive side, while the connector with the blue trim ring is typically used for the negative side. Watch our [Austere Banana Adapter and Speaker Cable Video](#) on YouTube for a visual of how to attach the adapters to the speaker cable.


**1 ** Unscrew the gold-plated connector of each adapter.



**2 ** Slide one end of the cable all the way through the housing of one of the banana adapters until it stops.



**3 ** Next evenly spread the wires over the self-crimping teeth.



**4 ** Finally, replace the connector and securely fasten. Repeat same steps for all banana adapters.



Technical Support: Please contact our technical support team with installation questions, troubleshooting needs, or general product questions.

- Phone: 1-855-672-0684
- Email: support@ austere.com

LIFETIME GUARANTEE FOR CONSUMERS

Austere, 9375 SW Commerce Circle, Suite 7, Wilsonville, OR 97070, USA extends to you this Limited Guarantee. Statutory or common law may provide you with additional rights or remedies, which shall not be affected by this Limited Lifetime Guarantee. This Guarantee gives you specific legal rights, you may have other rights, which vary from state to state or country to country.

Scope of Guarantee

Austere provides a guarantee of the function of this product, if used in accordance with all applicable instructions and warnings, to be free from original defects in material and workmanship for the Lifetime** of the product, subject to the conditions and limitations below. If the product should prove defective in material or workmanship within that period, Austere will, subject to the following terms, conditions and limitations, repair or, at Austere's sole discretion, replace the defective product, replace with a comparable product if the specific product is no longer available or refund to you the original purchase price you paid to the authorized dealer for the defective product if repair or replacement is not commercially practical or cannot be completed in a timely manner.

**** "Lifetime" **** means the duration of use of the product under normal circumstances and used in accordance with all instructions and warnings, and specifically such time as the product can no longer function after normal use for the specific purpose intended. Lifetime is further defined as the expected and typical life of the product, and specifically not the lifetime of the original purchaser or user.

OBSERVE: Prior to use, the individual user should review all instructions and warnings and take immediate care to determine whether this product is suitable, adequate or safe for the use intended. Because individual applications are subject to great variation, Austere makes no representation or guarantee as to the suitability or fitness of these products for any specific application.

Limitations

This guarantee does not apply to product purchased in used or unpackaged form or purchased from someone other than an authorized dealer, damages incurred as a result of product wear and tear caused by normal use over time, the natural breakdown of colors, cloth and materials over extended time and use, accidental damage, abuse, improper care, unreasonable use, natural disaster, abnormal mechanical or environmental conditions, disassembly, modifications or alterations to the product or negligence in care or use of the product. Removal or defacing of brand labels will immediately void this guarantee.

This guarantee is non-transferable and only applies to the original purchaser of the product. This guarantee is restricted to the original country of purchase and will be void on any product taken outside the country where originally purchased or shipped to directly from an authorized dealer.

Austere shall not be liable for any incidental, reliance, or consequential damages or breach of implied guarantee on its products, including any damage to person or property, and specifically disclaims the warranty of merchantability and warranty of fitness for a particular purpose, whenever the law allows such limitations and disclaimers. Austere's sole and maximum obligation shall be to repair or replace the product or issue a refund in Austere's sole discretion.

See the full terms and details of the Austere guarantee at, www.austere.com/guarantee.

2021 Austere. All rights reserved. Austere and More Than Expected are trademarks of Austere or its affiliates. All other trademarks are the property of their respective owners.





@BeAustere #BeAustere
AUSTERE.COM

