





Replacement Guide

iAdaptAir® Filter Cartridge



To download the complete
Owner's Manual scan here:



To ensure safety and view detailed instructions for
all models, download each complete manual at
<https://www.airoasis.com/resources/>





Replacement Guide

iAdaptAir® Filter Cartridge

- 1) Turn the iAdaptAir® off.
- 2) Open the filter cover by sliding it to the right.
- 3) Lift the used filter from the housing.

Note: If the filter Ribbon breaks during removal, the front dust covers can be removed to facilitate easy removal.





- 4) Place new filter into the iAdaptAir®

Note: Ensure the silver portion of the filter is facing the back of the iAdaptAir.


- 5) Close the filter cover.

Note: After installation press and hold the Filter Indicator light to reset the iAdaptAir.

- 6) Enjoy clean air!



To download the complete
Owner's Manual scan here:



To ensure safety and view detailed instructions for all models, download each complete manual at <https://www.airoasis.com/resources/>

