


# EDEN

# habitat



## Spare Parts

 [www.argos-support.co.uk](http://www.argos-support.co.uk)

 [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk)

 0370 112 1928

## Customer Support

 0045 7668 8055



# Safety and Care Advice

---


## Product Details

White 466/6309  
Rose 311/7749

## IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

- Keep children and animals away from the work area. Small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- This product has been constructed to be used in the domestic environment only and not for commercial purposes.
- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.
- Assembly to be carried out by a competent adult only.
- Do not use this item if any components are missing or damaged



- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.
- **WARNING:** In order to prevent overturning, this product must be used with the wall attachment provided.

## Care and maintenance

---

- Only clean using a damp cloth and mild detergent. Do not use bleach or abrasive cleaners. Furniture polish is not recommended.
- From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.
- This product is suitable for children in the age 18 months to 12 years. Maximum load on chest 30 kg. Maximum load in each drawer 7 kg.




# Tools required

---




Phillips screwdriver  
(medium)



Ruler/tape  
measure




Flatblade screwdriver  
(medium)



Eye protection  
(when using a  
hammer or glue)




Small hammer




Allen key 4mm  
(included)  
No. 4033-002


# Components




**1** Top  
(788x395x16mm)  
No. 4301-1607881-40 White  
No. 4301-1607881-26 Rose




**2** Bottom  
(788x395x16mm)  
No. 4301-1607882-40 White  
No. 4301-1607882-26 Rose




**3** Side x2  
(579x391x16mm)  
No. 4301-1605791-40 White  
No. 4301-1605791-26 Rose




**4** Drawer front x3  
(744x189x16mm)  
No. 4301-1607449-40 White  
No. 4301-1607449-26 Rose




**5** Drawer back x3  
(716x167x13mm)  
No. 15-01307161




**6** Leg x4  
(Ø48x140mm)  
No. 12-04801401




**7** Back panel  
(598x767/383,5x3mm)  
No. 4309-0305981



**8** Drawer side Right x3  
(353x167x13mm)  
No. 15-01303503



**9** Drawer side Left x3  
(353x167x13mm)  
No. 15-01303504




**10** Drawer base x3  
(728x348x3mm)  
No. 4309-0307281





# Fittings (Shown to scale)



## Bag





# 1






# 2



# 3






# 4a







Front edge




# 4b




# 5



# 6






# 7





[K\* & L\*]



**NB!**






# 8





# 9





# 10



# 11



# 12



This drawer must be positioned furthest from floor level

## WARNING!

**IN ORDER TO PREVENT OVERTURNING  
THIS PRODUCT MUST BE USED WITH  
THE WALL ATTACHMENT DEVICE  
PROVIDED**

Serious or fatal crushing injuries can occur from furniture tipping over. To help prevent topple over:

- Use the wall attachment device provided
- Never allow children to climb or hang on drawers, doors or shelves
- Place heaviest items in the lower drawers or shelves
- Unless specifically designed to accommodate, do not set TV's or other heavy objects on top of this product
- Never open more than one drawer at a time

An attachment device is provided with your product, however you will need to source suitable fixings for your wall type. If in doubt, please consult a qualified trades person.

Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.

Permanent safety label. Please do not remove

