

ANDERIC® RRDYS01 Operating Manual

The Anderic® RRDYS01 Remote Control is to work with Dyson® Hot, Cool, Humidifier, and Purifying upright floor fans.



Installing Batteries

Please insert two AAA batteries (sold separately) into the battery compartment behind the battery door on the back of the remote. You may need to remove the screw securing the battery cover. Please make sure to match polarities when installing the batteries. Slide the battery cover down toward the bottom of the remote to remove it, then replace it after installing the batteries. The battery cover screw is optional and is not needed to secure the battery cover to the remote.

Optional security cable (sold separately)

This remote has an optional security cable (sold separately) attachment. You can purchase this security cable from Anderic.com/CBL01. Part number: CBL01.

Programming to your fan:

1. Locate your model fan in the programming chart below.
2. Press and hold the two keys shown beside your fan model for about 3 seconds. The indicator light will blink twice and release the keys.

Note: Please refer to the Key Operations Chart to see which keys should operate. If your fan does not serve as expected, you can also try the other codes; there may be a better-suited code. The RRDYS01 is a universal remote but may not work on all models of fans.

Programming chart

	Press & hold keys:	Fan model(s):
1	&	TP01, TP02, DP02
2	&	PH02
3	&	HP09
4	&	HP07
5	&	TP04, TP05, 969154
6	&	HP02, 967826
7	&	AM10
8	&	BP01, 970192
9	&	TP04, TP05, 969154
10	&	TP06
11	&	AM05, AM04, 922662
12	&	HP01, 967197
13	&	AM06, AM08, 965824

	Press & hold keys:	Fun model:
1	 &  +	Reset to factory default
2	 &  -	Exit learning mode
3	 & ● +	Enter learning mode
4	 & ○ -	Delete all learned keys

Learning Instructions:

Note: All keys on the RRDYS01 are learnable, and an original remote is needed. This method does not require codes.

1. Press and hold the  & ● + keys simultaneously for about 5 seconds; the indicator light will illuminate brighter and remain bright. Release the keys.
2. Point the original remote control head-to-head with the RRDYS01, aligning top edges at about 1-2 inches apart (both remotes should be pointing at each other).
3. On the RRDYS01, Press and release the first key to be learned, and the indicator light will now flash slowly.
4. On the original remote, press and hold the key that you want to learn to the corresponding key previously pressed on the

RRDYS01. The indicator light will flash three times to confirm and then remain on, waiting for the following key to learn.

5. Repeat steps 2-4 to learn other keys.
6. Press  &  - keys simultaneously to save and exit; otherwise remote will exit automatically after 20 seconds.

Delete all learned keys

1. Press and hold  & ○ - keys simultaneously for 3 seconds; the indicator light will flash twice to confirm. The deletion of all learned keys is now complete.

Reset to factory default status

1. Press and hold  &  + keys simultaneously for 3 seconds; the indicator will flash twice to confirm. Reset to factory default is now complete.

Help: Go to Anderic.com/rrdys01

Legal: Anderic is a registered trademark of Dan's Electronics Etc., Inc. All rights reserved. Dyson® is a registered trademark of Dyson Limited. Dan's Electronics Etc., Inc. has no affiliation with Dyson Ltd.



Key Operations Chart

Refer to the below chart to determine which keys are active and the key descriptions.

KEY	Key description	Code number (Refer to the Programming Chart above)												
		1	2	3	4	5	6	7	8	9	10	11	12	13
	POWER	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	FILTER INFORMATION		✓	✓	✓	✓			✓	✓	✓			
AUTO 	AUTO MODE (PURIFY)		✓	✓	✓	✓	✓			✓	✓			
 AUTO	AUTO MODE (HUMIDIFY)		✓					✓						
	HEATING CONTROL (INCREASE TEMP)			✓	✓		✓					✓	✓	
	HEATING CONTROL (DECREASE TEMP)			✓	✓		✓					✓	✓	
	FAN SPEED (INCREASE)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	FAN SPEED (DECREASE)	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	ON/OFF HUMIDIFIER							✓						
	ON/OFF SLEEP TIMER		✓	✓	✓				✓					
	ON/OFF COOLING MODE			✓	✓		✓						✓	
	FOCUSED MODE						✓						✓	
	DIFFUSED MODE						✓						✓	
	SLEEP TIMER (INCREASE)	✓				✓	✓	✓					✓	✓
	SLEEP TIMER (DECREASE)	✓												✓
	HUMIDITY CONTROL (INCREASE)		✓					✓						
	HUMIDITY CONTROL (DECREASE)		✓					✓						
	ON/OFF OSCILLATION	✓	✓	✓	✓	✓	✓		✓	✓	✓	✓	✓	✓
	AIRFLOW DIRECTION		✓	✓	✓					✓	✓			
	ON/OFF NIGHT MODE		✓	✓	✓	✓	✓			✓	✓			