



PRECAUTIONS

To maintain good performance, do not put the unit in places which are extremely hot, cold, dusty or humid, specially do not keep the unit:

1. In a high humidity area.
2. Near a heater.
3. In an area exposed to direct sunlight.

WARNING

1. For the non-professional personnel, please do not open the case of the product and touch the inner part.
2. This product uses direct current, therefore please disconnect the unit first when you want to do some maintenance.
3. Disconnect the unit if it is unused for a long time.
4. Never connect the unit when hands are wet.

NOTICE BEFORE USING

1. Put product in the well-ventilated place, and let all its sides(such as surrounding, back or top) have at least 10 CM as free space.
2. Avoid Cleaning with oil, chemical solvent, or Insecticide.
3. When using product, please avoid abnormal temperature, moist water droplet, Prevent using under high temperature (above 60)or very low temperature.
4. Keep away from the direct sunlight, strong magnetic field, extreme dirty or wet place, as well as computer, fax machine etc.) to prevent electrical interference from such equipment

RADIO OPERATION

1. Choose bands: tune band switch, can choose AM, FM, SW
2. Turn the “TUNING” button to choose the required station
3. Adjust antenna position to get the best receiving effect.

REGULAR MAINTENANCE

Inner maintenance

Use a cotton swab lightly moistened with cleaning liquid or denatured alcohol.

When the parts are cleaned let it dry before using the unit.

Outside maintenance

1. When the case becomes dirty or stained, use a soft cloth lightly moistened with a mild detergent and wipe clean. Do not use strong solvents (alcohol, benzene, thinner, etc.) to clean the case. Do not use dry towel to scrape the case.
2. Keep the plug of headphones away from magnetic goods.

BLUETOOTH OPERATION

Pairing a Bluetooth enabled device with S2.

1. Turn on the VOLUME button, Select “MP3”, will sound “Blue tooth ,waiting for playing”.
2. Please open your device Bluetooth function, and choose S2,When connected successfully, it will sound “Bluetooth connecting”.

SPECIFICATION

General specification:

DC:5V

Output power:1.2W

EP JACK:3.5mm

Speaker: 3 W4Ω3 inch

Net Weight:0.6kgs

Unit size: 178X68X135 mm

Noise rate: ≥ 36db

1.HOW TO USE RECHARGEABLE BATTERY

(1)THE UNIT BUILT IN RECHARGEABLE BATTERY, PLEASE NOTE THAT FIRST TIME NEED TO CHARGE 12 HOURS.

(2)NORMALLY, IF USE RECHARGEABLE BATTERY, IT CAN OPERATE UNIT IN FOLLOWING TIME:

IF USE FOR USB/TF ---IT CAN LAST OVER 270 MINUTES;

IF USE FOR RADIO---IT CAN LAST OVER500 MINUTES;

! WARNING:

To prevent fire or shock hazard, do not expose this appliance to rain or moisture. Do not remove cover(or back) ,no user serviceable parts inside. Refer servicing to qualified service personnel.

Videyas

AM/FM/SW1-6 8 BAND WORLD RECEIVER INSTRUCTION MANUAL



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

