


60cm Ceramic Cooktop




FEATURES

4 Cooking Zones, Front Touch Controls,
9 Power Levels, 99 Minute Timer, Residual Heat Indicators
Durable Ceramic Glass, Child Lock

Congratulations on your new InAlto 60cm Ceramic Cooktop!

YOUR COOKTOP



Legend:

1. Max. 1200 W zone
2. Max. 1800 W zone
3. Max. 1200 W zone
4. Max. 1800 W zone
5. Glass plate
6. ON/OFF
7. Control panel

USING YOUR COOKTOP

To start cooking:

- Touch the "ON/OFF" control and all the indicators will show "-".
- Make sure the bottom of the pan and the surface of the cooking zone are clean and dry. Then place a suitable pan on the cooking zone that you wish to use.
- Select a heat setting by touching the "-" or "+" button controls. The options range from 0-9. You can modify this temperature at any time during cooking.

To end cooking:

- Turn a specific cooking zone off by scrolling down to "0" or touching the "-" and "+" controls at the same time.
- Alternatively, turn the whole cooktop off by touching the ON/OFF control.
- After a cooking zone is turned off, the corresponding indicator will show "H" until the zone has cooled to a safe temperature.

Note: For further operation instructions refer to pages 10-12 of your user manual.

DETAILS

Dimensions (W, D, H mm): 590 × 520 × 55
Built-in Dimensions (W, D mm): 560 × 490
Warranty: 3 Years (2 + 1 on registration)

SUPPORT

Telephone: 1300 11 4357
Email: support@residentiagroup.com.au