

REPAIR SHEET

BRAND


RYOBI

MODEL NO.

P208

DESCRIPTION

18 Volt 1/2 in. 2-Speed Drill-Driver




ONE WORLD TECHNOLOGIES, INC.

P.O. Box 1288, Anderson, SC 29622 ■ 1-800-525-2579 ■ www.ryobitools.com

2-23-21 (Rev:03)

The model number and manufacturing location will be found on a label attached to the product. Always mention this information in all communications regarding this product and when ordering parts.








P208

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	304952001	Housing Assembly	1
2	303433002	Top Level Assembly	1
3	940114178	Logo Label	1
4	6613402	Screw (Special)	1
5	670794017	Chuck	1
6	201953002	Clutch Cap and Gear Box Assembly	1
7	350135001	2-Speed Change Knob	1
8	660212005	Screw (M4 x 8 mm)	2
9	670030004	Spring Washer (OD7.2 x ID4.1 x 1t)	2
10	230079019	Motor Assembly	1
11	270016163	Switch Assembly	1

KEY NO.	PART NO.	DESCRIPTION	QTY.
12	522136001	Forward / Reverse Button	1
13	290804048	LED Assembly	1
14	660031012	Screw (M3.5 x 14 mm)	7
15	660419003	Screw (M3.5 x 20 mm)	2
16	940488311	Data Label	1
17	303001042	Magnet	1
18	630206007	Bit Clip	1
19	6782045	Double Bit	1
20	303487004	Auxiliary Handle	1
	Not Shown:		
	988000599	Operator's Manual	



**WIRING DIAGRAM**