





0199




Position ID	Part number.	Replaces:	Description
0101	00146135		Back wall panel
0102	11031592		Back panel
0103	00649417	00752161	Cover
0104	20000372		Panel
0105	20000373		Panel side
0106	00719250		Panel side
0107	00771304		Front panel
0108	00623741		Screw





Position ID	Part number.	Replaces:	Description
0201	12024418		Module-relay
0202	12024417		Module-relay
0203	00617931		Display
0205	00609115		Switch
0206	11032495		Display module not programmed
0209	12028681		Switch-selector
0211	00719263	23000460	Support
0213	20000024		Panel-facia
0214	10008212		Screw
0215	10008201		Ring
0216	00418122		Ring
0217	10010231		Encoder
0218	10008199		Knob
0219	10008200		Knob
0221	10011932		Ring
0222	10011933		Ring
0223	10008226		Bracket
0224	00629049		Energy regulator
0225	00617886		Display
0227	10011934		Knob
0228	10008225		Knob
0206	12028875		Display module programmed
0212	00623615		Nut






Position ID	Part number.	Replaces:	Description
0301	10004490		Burner cap
0302	10004489		Burner cap
0303	10004493		Burner
0304	10004492		Burner
0305	10004495		Venturi nozzle
0306	10006471		Electrode
0308	10004498		Burner housing
0309	10004497		Burner housing
0311	10006793		Jet
0312	10006797		Jet
0313	12007259		Ignition device
0315	00687075		Tray
0316	12024446		Heat shield
0314	00701902		Rail
0307	10008211		Screw
0310	10004531		Screw






0496



Position ID	Part number.	Replaces:	Description
0401	10004490		Burner cap
0402	10004489		Burner cap
0403	10004493		Burner
0404	10004492		Burner
0405	10004495		Venturi nozzle
0406	10006471		Electrode
0408	10004498		Burner housing
0409	10004497		Burner housing
0411	10006793		Jet
0412	10006797		Jet
0413	12007259		Ignition device
0415	11013687		Hob top
0416	10008221		Heat shield
0414	00701902		Rail
0407	10008211		Screw
0410	10004531		Screw






Position ID	Part number.	Replaces:	Description
0501	11030914		Gas tap
0502	11030913		Gas tap
0503	11032796		Gas tap
0504	11032797		Gas tap
0505	11030916		Gas tap
0506	11030915		Gas tap
0507	00719264		Tube
0508	11030971		Gas tap
0509	11032982		Gas tap
0510	11030970		Gas tap
0511	00605061		Valve-two way
0512	11032984		Gas tap
0513	00607662		Connection
0514	00423093		Valve
0516	00427661		Connection piece
0517	00601543		Connection
0518	00425942		Pipe connection piece
0520	10010270		Pipe connection piece
0521	11032983		Gas tap
0522	10003806		Valve
0523	10009155		Valve
0524	00420807		Screw
0525	00779008		Manifold
0526	20000265		Manifold
0528	00754658		Regulator-pressure
0529	10010200		Adapter
0530	11030960		Gas tap




0531	10010197		Bracket
0515	11032985		Gas tap
0527	10009569		Bracket
0519	10011560		Connection piece





Position ID	Part number.	Replaces:	Description
0601	12024441		Frame
0602	10008228		Screw
0603	00634163		Clip
0604	10010298		Washer
0605	10008224		Screw
0606	00145749		Grill grid
0607	11030956		Heating element
0608	10008210		Screw
0609	11030067		Grill accessories
0610	11030015		Tray for Ceramic Briquettes (for PABRICKBKW)
0611	00098049		Salver
0612	12004405		Temperature sensor
0613	10008210		Screw
0614	00634165		Bracket
0615	10008210		Screw
0616	12006463		Cable harness





Position ID	Part number.	Replaces:	Description
0701	11032521		Control module programmed
0701	12025831		Control module not programmed
0702	00418283		Support
0703	12024477	12034882	Control module
0704	12028138		Limiter-temperature
0706	10005470		Control module
0707	00489194		Transformer
0709	10008933		Clip
0710	10008207		Ignition cable
0710	10010202		Clip
0711	12024415		Ignition cable
0712	12026846		Cable harness
0713	12028682		Cable harness
0714	12024414		Cable harness
0715	12028039		Cable harness
0716	12028077		Cable harness set
0717	12026925		Cable harness
0719	12028683		Cable harness
0720	12026870		Cable harness
0721	12024436		Cable harness
0723	12026868		Cable harness
0725	10010201		Adapter
0726	12026928		Cable harness
0730	12024442		Cable harness
0731	10011798		Cable harness
0732	00656309	00752650	Power cord
0708	12031987		Connectivity module




0733	00423966		Cable strap
------	----------	--	-------------





0896



Position ID	Part number.	Replaces:	Description
0804	10007424		Lamp
0805	11032986		Lining
0809	00627375		Temperature sensor
0813	10011396		Bolt
0810	11032987		Deflector
0812	00146140		Support
0816	00600909		Bracket
0817	20000383		Burner pipe
0820	00701957		Burner
0815	00492431		Igniter



0901



0902



0904



0915

0916



0917




0999



0996

0918

0913



0912

0913

0905

0911

0903

0909




0921


0908

0906

0907



0904



0913

0913


0920

0915

0910



Position ID	Part number.	Replaces:	Description
0901	00497756		Motor
0902	00489178		Bracket
0903	00479238		Cover
0904	10007424		Lamp
0905	20000102		Lining
0906	10010225		Nut
0908	00632039	10007567	Socket
0909	00627375		Temperature sensor
0911	11030909		Cover
0912	00146140		Support
0913	10011396		Bolt
0916	00600909		Bracket
0917	11030965		Burner
0920	11032345		Burner pipe
0918	00445814		Guide
0907	00605039		Washer
0910	11030966		Plate
0915	00492431		Igniter
0999	12030862		Repair-set
0921	10020313		Cover







Position ID	Part number.	Replaces:	Description
1002	00643600		Cooling Fan
1003	10011167		Limiter-temperature
1004	00628372		Terminal
1006	00618400		Switch-door
1007	10001186		Plate
1008	10011170		Bolt
1011	12028040		Seal-door
1012	00146142		Cover sheet
1013	11030961		Seal-door
1014	11032988		Cover sheet
1009	10001351		Foot
1010	00649416		Hinge-plate
1001	10020211		Fan motor






Position ID	Part number.	Replaces:	Description
1101	20000091		Door-outer
1102	20000093		Door-inner
1111	11032539		Hinge
1103	10010275		Screw
1104	10011398		Bracket
1105	10011397		Handle-cap shaped
1106	11033705		Handle-door
1107	10011397		Handle-cap shaped
1109	10010274		Screw
1110	10008228		Screw
1112	00618862		Screw





Position ID	Part number.	Replaces:	Description
1201	20000063		Door-outer
1202	20000065		Door-inner
1211	10011376		Hinge
1203	10010275		Screw
1204	10011398		Bracket
1205	10011397		Handle-cap shaped
1206	11032089		Handle
1207	10011397		Handle-cap shaped
1208	10010271		Plate
1209	10010274		Screw
1210	10008228		Screw
1212	00618862		Screw





Position ID	Part number.	Replaces:	Description
1303	00774612		18" Telescopic Rack
1304	00774613		30" Telescopic Rack
1305	11013689		Grill tray
1306	00484628	00449757	Tray for Broiler Pan
1307	00666710		Broiler Pan
1308	00666709		Tray for Broiler Pan
1309	10010207		Bracket
1310	00753356		Sensor
1301	00145306		Grill grid
1302	00637940		Grate Foot Replacement Kit

