


60cm 13 Function Compact Combi Microwave Oven



FEATURES

13 Functions inc. Grill, 50L Capacity, Touch Control Panel, LED Display Screen, 13 Auto Programs, Programmable Timer, Black Glass Finish, Child Lock



Congratulations on your new InAlto 60cm 13 Function Compact Combi Microwave Oven

BEFORE USING YOUR COMBI MICROWAVE OVEN FOR THE FIRST TIME

- Before using this appliance read this manual, taking special note of the 'Safety Instructions' section.
- Ensure that all packaging materials are removed from the appliance.
- To remove the new cooker smell, heat up the oven when it is empty and closed. One hour with convection at 250°C is ideal. Refer to your *User Manual* page 11 for detailed instructions on how to do this.

START COOKING AS AN OVEN

1. In waiting state, touch the F button once. The default temperature and oven function will show on the display.
2. Touch the F button repeatedly until your desired function displays on the screen.
3. Touch the - / + or slide the slider control to set the temperature to your desired temperature.
4. Touch  to enter cooking time setting mode. "00:00" will flash.
5. Touch - / + or slide the slider bar to set the cooking time to you desired time.
6. Touch the  button. The oven will begin operation.

START COOKING AS A MICROWAVE

1. In waiting state, touch the  button to enter microwave operation. The default microwave power 900W will appear and the default cooking time will flash.
2. Touch the - / + or slide the slider bar to set the cooking time.
3. Touch  button to activate the microwave power.
4. Touch - / + or slide the slider control to set the microwave power.
5. Touch the  button. Operation begins and the time starts counting down on the display.

Refer to your *User Manual* Pages 12-17 for detailed operation instructions.

DETAILS

Dimensions (W, D, H mm): 595 × 568 × 454
Warranty: 3 Years (2 + 1 on registration)

SUPPORT

Telephone: 1300 11 4357
Email: support@residentiagroup.com.au

