



SUPPORT THE ART
OF PHOTOIMAGING

3POD TREK SERIES CARBON FIBER TRAVEL TRIPOD



3PCFTT



3POD

SUPPORT THE ART OF PHOTOIMAGING

3POD TREK Series.

The best balance of stability, weight, dexterity, and compact travel in a tripod, optimized for easy transport and quick setup. For the photographer on the prowl, in you.

The TREK Series Carbon Fiber Travel Tripod from 3POD may be one of the most travel-friendly camera supports ever created. Eight layers of the most formidable Carbon Fiber design clad the vibration absorbing legs better than most aluminum-based concepts. Carbon fiber is more than lightweight.

It is a heavyweight champ, ready to fight off contenders for the throne of image stability. Above all, add your own selection of matched head that holds sway for its firm grip, unwavering position, and smooth dexterity.

The formula for the A-Team of Travel.

The twist-lock telescopic legs cluster close-fitting about the center column for an amazingly compact traveling height just over 16", and with the entire unit weighing in at an ultralight 2.16 lbs, there's nothing to stop you from carrying it with you anywhere you go. The center column can be extended to give the system a total height of 58" without sacrificing stability.

Each 4-sectioned telescoping leg features three-position auto-settings and can lock in place individually at preset angles for perfect stance on uneven terrain. The twist locks are fortified with a cutting-edge, wear-resistant internal structure, making them immune to dust, moisture, changes in temperature, and the gradual loosening over time that can occur in inferior locking mechanisms.

A convenient retractable weight hook provides an additional counterbalance to hang accessories. Transverse terrain, scale the heights or explore the grottos with this rugged, extraordinary lightweight 8X carbon fiber with fashionable accents and a superior wear-resistant finish.



Contents

FEATURES	3
TRIPOD DETAILS	4
LEG LENGTH ADJUSTMENT	5
LEG ANGLE ADJUSTMENT	6
THE CENTER COLUMN	7
CENTER COLUMN SPRING HOOK	8
MONOPOD MODE	9
TALKING OPTIONAL HEADS	10
TRAVEL-FRIENDLY PREP	11
NOTES	12
SPECIFICATIONS	13
WARRANTY	15
CUSTOMER SUPPORT	16




FEATURES:


- TREK Series are the lightest travel-friendly camera supports ever created.
- Travel Minimum at 16.5 inch / 41.9 cm and reaches max height 58" inch / 147.3 cm.
- Handles camera and lens combination with a capacity of up to 11 lbs / 5kg.
- Grasp the Trek-Friendly Tripod with one hand.
- Carbon Fiber solves the challenge of size matters.
- Abrasion-resistant 8X Carbon Fiber appointed leg construction.
- Ready for your choice of head to make the TREK complete.
- Anodized red aluminum fashion accents stand apart.
- Seamlessly telescoping legs with twist wear-resistant locks.
- 180° fold-up legs for space-saving compact folding and storage.
- Reversible center column
- Retractable weight/accessory hook



TRIPOD DETAILS



LEG LENGTH ADJUSTMENT




1. Turn any leg twist-lock counterclockwise to unlock the leg. The section is free to be set at any desired length.
2. Twist the leg lock clockwise firmly to lock. Hold the adjacent segment to preserve the leg's settings.

3POD recommends that the sections be extended in a specific order to favor stability over height. Legs with wider diameters are less subject to vibration; therefore, extend the highest and thickest leg section first.

Never over loosen the twist locks to avoid damage to the tripod!


LEG ANGLE ADJUSTMENT



1. Press the Angle Adjustment Button to release the position lock.
2. Upon release, the lever will lock to a preset angle in 3 splay positions, 20°, 50°, and 70°. The trigger spring action automatically sets the first angle when the leg is lifted. The second angle is achieved by raising the leg after pressing the Angle Adjustment Lever past the first stop. The third and highest level can be reached by pressing and lifting the leg to the third stop.
3. Do not lower the leg with the unreleased latch unless you want to go down to the next preset angle.
4. Each time the leg is brought closer to the center, the lower the Angle Adjustment Button's spring lock stops and the lower position.
5. Each leg can be independently set according to the situation presented in the environment, steps, uneven terrain, or flattest of surfaces.



THE CENTER COLUMN




1. Turn the Center Column Twist Lock counterclockwise to unlock the center column. The sliding column can be set to any vertical position.
2. Twist the Center Column Twist Lock clockwise to fix the height of the column.



CENTER COLUMN SPRING HOOK

The Center Column has a hook that is helpful to maintain stability. Use sandbags, waterbags, backpacks, and even rocks in a plastic bag to enhance the balance of the three-legged camera support by suspending them on the hook.


Newton was right! Gravity rules!



MONOPOD MODE

The Spring Hook for weighing down the tripod is removable to transform the Center Column into a handy Monopod.

1. Unscrew the Spring Hook attachment ring and remove it from the end of the column. Keep it safe and saved for future use.
2. Grasp the tripod leg with the upper section enwrapped in foam and twist it clockwise until it unscrews from the socket.
3. Screw the Center Column to the foam-coated leg and join them to create your Monopod.



TALKING OPTIONAL HEADS


Now, what good is an incredible travel tripod without a head?! Like, nowhere! So, let's talk heads.

Here's how to have a ball with the head:

1. Join the head of your liking to the Center Column Loading Plate. There is a 3/8" bolt protruding from the plate. There is a 3/8" tap in the base of the ball head.
2. Screw the bolt into the base of the head.
3. Shoot stills or video with confidence that your device is firm and steady in the 3Pod TREK Series Carbon Fiber Travel Tripod.



TRAVEL-FRIENDLY PREP



The crowning glory of the TREK Series Carbon Fiber Travel Tripod is (surprise!) traveling! The legs flip up to a nice compact stance and are ready to fly!

1. Unlock the Center Column by turning the Locking Collar counterclockwise. Align your optional Tripod Head so that it is in the most compact position.
2. Slide the Column to maximum height.
3. Press and hold the Leg Angle Adjustment Lock for each leg as you swing them upward to meet the center column. All three legs nestle together to form a tight cluster for the most compact travel-ready package.



NOTES

1. Do not exceed the maximum payload.
2. When using the tripod, always lock the central column. Lock or tighten every place that has been loosened during setup.
3. Always safely use the tripod. It's not a baseball bat!
4. Do not use at temperatures below -104°F/-40°C or more than 212°F/100°C.
5. Do not expose to wet, sandy, or dusty environments, especially seawater.
6. Protect the tripod from direct or indirect sun exposure and avoid high temperature environments, such as vehicle interiors.
7. Do not set the tripod as a trip magnet for unaware people in private or public areas.
8. Use a mild detergent and a soft towel to clean the tripod. Pay particular attention to the lock system and the sliding leg extensions.
9. Do not expose the tripod to electrical currents. The results could be shocking!
10. And, we repeat: Never over loosen the twist locks to avoid damage to the tripod!



SPECIFICATIONS

Materials	8X (layers) Carbon Fiber, Hardened Aluminum Alloy, Rubber, Polycarbonate
Maximum Height	58 inch / 147.3 cm
Minimum height	13.25 inch / 33.6 cm
Leg Sections	4
Leg Extension Lock	Twist
Leg Angles	20°, 50°, 70°, 180°
Compact Height	20 inch / 50 cm
Compact Folded Height	16.5 inch / 41.9 cm
Load Capacity	26 lbs / 11.8 kg
Center Column Sections	1
Height monopod	37 inch / 94 cm
Weight	2.16 lbs / .981 Kg



IN THE BOX

- 3Pod TREK Series 8X Carbon Fiber Travel Tripod
- Carry Case
- Manual
- Five Year 3POD Warranty



FIVE YEAR 3POD LIMITED WARRANTY

3POD warrants to the original purchaser that your 3POD product shall be free from defects in material and workmanship for five (5) years from the date of purchase (or delivery as may be required in certain jurisdictions) or thirty (30) days after replacement, whichever comes later.

3POD's entire liability and your exclusive remedy for any breach of warranty shall be, at 3POD's option, to repair or replace the hardware, provided that the hardware is returned to the point of purchase or such other place as 3POD may direct with a copy of the sales receipt or dated itemized receipt. 3POD may, at its option, replace your product, offer to provide a functionally equivalent product, or repair any product with new, refurbished, or used parts as long as such parts are in compliance with the product's technical specifications. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer, or for any additional period that may be applicable in your jurisdiction. If the product has been discontinued, the warranty provider reserves the right to replace it with an equivalent quality and function model.

This warranty does not cover problems or damage resulting from accident, abuse, misapplication, or any unauthorized repair, modification or disassembly, improper operation or maintenance, normal wear and tear, or usage not in accordance with product instructions or connection to an improper voltage supply, use of consumables, such as replacement batteries, not supplied by 3POD, except where such restriction is prohibited by applicable law.

Except where prohibited by applicable law, this warranty is nontransferable. It is limited to the original purchaser and the country in which the product was purchased. This warranty gives you specific legal rights, and you may also have other rights, including a more extended warranty duration that may vary under local laws.

To start a warranty claim, contact the 3POD Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to 3POD, along with the RMA number and proof of purchase.



QUESTION ABOUT OUR PRODUCT LINE? NEED PRODUCT SUPPORT?

We are proud of our products and celebrate our customers.

We are with you, from product selection to everyday use.

Be secure with your purchase and reach us as you need.

 212-647-9300

 brands@adorama.com

 Adorama Brands,
42 West 18th Street,
New York, NY 10011

You can always contact us at **BRANDS@ADORAMA.COM** for personal technical support. Our website contains a wide range of Support and FAQ pages with valuable technical assistance.

3POD is a registered trademark of ADORAMA CAMERA.

© 2022 Adorama Camera, Corp.

All Rights Reserved.



