


Intelligent doorbell

Manual and Instructions for Installation



Read the user manual carefully and keep it properly before using the product.

7.History

Drag the progress bar to watch and store video click on the calendar icon. You can choose the time to watch the video.

8.Cloud storage

If you need cloud storage service, please contact the operator.


9.Function setting

Select the configuration in the upper right corner of the real-time video page, and then go to the [configuration] page to configure the functions of the device.



- ①Enter device name: enter to modify the name of the equipment;
- ②Device password : Enter and modify the device password. In LAN search, you can search the device and input the device password to add.
- ③Wi-Fi settings : Enter the "Wi-Fi Settings" page, select a Wi-Fi, and enter the password, you can change the device Wi-Fi;
- ④Video resolution : Enter settable high definition, standard definition, fluent resolution.
- ⑤Recording mode :here are three alternative video modes-
a.Full-time : refers to the continuous video recording of the camera or doorbell.
b.Alarm : Camera or doorbell are recorded when mobile detection or human body sensing is detected.
c.Disabled : means that the camera or doorbell is not videotaped
- ⑥Infrared sensitivity :Usually used for unattended surveillance video and automatic alarm. The images captured by doorbell at different frame rates

● Function Description




Descript ion	Expl ain
infrared lamp	When the light is dusky, the device will automatically turn the infrared lamp on
Micro SD card slot	Support TF card storage (up to 64 GB)
RESET key	Press the RESET button for 6 seconds to restart the device and restore the default.

● Operational instructions

1.Installation of Batteries

- ①Slide down to remove the backplane
- ②install the battery
- ③cover the back of battery bin.



2.App Download

Use the mobile phone to scan the right two-dimensional code, choose Android or IOS to download and install APP according to the mobile phone system, or search for "JJHOME" to download and install in the mobile application market.

3.Registration and Login

Open APP, if there is no account, please click "Register" according to the interface prompt, sign in after registering a new account, if there is an existing account, complete and click "Login".



11.Delete device

After finding the corresponding device and sliding to the left, a "Delete Device" appears. Click on the Delete Device to delete the device.



12.Personal Center

My order : Click on my order to view historical orders for cloud storage


- 1)Albums :Click on the "Photo Album" on the "Personal Center" page to view the device screen shots, edit and delete the screen shots, etc.
- 2)Settings :Message notification can be set for mobile phones.
- 3)Modify password :The password of the current user can be modified.
- 4)About :
a.User license agreement
b.User manual :It's a common problem in the use of APP.

4.Add device

1)Turn on The device connects to the power cord. Please press the reset key for a long time. The device prompts "Reset Successful". Please check whether there is a hot spot "JJ*****" in the Wi-Fi list.

2)Add

①Enter the list of devices, click "Add key", click "Smart doorbell", and choose the way to add.



②Add methods

A.Sound wave :Get the WIFI connected to the mobile phone, enter the password, click the next step, the interface pop-up operation prompts "mobile phone speaker near the device's wheat", click OK, the mobile phone emits sound waves, the device receives the sound wave blue light flashing, until the mobile phone's sound wave stops, the blue light stops flashing, waiting for the device to connect to the router;



13.LAN Visit

In the login interface, click "LAN access" to enter the "LAN access" interface, through the LAN search to find the same network device; you can complete the "manual add" in Figure 21, add devices.



● device installation

- ①First tear off the back glue paper.
 - ②Stick the back glue on the floor.
 - ③Fix the back board on the wall or door with screw.
 - ④ Install the door bell on the floor.
 - ⑤Install the whole fixing screw at the bottom of the door bell.
- Note: Installation of the floor should be positioned and perforated at least 1 cm away from the side wall.

B.AP connection :

Click "skip" - Select the device hot spot "JJ*****" and enter the initial password(12345678); Return to APP, proceed to the next step according to the prompt, enter the Wi-Fi password, click save, device connection router;



5.Watch videos


Click "Play" on the "Device List" interface and enter the Play interface.

- ①Enter Real-Time Video Page
- ②share
- ③Cloud storage
- ④View events
- ⑤Set
- ⑥History playback date
- ⑦Full screen
- ⑧Historical playback
- ⑨video
- ⑩Hand-free/handset
- ⑪screenshot
- ⑫Album
- ⑬Two-way Interview




6.View events

Click to view the event to see someone push the doorbell, human body induction alarm push, alarm push, power push, and can also view the alarm video playback and other events.



⑥There is no positive or negative pole if AC power supply is needed through adapter board connection.



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

