


SOUNDPODS INSTRUCTION MANUAL

DO NOT PRINT THIS LAYER

PRINT BACK TO BACK

FOLDING INSTRUCTIONS



Front



SoundPods™

USER MANUAL



Introduction



- 1- Earbuds
- 2- Earbuds LED indicator
- 3- On/Off button
- 4- Charging case LED indicator
- 5- Charging case
- 6- Multi-function Button.

Pairing your earbuds



Take your earbuds out of the **Charging Case [5]**. The earbuds will automatically turn on and enter into pairing mode and the earbuds **LED lights[2]** will alternately flash between red and blue.

On your device, go to your Bluetooth settings.

Turn your device Bluetooth function on.

Choose **"SoundPods"** from your list of devices.

After the pairing is successful, the earbuds LED will flash blue.

ENJOY!!

To use only one earbud after both earbuds were paired

Simply put one of earbuds back in the charging case and the other earbud will keep working normally.

Turn on/off

To turn your earbuds **ON**:

- The Earbuds will automatically turned ON once taken out of the charging case.
- If the earbud is off press the **Multi-function [6]** button for 3 seconds to turn it ON.

To turn your earbuds **OFF**:

- The Earbuds will automatically turned OFF once placed back in the charging case.
- If the earbud is on press the **Multi-function [6]** button for 3 seconds to turn it OFF.

Bluetooth Functions

For the following functions use the **Multi-function [6]** button on the earbuds.

Calls Functions

- Short press** to answer a call.
- Short press** to hang up if you're in a call.
- Long press** (1.5 seconds) to refuse a call.
- Double click** to redial the last call (dialed or unanswered).

Listening to music Functions

- Short press** to Pause.
- Long press** for the next song.

Back

Charging your device



- To charge your **Earbuds[1]**: Place the earbuds in the **Charging Case[5]**. The earbuds **LED lights[2]** will turn **red** when the earbuds are charging. The earbuds **LED lights[2]** will turn **blue** once the earbuds are fully charged. When one of the earbuds has a **low battery** level, the lower battery tone will be issued every 30 seconds.
- To charge your **Charging Case[5]**: Plug in the charging case using the micro USB charging cable included. The Charging Case is fully charged when the **LED indicator[4]** has 4 lights.



Specifications

- Bluetooth version: V5.0
- Earbuds Battery Capacity: 40mAh each
- Charging Case Capacity: 300mAh
- Play Time: Up to 16hrs
- Earbuds Charging Time: About 1.5hrs
- Charging Case Time: 2hrs
- Charging Port: Micro USB

Package Includes

- 1- Pair of SoundPods Earbuds
- 1- Charging Dock
- 1- Charging Cable
- 1- User Manual

Attention:

1. Handle with care. Do not throw, sit on, or store the SoundPods under heavy objects. Keep away from high temperatures and environments with high humidity. Store in an environment with a temperature between -10°C – 60°C.
2. Keep away from high frequency transmitting equipment such as WIFI routers which may cause sound interference or disconnection.
3. Please keep the earbuds within a 10m (33 ft) range of the connected device.
4. This product is a compatible with both iOS® and Android™ devices.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution:

Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

© 2020 Zeikos, Inc. iHip is a trademark of Zeikos, Inc., iPod, iPhone and iPad are trademarks of Apple Inc., The "Android" name, the Android logo, and other trademarks are property of Google LLC. Registered in the U.S. and other countries. The illustrated product and specifications may differ slightly from that supplied. All other trademarks and trade names are those of their respective owners. United States and international patent pending. All Rights Reserved. For ages 12+. This is not a toy. Designed by iHip. Manufactured in China.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by "iHip" is under license. Other trademarks and trade names are those of their respective owners.

Limited One Time Warranty.
To activate your product warranty go to our website: www.iHip.com & register this product.



19 Progress St
Edison, NJ 08820
www.iHip.com



Find us on Facebook.
Keyword: iHip Portable Entertainment

