


SONOS



Wireless Charger
Important Product Information

THIS DOCUMENT CONTAINS INFORMATION THAT IS SUBJECT TO CHANGE WITHOUT NOTICE.

No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including but not limited to photocopying, recording, information retrieval systems, or computer network without the written permission of Sonos, Inc.

SONOS and all other Sonos product names and slogans are trademarks or registered trademarks of Sonos, Inc. SONOS Reg. U.S. Pat. & Tm. Off. Sonos products may be protected by one or more patents. Our patent-to-product information can be found here: **sonos.com/legal/patents**.

All other products and services mentioned may be trademarks or service marks of their respective owners.

040121

© 2004-2021 by Sonos, Inc. All rights reserved.

Terms of Use, License, Warranty, and Privacy

To use this Sonos product you have to accept the Sonos Terms of Use, License and Warranty Agreement, available at **www.sonos.com/legal/terms-of-use**. Sonos privacy statement is available at **www.sonos.com/legal/privacy**.

Guides

For the latest Sonos product documentation, please go to **www.sonos.com/guides**.

Customer Support

Visit our Web site at **www.sonos.com/support**. There you can browse our Knowledge Base or request assistance.

Note: If a red LED appears on the wireless charger, it indicates the presence of a foreign metal object or an internal fault. Go to **<https://faq.sonos.com/chargerlight>** to learn more.



[EN] To charge, just place Sonos Roam on the smooth, magnetized side of the wireless charger.

[DA] Sonos Roam oplades, ved at du sætter den på den glatte, magnetiske side af den trådløse oplader.

[DE] Zum Aufladen legst du den Sonos Roam einfach auf die glatte, magnetische Seite des kabellosen Ladegeräts.

[ES] Para cargarlo, coloca Sonos Roam sobre la superficie lisa y magnetizada del cargador inalámbrico.

[FR] Pour charger votre Sonos Roam, placez-le sur le côté lisse et magnétisé du chargeur sans fil.

[IT] Per ricaricare Sonos Roam, posizionalo sul lato liscio magnetico del caricabatterie wireless.

[NL] Om Sonos Roam op te laden, hoeft je hem alleen maar op de gladde, magnetische kant van de draadloze oplader te plaatsen.

[NO] For å lade, plasserer du bare Sonos Roam på den glatte, magnetiserte siden av den trådløse laderen.

[PL] Aby zacząć ładować, umieść Sonos Roam na gładkiej, magnetycznej stronie ładowarki bezprzewodowej.

[PT-BR] Para carregar, coloque o Sonos Roam no lado liso e magnetizado do carregador sem fio.

[SE] För att ladda Sonos Roam, placera den på den släta, magnetiserade sidan av den trådlösa laddaren.

[CN] 要充电，只需将 Sonos Roam 放在无线充电器光滑且有磁性的一侧。

[JP] 充電するには、Sonos Roam をワイヤレス充電器のつるとした着磁面側に置いてください。

Regulatory Information



Available at: <https://www.sonos.com/support/policies>

Declaration of Conformity

Hereby, Sonos, Inc. declares that the model name: LPS-05WB-I is in compliance with Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at: <https://www.sonos.com/support/policies>.

This device operates at -10.70dBuA/m (H-Field Strength) in WPC112-148kHz frequency range (MHz). This device operates at maximum transmit power (dBm/mW) at -0.08dBm (0.00098W) at BLE frequency range.

Canada

The installer of this radio equipment must ensure that the product is located such that it does not emit RF field in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's Web site www.hc-sc.gc.ca/rpb. As mentioned before, the installer cannot control the antenna orientation. However, they could place the complete product in a way that causes the problem mentioned above.

This class B digital apparatus complies with ISED CAN ICES 003(B) / NMB-003(B), RSS-GEN, RSS-216, and RSS-247. This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

L'installateur du présent matériel radio doit veiller à ce que le produit soit placé ou orienté de manière à n'émettre aucun champ radioélectrique supérieur aux limites fixées pour le grand public par le ministère fédéral Santé Canada consultez le Code de sécurité 6 sur le site Web de Santé Canada à l'adresse : www.hc-sc.gc.ca/rpb. Comme indiqué auparavant, l'installateur ne peut pas contrôler l'orientation de l'antenne. Il peut néanmoins placer le produit tout entier de manière à provoquer le problème décrit ci-dessus.

Cet appareil numérique de classe B est conforme à ISED CAN ICES 003(B) / NMB-003(B), à RSS-GEN, à RSS-216 et à RSS-247. L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement

économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Exposure Requirements (MPE)

To comply with FCC and Industry Canada and CE exposure essential requirements, this equipment should be installed and operated with minimum distance 20cm (8 inches) between the radiator & your body. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician to help.

Exigences en matière d'exposition aux radiofréquences

Pour satisfaire aux exigences essentielles de la FCC et d'Industrie Canada concernant l'exposition, une distance minimum de 20 cm (8 pouces) doit être respectée entre l'équipement et l'utilisateur ou des personnes se trouvant à proximité.

Recycling Information



This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead please deliver it to the applicable collection point for the recycling of electrical and electronic equipment. By recycling this product correctly, you will help conserve natural resources and prevent potential negative environmental consequences. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

BLE Advertising Timing and Interval

The BLE radio shall not transmit any packets when no device is receiving power from the wireless charger. The BLE radio shall begin transmitting advertising packets within 1 second of a device placed on the wireless charger. The BLE radio shall stop transmitting 60 seconds +/- 1 seconds after a device is placed on the wireless charger. The BLE radio shall transmit advertising packets at a frequency of 2 Hz.

Nom 024 information (Mexico only)

Información para Nom 024 (unicamente para Mexico)

EU	Mexico
Importer name/address	Nombre / dirección del importador
Company: Sonos Inc.	Company: Viastara SA de CV
Address: 614 Chapala Street, Santa Barbara, CA 93101	Address: Blvd. Adolfo López Mateos 261, Ampliación Los Alpes, Álvaro Obregón, 01010
Contact name: Zibo Nelson	Ciudad de México, CDMX, Mexico
Contact TEL no: (+1) 805 965 3001	Contact name: Jesus Ledesma
	Email : jesusledesma@viastara.com
	Grupo de Desarrollo Inteligente. (a.k.a. Inteligos)
	Address: Blvd. Rogelio Cantú Gómez 370, Santa María, 64650 Monterrey, N.L., Mexico:
	Contact: Flavia Canamar
	email: falvia.canamar@inteligos.com

Equipment Brand Name	Equipo Nombre de la marca	Wireless Charger Sonos
Model Name	Nombre del modelo	LPS-05WB-I
Customer Service Center	Centro de atención al cliente	Sonos, Inc. 614 Chapala St. Santa Barbara, CA 93101 1 (800) 680-2345 www.sonos.com
Sonos Terms of Use, License and Warranty Agreement	Acuerdo de licencia y garantía y condiciones de uso	www.sonos.com/legal/terms-of-use
Input	Entrada	5V +/- 5%, 2.1 A max, 10.2 W max
Output	Salida	5 V max, 1 A max, 5 W max
Weight	Peso	75 gm
Operating Temperature	Temperatura de funcionamiento	De 0 °C a 40 °C (de 32 °F a 104 °F)

产品中有毒有害物质或元素的名称及含量 The Table of Toxic and Hazardous Substances and Concentration

按照中国《电子信息产品污染控制管理办法》的要求

In accordance with the requirement of China's Management Methods for Controlling Pollution by Electronic Information Products

有害物质的名称及含量表 Toxic and Hazardous Substances and Concentration

	铅	汞	镉	六价铬	多溴联苯	多溴二苯醚
部件名称 (Parts)	Pb Lead	Hg Mercury	Cd Cadmium	Cr6+ Hexavalent Chromium	PBB Polybrominated Biphenyls	(PBDE) Polybrominated Diphenyl Ethers
电线与附件 (Cables & Accessories)	X	O	O	O	O	O
包装 (Packaging)	O	O	O	O	O	O

O: 表示该有毒有害物质在该部件所有均质材料中的含量均在 GB/T 26572-2011 标准规定的限量要求以下。

O: Indicates that the concentration of the hazardous substance in all homogeneous materials in the parts is below the relevant threshold of the GB/T 26572-2011 standard.

X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572-2011 标准规定的限量要求。

X: Indicates that the concentration of the hazardous substance of at least one of all homogeneous materials in the parts is above the relevant threshold of the GB/T 26572-2011 standard.



所有 Sonos 的产品有 10 年的“环保使用期限”(EPUP)。

All Sonos products have an EPUP "environment protection use period" of 10 years.

此表中带 X 命名的所有部件都符合欧盟 RoHS II 2011/65/EU 指令。

All parts named in this table with an X are in compliance with the European Union RoHS II Directive 2011/65/EU.

(معلومات مهمة للسلامة) العربية)

1. اقرأ هذه الإرشادات.
2. احتفظ بهذه الإرشادات.
3. انتبه إلى جميع التحذيرات.
4. اتبع جميع الإرشادات.
5. لا تستخدم إلا قطعة قماش ناعمة وجافة لتنظيف هذا الجهاز؛ حيث إن المنظفات المنزلية أو المذيبات قد تلحق ضرراً بالطلاء الخارجي لمكونات Sonos.
6. لا تقم بالتركيبة بالقرب من أية مصادر حرارية كالمبردات أو شفاطات الحرارة أو المواقد أو أي جهاز آخر تبعث منه حرارة.
7. احرص على ألا يمشي أحد أو يضغط فوق كبل الطاقة، خاصة فوق مقابس التوصيل ومقابس الملاءمة وموقع خروجها من الجهاز.
8. لا تستخدم إلا المرفقات/الملحقات التي حددتها جهة التصنيع.
9. افصل هذا الجهاز عن مصدر التيار الكهربائي أثناء العواصف الرعدية أو عند عدم استخدامه لفترات زمنية طويلة.

5. Maak de apparaten alleen schoon met een droge, zachte doek. Huishoudelijke schoonmaak- of oplosmiddelen kunnen de afwerking van Sonos-componenten beschadigen.
6. Installeer apparaten niet in de buurt van warmtebronnen, zoals radiatoren, ventilatieroosters, kachels of andere apparaten die warmte afgeven.
7. Zorg ervoor dat er niet over het netsnoer kan worden gelopen en dat dit niet bekneeld kan raken, vooral niet bij de stekkers, bij stopcontacten en op het punt waar de snoeren het apparaat verlaten.
8. Gebruik alleen door de fabrikant gespecificeerde accessoires.
9. Haal bij onweer of als u het apparaat gedurende een lange periode niet gebruikt, de stekker uit het stopcontact.
10. Laat alle onderhoud uitvoeren door gekwalificeerd onderhoudspersoneel van Sonos. Onderhoud is nodig wanneer het apparaat schade heeft opgelopen, bijvoorbeeld wanneer een netsnoer of stekker is beschadigd, vloeistof of een voorwerp in het apparaat is terechtgekomen, het apparaat is blootgesteld aan regen of vocht, het apparaat niet naar behoren functioneert of het apparaat op de grond is gevallen.
11. De stekker in het stopcontact moet gemakkelijk bereikbaar zijn om de stroomvoorziening af te kunnen sluiten.

EULA en privacyverklaring

Voor gebruik van dit Sonos-product moet je de gebruiksvoorwaarden, licentie- en garantie-overeenkomst accepteren die je vindt op [**www.sonos.com/legal/terms-of-use**](http://www.sonos.com/legal/terms-of-use). Je vindt de privacyverklaring van Sonos op [**www.sonos.com/legal/privacy**](http://www.sonos.com/legal/privacy).

Important Safety Information (English)

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Clean only with dry soft cloth. Household cleaners or solvents can damage the finish on your Sonos products.

6. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
7. Protect the power cable from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
8. Only use attachments/accessories specified by the manufacturer.
9. Unplug this apparatus during lightning storms or when unused for long periods of time.
10. Refer all servicing to Sonos qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cable or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
11. The Mains plug should be readily available to disconnect the equipment.

Terms of Use, License, Warranty, and Privacy

To use this Sonos product you have to accept the Sonos Terms of Use, License and Warranty Agreement, available at [**www.sonos.com/legal/terms-of-use**](http://www.sonos.com/legal/terms-of-use). Sonos privacy statement is available at [**www.sonos.com/legal/privacy**](http://www.sonos.com/legal/privacy).

Oluline ohutusalaane informatsioon (Eesti keel)

1. Lugege juhised läbi.
2. Hoidke need kättesaadavas kohas.
3. Pöörake tähelepanu kõigile hoiatustele.
4. Järgige kõiki juhiseid.
5. Puhastage ainult kuiva ja pehme riidest lapiga. Majapidamises kasutatavad puhastusvahendid või lahustid võivad Sonose detailide viimistlust vigastada.
6. Ärge paigaldage soojusallikate (nagu näiteks radiaatorid, küttekanalite avad, ahjud või muud soojusallikad) lähedusse.
7. Asetage toitekaabel nii, et sellele ei astutaks peale ega sellele ei avaldataks survet, eriti pistikute ja pistikupesade juures ning kohas, kus kaabel väljub seadmest.



610-00076 Rev C
Sonos, Inc.