



Gebruikershandleiding Smartwatch S11



Lees de instructies voor gebruik

INHOUD

- 
- 1 UITERLIJK INTRODUCTIE
 - 2 OPLADEN EN OPSTARTEN
 - 3 APP DOWNLOADEN
 - 4 VERBINDEN
 - 5 FUNCTIES INTRODUCTIE
 - 6 ALGEMENE PROBLEMEN
 - 7 ONDERHOUD
 - 8 GARANTIE

01

Uiterlijk
introductie




Knop
Lang inhouden om op te starten,
of af te sluiten
1 keer drukken om terug te gaan

- ⦿ De armband is gemaakt van duurzame materialen
- ⦿ Als de huid tijdens het dragen vervelend aanvoelt, doe dan de watch af en raadpleeg een arts

02

Opladen
en opstarten



Laad het product voor gebruik meer dan twee uur op. Zorg dat de oplader goed op de metalen poorten zitten. Zodra er een oplaadindicator op het scherm verschijnt begint de watch met opladen.

- ⦿ Gebruik de speciale oplaadkabel die bij het pakket wordt geleverd. Houd de oplaadpoort vrij en droog.
- ⦿ Opmerking: gebruik geen voedingsadapter met een output van meer dan 5V 1A om op te laden, anders kan het circuit doorbranden, waardoor het opladen niet meer mogelijk is.



① Scan de QR-code rechts met uw mobiele telefoon of ga naar de APP Store om GloryFit te downloaden en te installeren. Geef deze software de bijbehorende machtigingen om ervoor te zorgen dat de Bluetooth verbinding optimaal is.



04

Koppelen

- ①Open de APP en voegde watch die je wilt verbinden toe aan de APP. Bevestig bij het koppelen dat de Bluetooth adressen die worden weergegeven op de APP en de watch hetzelfde zijn. (Je kunt het Bluetooth adres van de watch controleren in de instellingen)
- ②Zorg er tijdens het koppelen voor dat de Bluetooth van de mobiele telefoon is ingeschakeld en dat de watch dicht bij de mobiele telefoon is om verbinding te maken. Nadat het koppelen is gelukt, kunt u de verbindingstatus controleren in de keuzelijst van de watch.



De armband ondersteunt aanraken op volledig scherm, omhoog vegen, omlaag vegen, naar links vegen, naar rechts vegen, lang indrukken en andere bewerkingen, veeg op het scherm om verschillende functies te bekijken; u kunt ook op het scherm klikken en lang drukken voor gerelateerde bewerkingen.

De armband ondersteunt functies zoals trainingsmonitoring, hartslagmonitoring en berichtherinnering en meer.



①App kan het apparaat niet vinden

Antwoord: Probeer eerst op de aan/uit knop te drukken, als het scherm niet verlicht is, kunt u het apparaat op de oplader aansluiten om op te laden, om er zeker van te zijn dat er stroom is.

②Het apparaat wordt herhaaldelijk aangesloten en losgekoppeld

Antwoord: Mobiele telefoons van verschillende merken zullen automatisch het achtergrondprogramma van de mobiele telefoon opschonen. U moet de APP toevoegen aan de betrouwbaar lijst van de mobiele telefoon of zelfstartbeheer.

③Het apparaat kan niet worden opgeladen

Antwoord: Zit er vuil, corrosie, etc. op de oplaadplaats? Alleen door middel van volledig contact tussen de USB-interface en de oplaadkop kan er met succes worden opgeladen.



- ① Draag geen smartwatch bij het baden, zwemmen of andere wateractiviteiten
- ② Stel de smartwatch niet langdurig bloot aan een plaats met veel vocht, hoge temperaturen of lage temperaturen
- ③ Vermijd kamers met veel stof zoals laboratorium, lichte industriestudio, stofomstandigheden in opslagruimten.
- ④ De smartwatch is gecrasht en opnieuw opgestart. Controleer of wis de geheugeninformatie van de telefoon en probeer het opnieuw of herstart de APP.

The Life Style Goods behoudt zich het recht om de inhoud van deze handleiding zonder enige kennisgeving te wijzigen. Sommige functies zijn anders in specifieke softwareversies.





Garantie kaart			
Klant informatie			
Model		Leverancier	(TLSG)
Klantnaam		Contact nr.	
Leverancier nr.		Besteldatum	
Klantadres			
Leverancier adres			
Omschrijving			
Datum	Probleem	Diagnose	Opmerking



User manual

Smartwatch S11



Read the instructions before use

CONTENTS

- 
- 1 APPEARANCE INTRODUCTION
 - 2 CHARGING AND START UP
 - 3 APP DOWNLOAD
 - 4 BINDING
 - 5 FUNCTIONS INTRODUCTION
 - 6 COMMON PROBLEM
 - 7 MAINTENANCE
 - 8 WARRANTY CARD

01

Appearance
introduction




Long press to start up
/shut down,
Short press return

- ◎The bracelet is made of healthy materials, please be assured to use.
- ◎Due to individual differences, if skin feels uncomfortable while wearing, please stop wearing and consult the doctor

02

Charging
and start up



Please charge the product for more than two hours before use. Align the charging port with the metal contacts on the charging base until the charging indicator appears on the bracelet screen.

- Please use the special charging cable that comes with the package, Keep charging port clear and dry.
- Note: Do not use a power adapter with an output of more than 5V 1A to charge, otherwise the circuit may be burned, resulting in no charging.



① Scan the QR code on the right with your mobile phone Or Go to APP Store to download and install GloryFit, Please give this software the corresponding permissions, to ensure that the Bluetooth connection is normal.



04

Binding

①Open the APP and add the bracelet device you want to connect in the APP. When binding, please confirm that the Bluetooth addresses displayed on the APP and the bracelet are the same. (You can check the Bluetooth address of the bracelet in the bracelet settings)

②When pairing, make sure that the Bluetooth of the mobile phone is turned on, and the bracelet needs to be close to the mobile phone to connect. After the pairing is successful, you can check the connection status in the pull-down notification bar of the bracelet.



The bracelet supports full-screen touch, slide up, slide down, slide left, slide right, long press and other operations, slide the screen to switch to view various functions; you can also click and long press the screen for related operations.

The bracelet supports functions such as exercise monitoring, heart rate monitoring, and message reminder etc.





①App can't search the device

Answer: Please try to press the device button first, if the screen is not lit, you can connect the device to the charger to charge, to ensure that there is power.

②The device is repeatedly connected and disconnected

Answer: Mobile phones of different brands will automatically clean up the mobile phone background program. You need to add the APP to the mobile phone white list or self-start management.

③The device cannot be charged

Answer: Is there any dirt, corrosion, etc. in the charging place? Only the full contact between the USB interface and the charging head can charge successfully.



- ① Do not wear bracelets for bathing, swimming or other water activities
- ② Do not expose the bracelet to a place with high moisture, high temperature or low temperature for long time
- ③ Can prevent such as living room, office, laboratory, light industry studio, storage room dust conditions, not suitable for special dust environment.
- ④ The bracelet has crashed and restarted. Please check the phone's memory information to clear and try again, or quit the APP and open it again.

The Life Style Goods reserves the right to modify the contents of this manual without any notice. Some functions are different in specific software versions, which is normal.





Warranty card			
Client information			
Model		Vendor	(stamp)
Client name		Contact no.	
Supplier Tel		Purchase date	
Client address			
Supplier address			
Description			
Date	Problems	Diagnosis	Note