




MODEL: TT-BH070
TAOTRONICS SOUNDELITE 70
WIRELESS STEREO EARPHONES
User Guide



EN

Package Contents

- 1 x TaoTronics Wireless Stereo Earphones
- 1 x USB Charging Cable
- 6 x Ear Buds (two are equipped on the headphones)
- 6 x Ear Hooks (two are equipped on the headphones)
- 1 x Travel Pouch
- 1 x User Guide

DE

Lieferumfang

- 1 x TaoTronics Kabellose Stereo Kopfhörer
- 1 x USB-Ladekabel
- 6 x Ohrstöpsel (ein Paar kommt bereits an den Kopfhörern)
- 6 x Ohrbügel (ein Paar kommt bereits an den Kopfhörern)
- 1 x Reiseetui
- 1 x Bedienungsanleitung

FR

Contenu du Package

- 1 x Écouteurs Stéréo Sans Fil TaoTronics
- 1 x Câble de Charge USB
- 6 x Oreillettes (deux sont déjà installées sur les écouteurs)
- 6 x Crochets d'Oreille (deux sont déjà installés sur les écouteurs)
- 1 x Pochette de Transport
- 1 x Guide d'Utilisation

ES

Contenido del paquete

- 1 x Auriculares estéreo inalámbricos TaoTronics
- 1 x Cable de carga USB
- 6 x Tapones (dos están equipados en los auriculares)
- 6 x Ganchos de oído (dos están equipados en los auriculares)
- 1 x Bolsa de viaje
- 1 x Manual del usuario

IT

Contenuto della Confezione

- 1 x TaoTronics Auricolari Stereo Bluetooth
- 1 x Cavo di Ricarica USB
- 6 x Gommini Auricolari (2 presenti sugli auricolari)
- 6 x Ganci Auricolari (2 presenti sugli auricolari)
- 1 x Custodia
- 1 x Guida Utente

JP

同梱物

- 1 x TaoTronics ワイヤレスステレオイヤホン
- 1 x USB 充電ケーブル
- 6 x イヤーピース (内2つは既にイヤホンに装着されています)
- 6 x イヤーフック (うち2つはイヤホンに装着済)
- 1 x トラベルポーチ
- 1 x 取扱説明書

IT

Schema del Prodotto

1. Volume + /Traccia Successiva
2. Tasto Multifunzione
3. LEDインジケター
4. Volume - /Traccia Precedente
5. Microfono
6. Porta di Ricarica Micro-USB

EN

Product Diagram

1. Volume+/Next Track
2. Multifunction Button
3. LED Indicator
4. Volume-/Previous Track
5. Microphone
6. Micro USB Charging Port

FR

Description du Produit

1. Volume+/Piste Suivante
2. Bouton Multifonction
3. Voyant à LED
4. Volume-/Piste Précédente
5. Micro
6. Port de Charge Micro-USB

IT

Schema del Prodotto

1. Volume + /Traccia Successiva
2. Tasto Multifunzione
3. LEDインジケター
4. Volume - /Traccia Precedente
5. Microfono
6. Porta di Ricarica Micro-USB

ES

Diagrama del producto

1. Volumen + / Pista siguiente
2. Botón multifunción
3. Indicador LED
4. Volumen - / pista anterior
5. Micrófono
6. Puerto de carga micro USB

JP

製品図

1. 音量+ /次の曲
2. 多機能ボタン
3. LEDインジケター
4. 音量- /前の曲
5. マイク
6. Micro USB ポート

EN

How to Use

1. Charging

- 1) Connect the charging port with any USB charging adapter or active computer USB port.
- 2) Charging will start automatically with the LED indicator turning red.
- 3) The headphones are fully charged when the LED indicator turns blue.

Note:

- Charge the headphones at least once every 6 months when not using for a long time.
- Make sure the battery is fully charged before putting the headphones away for storage.

2. Pairing

- 1) Make sure the headphones and your Bluetooth® device are next to each other (within 3 feet / 1 meter).
- 2) The first time you use the headphones, press and hold the Multifunction Button until the LED indicator flashes red and blue alternately. Now the headphones is in pairing mode.
- 3) Activate Bluetooth® function on your phone and search for the nearby Bluetooth® connection: Find "TAOTRONICS SoundElite 70" in the search results. Tap on the name to connect. Once connected, only the blue LED will flash.

DE

Bedienungsanleitung

1. Aufladen

- 1) Verbinden Sie den Ladeanschluss mit irgendeinem USB-Ladeadapter oder aktivem Computer via USB-Anschluss.
- 2) Der Ladeprozess wird automatisch gestartet und die LED-Anzeige wird rot leuchten.
- 3) Die Kopfhörer sind vollständig aufgeladen, wenn die LED-Anzeige blau leuchtet.

Anmerkung:

- Laden Sie die Kopfhörer mindestens alle sechs Monate auf, wenn Sie sie für eine längere Zeit nicht benutzen.
- Stellen Sie sicher, dass der Akku vollständig geladen ist, bevor Sie die Kopfhörer zum Lagern verstauen.

2. Kopplung

- 1) Stellen Sie sicher, dass die Kopfhörer und Ihr Bluetooth®-Gerät sich nah beieinander befinden (innerhalb von 1 Meter).
- 2) Wenn Sie die Kopfhörer das erste Mal benutzen, halten Sie den Multifunktionsknopf gedrückt, bis die LED-Anzeige abwechselnd rot und blau leuchtet. Die Kopfhörer befinden sich jetzt im Kopplungsmodus.
- 3) Aktivieren Sie die Bluetooth®-Funktion auf Ihrem Smartphone und suchen Sie nach Bluetooth®-Verbindungen in der Nähe: Wählen Sie "TAOTRONICS SoundElite 70" aus der Liste aus. Sobald die Verbindung besteht, blinkt die LED nur blau.

FR

Mode d'Emploi

1. Chargement

- 1) Connectez le port de charge à un adaptateur USB ou un port USB d'ordinateur actif.
- 2) Le chargement va démarrer automatiquement et le voyant à LED deviendra rouge.
- 3) Les écouteurs seront entièrement chargés quand le voyant à LED devient bleu.

Remarque:

- Chargez les écouteurs au minimum une fois tous les 6 mois si vous ne les utilisez pas dans une longue période.
- Assurez-vous que la batterie est complètement chargée avant de ranger les écouteurs pour le stockage.

2. Couplage

- 1) Assurez-vous que les écouteurs et votre appareil Bluetooth® soient à proximité l'un de l'autre (à moins d'un mètre).
- 2) La première fois que vous utilisez les écouteurs, appuyez et maintenez le Bouton Multifonction jusqu'à ce que le voyant à LED clignote rouge et bleu alternativement. Les écouteurs sont maintenant en mode de couplage.
- 3) Activez la fonction Bluetooth® sur votre téléphone et cherchez les connexions Bluetooth® à proximité : localisez "TAOTRONICS SoundElite 70" dans les résultats de la recherche. Cliquez dessus pour établir la connexion. Une fois connecté, le voyant à LED clignotera lentement en bleu.

DE

Bedienungsanleitung

1. Aufladen

- 1) Verbinden Sie den Ladeanschluss mit irgendeinem USB-Ladeadapter oder aktivem Computer via USB-Anschluss.
- 2) Der Ladeprozess wird automatisch gestartet und die LED-Anzeige wird rot leuchten.
- 3) Die Kopfhörer sind vollständig aufgeladen, wenn die LED-Anzeige blau leuchtet.

Anmerkung:

- Laden Sie die Kopfhörer mindestens alle sechs Monate auf, wenn Sie sie für eine längere Zeit nicht benutzen.
- Stellen Sie sicher, dass der Akku vollständig geladen ist, bevor Sie die Kopfhörer zum Lagern verstauen.

2. Kopplung

- 1) Stellen Sie sicher, dass die Kopfhörer und Ihr Bluetooth®-Gerät sich nah beieinander befinden (innerhalb von 1 Meter).
- 2) Wenn Sie die Kopfhörer das erste Mal benutzen, halten Sie den Multifunktionsknopf gedrückt, bis die LED-Anzeige abwechselnd rot und blau leuchtet. Die Kopfhörer befinden sich jetzt im Kopplungsmodus.
- 3) Aktivieren Sie die Bluetooth®-Funktion auf Ihrem Smartphone und suchen Sie nach Bluetooth®-Verbindungen in der Nähe: Wählen Sie "TAOTRONICS SoundElite 70" aus der Liste aus. Sobald die Verbindung besteht, blinkt die LED nur blau.

FR

Mode d'Emploi

1. Chargement

- 1) Connectez le port de charge à un adaptateur USB ou un port USB d'ordinateur actif.
- 2) Le chargement va démarrer automatiquement et le voyant à LED deviendra rouge.
- 3) Les écouteurs seront entièrement chargés quand le voyant à LED devient bleu.

Remarque:

- Chargez les écouteurs au minimum une fois tous les 6 mois si vous ne les utilisez pas dans une longue période.
- Assurez-vous que la batterie est complètement chargée avant de ranger les écouteurs pour le stockage.

2. Couplage

- 1) Assurez-vous que les écouteurs et votre appareil Bluetooth® soient à proximité l'un de l'autre (à moins d'un mètre).
- 2) La première fois que vous utilisez les écouteurs, appuyez et maintenez le Bouton Multifonction jusqu'à ce que le voyant à LED clignote rouge et bleu alternativement. Les écouteurs sont maintenant en mode de couplage.
- 3) Activez la fonction Bluetooth® sur votre téléphone et cherchez les connexions Bluetooth® à proximité : localisez "TAOTRONICS SoundElite 70" dans les résultats de la recherche. Cliquez dessus pour établir la connexion. Une fois connecté, le voyant à LED clignotera lentement en bleu.

FR

Mode d'Emploi

1. Chargement

- 1) Connectez le port de charge à un adaptateur USB ou un port USB d'ordinateur actif.
- 2) Le chargement va démarrer automatiquement et le voyant à LED deviendra rouge.
- 3) Les écouteurs seront entièrement chargés quand le voyant à LED devient bleu.

Remarque:

- Chargez les écouteurs au minimum une fois tous les 6 mois si vous ne les utilisez pas dans une longue période.
- Assurez-vous que la batterie est complètement chargée avant de ranger les écouteurs pour le stockage.

2. Couplage

- 1) Assurez-vous que les écouteurs et votre appareil Bluetooth® soient à proximité l'un de l'autre (à moins d'un mètre).
- 2) La première fois que vous utilisez les écouteurs, appuyez et maintenez le Bouton Multifonction jusqu'à ce que le voyant à LED clignote rouge et bleu alternativement. Les écouteurs sont maintenant en mode de couplage.
- 3) Activez la fonction Bluetooth® sur votre téléphone et cherchez les connexions Bluetooth® à proximité : localisez "TAOTRONICS SoundElite 70" dans les résultats de la recherche. Cliquez dessus pour établir la connexion. Une fois connecté, le voyant à LED clignotera lentement en bleu.

FR

Mode d'Emploi

1. Chargement

- 1) Connectez le port de charge à un adaptateur USB ou un port USB d'ordinateur actif.
- 2) Le chargement va démarrer automatiquement et le voyant à LED deviendra rouge.
- 3) Les écouteurs seront entièrement chargés quand le voyant à LED devient bleu.

Remarque:

- Chargez les écouteurs au minimum une fois tous les 6 mois si vous ne les utilisez pas dans une longue période.
- Assurez-vous que la batterie est complètement chargée avant de ranger les écouteurs pour le stockage.

2. Couplage

- 1) Assurez-vous que les écouteurs et votre appareil Bluetooth® soient à proximité l'un de l'autre (à moins d'un mètre).
- 2) La première fois que vous utilisez les écouteurs, appuyez et maintenez le Bouton Multifonction jusqu'à ce que le voyant à LED clignote rouge et bleu alternativement. Les écouteurs sont maintenant en mode de couplage.
- 3) Activez la fonction Bluetooth® sur votre téléphone et cherchez les connexions Bluetooth® à proximité : localisez "TAOTRONICS SoundElite 70" dans les résultats de la recherche. Cliquez dessus pour établir la connexion. Une fois connecté, le voyant à LED clignotera lentement en bleu.

FR

Mode d'Emploi

1. Chargement

- 1) Connectez le port de charge à un adaptateur USB ou un port USB d'ordinateur actif.
- 2) Le chargement va démarrer automatiquement et le voyant à LED deviendra rouge.
- 3) Les écouteurs seront entièrement chargés quand le voyant à LED devient bleu.

Remarque:

- Chargez les écouteurs au minimum une fois tous les 6 mois si vous ne les utilisez pas dans une longue période.
- Assurez-vous que la batterie est complètement chargée avant de ranger les écouteurs pour le stockage.

2. Couplage

- 1) Assurez-vous que les écouteurs et votre appareil Bluetooth® soient à proximité l'un de l'autre (à moins d'un mètre).
- 2) La première fois que vous utilisez les écouteurs, appuyez et maintenez le Bouton Multifonction jusqu'à ce que le voyant à LED clignote rouge et bleu alternativement. Les écouteurs sont maintenant en mode de couplage.
- 3) Activez la fonction Bluetooth® sur votre téléphone et cherchez les connexions Bluetooth® à proximité : localisez "TAOTRONICS SoundElite 70" dans les résultats de la recherche. Cliquez dessus pour établir la connexion. Une fois connecté, le voyant à LED clignotera lentement en bleu.

FR

Mode d'Emploi

1. Chargement

- 1) Connectez le port de charge à un adaptateur USB ou un port USB d'ordinateur actif.
- 2) Le chargement va démarrer automatiquement et le voyant à LED deviendra rouge.
- 3) Les écouteurs seront entièrement chargés quand le voyant à LED devient bleu.

Remarque:

- Chargez les écouteurs au minimum une fois tous les 6 mois si vous ne les utilisez pas dans une longue période.
- Assurez-vous que la batterie est complètement chargée avant de ranger les écouteurs pour le stockage.

2. Couplage

- 1) Assurez-vous que les écouteurs et votre appareil Bluetooth® soient à proximité l'un de l'autre (à moins d'un mètre).
- 2) La première fois que vous utilisez les écouteurs, appuyez et maintenez le Bouton Multifonction jusqu'à ce que le voyant à LED clignote rouge et bleu alternativement. Les écouteurs sont maintenant en mode de couplage.
- 3) Activez la fonction Bluetooth® sur votre téléphone et cherchez les connexions Bluetooth® à proximité : localisez "TAOTRONICS SoundElite 70" dans les résultats de la recherche. Cliquez dessus pour établir la connexion. Une fois connecté, le voyant à LED clignotera lentement en bleu.

ASIA PACIFIC

E-mail: support.jp@taotronics.com(JP)
JP Importer: 株式会社SUNVALLEY JAPAN
Address: 〒104-0032 東京都中央区八丁堀3丁目18-6 PMO京橋東9F

EUROPE

E-mail:
support.uk@taotronics.com(UK)
support.de@taotronics.com(DE)
support.fr@taotronics.com(FR)
support.es@taotronics.com(ES)
support.it@taotronics.com(IT)
EU Importer: ZBT International Trading GmbH
Address: Halstenbeker Weg 98C, 25462 Rellingen, Deutschland

NORTH AMERICA

E-mail: support@taotronics.com(US)
support.ca@taotronics.com(CA)
Tel: 1-888-456-8468 (Monday-Friday: 9:00 - 17:00 PST)

MANUFACTURER

Shenzhen NearbyExpress Technology Development Co.,Ltd.
Address: 333 Bulong Road, Shenzhen, China, 518129
Learn more about the EU Declaration of Conformity:
<https://www.taotronics.com/downloads-TT-BH070-CE-Cert.html>

ES

Cómo utilizarlos

1. Carga

- 1) Conecte el puerto de carga con cualquier adaptador de carga USB o a un puerto USB de un ordenador encendido.
- 2) La carga comenzará automáticamente cuando el indicador del LED se pondrá en rojo.
- 3) Los auriculares están completamente cargados cuando el indicador LED se vuelve azul.

Nota:

- Cargue los auriculares al menos una vez cada 6 meses cuando no lo utilice durante mucho tiempo.
- Asegúrese de que la batería está completamente cargada antes de guardarlos.

2. Emparejamiento

- 1) Asegúrese de que los auriculares y el dispositivo Bluetooth® estén uno al lado del otro (a menos de 3 pies / 1 metro).
- 2) La primera vez que utilice los auriculares, mantenga pulsado el botón multifunción hasta que el indicador LED parpadee en rojo y azul alternativamente. Ahora los auriculares están en modo de emparejamiento.
- 3) Active la función Bluetooth® en su teléfono y busque la conexión Bluetooth® cercana: Encuentre "TAOTRONICS SoundElite 70" en los resultados de búsqueda. Toque en el nombre para conectarse. Una vez conectado, el LED azul parpadeará.

Nota:

- Emparejamiento Automático: Los Articulares Bluetooth® pueden recordar dispositivos emparejados previamente. Simplemente encienda los auriculares y el dispositivo (con Bluetooth® activado), y se conectarán al último dispositivo conectado automáticamente sin entrar en modo de emparejamiento.

3. Modo EQ

Presione los botones de Multifunción y Volumen + al mismo tiempo para ajustar los modos de EQ incorporados (3 modelos en total).


4. Borrar Historial De Emparejamiento

- 1) Si los auriculares no pueden emparejarse con su dispositivo Bluetooth®, borre el historial de emparejamiento dejando presionado los Botones de Volumen + y Volumen - al mismo tiempo, el indicador LED parpadeará indicado que el historial se ha borrado exitosamente. Vuelva a emparejar su dispositivo Bluetooth® como se indica en la sección anterior.
- 2) Si quiere emparejar los auriculares ya emparejados con otro dispositivo, desactive la función Bluetooth® del dispositivo emparejado o elimine "TAOTRONICS SoundElite 70" de la lista de conexiones Bluetooth.

Como ponérselos

Por favor use los auriculares como se muestra en el diagrama:

- 1) Coloque los ganchos de oreja en los auriculares.
- 2) Use los auriculares y los ganchos en sus oídos y regúlelos para un mejor ajuste.



IT

Funzionamento

1. Come Ricaricare

- 1) Connettere la porta micro-USB degli auricolari con un adattatore USB o alla porta USB del computer.
- 2) La ricarica inizierà automaticamente e l'indicatore LED diverrà rosso.
- 3) L'indicatore diverrà blu quando gli auricolari sono carichi.

Nota:

- Ricaricare gli auricolari almeno una volta ogni 6 mesi per periodi di inutilizzo prolungato.
- Assicurarsi che la batteria sia completamente carica prima della perservazione delle cuffie.

2. Come Connettere

- 1) Assicurarsi che gli auricolari ed il dispositivo Bluetooth® siano entro 1 metro/3 piedi di distanza.
- 2) Tenere premuto il Tasto Multifunzione fino a che l'indicatore LED non lampeggi rosso e blu la prima volta che si utilizzano gli auricolari perché questi entrino in modalità d'associazione.
- 3) Attivare la funzione Bluetooth® del proprio dispositivo e cercare i dispositivi Bluetooth® disponibili nelle vicinanze: selezionare "TAOTRONICS SoundElite 70" tra la lista dei risultati. Una volta connessi, la luce blu del LED di notifica lampeggerà.

JP

使い方

1. 充電



















- 1) USB充電アダプタまたはコンピュータのUSBポートを充電ポートに接続します。
- 2) LEDインジケータが赤色になると自動的に充電が開始されます。
- 3) イヤホンはLEDインジケータが青色になると完全に充電されます。

注:

- 長時間使用しない場合でも、6ヶ月に1回はイヤホンを充電してください。
- 長時間ご使用にならない場合でも 一度フル充電されてください。

4. Cancellare lo Storico degli Accoppiamenti

- 1) Se le cuffie non riescono a collegarsi ad un dispositivo Bluetooth®, cancellare lo storico degli accoppiamenti premendo e tenendo premuti i Pulsanti Volume + e Volume - contemporaneamente quando le cuffie sono accese, finché l'indicatore LED lampeggerà due volte di viola ad indicare che la pulizia è avvenuta con successo. A questo punto, accoppiare nuovamente il dispositivo Bluetooth® come spiegato nella sezione Accoppiamento.
- 2) Se si vuole accoppiare la cuffie con un altro dispositivo quando queste sono già accoppiate, disattivare la funzione Bluetooth® sul dispositivo accoppiato o rimuovere "TAOTRONICS SoundElite 70" dalla lista dei dispositivi Bluetooth.



3. EQモード









多機能ボタンと音量+ボタンを同時に押すことでEQモードを調整することができます。(三つモードあり)

4. ペアリング履歴の消去

- 1) お使いのBluetooth®機器とのペアリングに失敗した場合、ペアリング履歴を消去する必要があります。消去するには、ヘッドフォンがオンの状態で、LEDインジケータが紫色に2度点滅するまで、音声 + ボタンと音声 - ボタンを同時に押します。その後、ペアリングの手順に従い、再度Bluetooth®機器とのペアリングを行ってください。
- 2) ヘッドフォンを他の機器とペアリングしたい場合、すでにペアリングを行った機器のBluetooth®機能を無効に設定するか、Bluetooth® のリストから "TAOTRONICS SoundElite 70" を削除してください。

装着方法

- 図のようにイヤホンを着用してください:
- 1) 耳掛けをイヤホンに取り付けます。
 - 2) イヤホンとフックを耳に付けて、最適なフィット感に調整します。



およびロゴをライセンスに基づいて使用しています。その他の 商標およびトレードネームは、それぞれの所有者に帰属します。

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Bluetooth® EN

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sunvalleytek International Inc. is under license. Other trademarks and trade names are those of their respective owners.

DE Die Marke Bluetooth® und das Bluetooth Logo sind eingetragene Markenzeichen der Bluetooth SIG, Inc. und jegliche Verwendung dieser Marke durch Sunvalleytek International Inc. ist lizenziert. Die Rechte an anderen Markenzeichen liegen beim jeweiligen Eigentümer.

FR Le terme et les logos Bluetooth® sont la propriété de Bluetooth SIG, Inc. et toute utilisation de ces marques par Sunvalleytek International Inc. se fait sous licence. Les autres désignations commerciales et marques mentionnées sont détenues par leur propriétaire respectif.

ES La marca Bluetooth® y los logotipos son de propiedad de Bluetooth SIG, Inc. y se encuentra autorizado cualquier uso de estas marcas por parte de Sunvalleytek International Inc. Otras marcas y nombres comerciales son aquellas de sus respectivos propietarios.

IT La parola e i loghi Bluetooth® sono marchi di fabbrica registrati di proprietà di Bluetooth SIG, Inc. e qualsiasi utilizzo di questi marchi da parte di Sunvalleytek International Inc. avviene su licenza. Gli altri marchi di fabbrica e nomi commerciali appartengono ai rispettivi proprietari.

JP Bluetooth®のワードマークおよびロゴはBluetooth SIG, Inc. が所有する登録商標であり、Sunvalleytek International Inc.はこれらのマーク

を登録商標として使用しています。その他の 商標およびトレードネームは、それぞれの所有者に帰属します。

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the