

QUICK START GUIDE

1

Activate the GSMA SIM card included in your package at angelwatchco.com/activate*

2

Unscrew watch's SIM cover and insert the (now activated) SIM into the slot: chip facing up, cut corner edge going in first. Press deeply using SIM tool and click in place. Screw cover on with rubber seal (ridge down). Power on or reboot in Settings.

3

After boot up, wait for 1 minute, then swipe down on the watch face. Confirm you have 4G with at least two bars of service. If no service is available, see p.6, reboot outdoors and try again.

4

Download the Angel Watch™ app. Accept all permissions and create an account. Password must be 6-12 characters (only letters & numbers). Select **NORTH AMERICA** as your account region.

5

Pair your watch with the Angel Watch™ App. On the watch open the 'QR Code' app, then press 'RegCode'. On the app tap  to scan watch code. Set a nickname for the wearer (no punctuation) and **your** relationship in "I am", e.g. I am Mom.



Allow up to 24 hrs for your network to improve.
ACTIVATED SIM REQUIRED FOR APP REGISTRATION
Always reboot your watch after inserting any SIM