

KDD

Webcam Stand Mount User Guide

Model Name:KDD-006

Please read this instruction before use and keep it for future reference.



Aluminum Alloy Bracket



Knob Screw For Desk Clamp Mount



1/4" to 5/8" Screw Adapter



Rubber Pads



Desk Clamp Mount (Max 2.2 inches)



Phone Clamp Mount (Clip Width: 2.3"-3.5")



Ball Head (1/4" Screw)

Installation

Step 1: Fix the desk clamp on the desk.

Step 2: Attach the bracket to the desk clamp, then tighten it by using the desk mount knob screw after adjusting the direction of the bracket rod.



Step 3: Attach the ball head to the top of the bracket arm.

Step 4: Simply loosen the screws and the knobs, adjust the angle and direction you need, then tighten the screws and knobs.

Step 5: Attach your webcam to the ball head.

Step 6: If you want to use with a phone, please attach the phone clamp to the ball head.


Step 7: Open the phone clamp then clip your phone into the clamp mount.



How To Adjust Angle And Direction



Simply loosen the knob, swivel the bracket rod to adjust the direction you need, then tighten the knob.



Simply loosen the screw, adjust the angle you need, then tighten the screw.

Compatibility 1: Universal 1/4" Screw Can be Compatible With Devices With a 1/4" Screw Hole

Compatibility 2: Universal 5/8" Screw Can be Compatible With Devices With a 5/8" Screw Hole



5/8" Screw

Comes with a standard 1/4" to 5/8" screw adapter for microphones or any other devices with 5/8" screw hole.



1/4" Screw



1/4" Screw



Webcam



Action camera



Projector



Ring light



Phone mount



Tablet mount

Note: This item is only fit for the devices with 1/4" or 5/8" screw hole, please check your devices carefully before use.

ATTENTION

1. Please use it with all joints locked.
2. When adjusting the joint angle, make sure that the gear is engaged before tightening.
3. Please tighten the knob on the desk clamp after the bracket has been inserted and adjusted.
4. Please loosen the knob of the ball head to adjust the device angle, and tighten the ball head knob to fix the angle.
5. Please add a rubber pad to the screw on the desk clamp to increase friction and provide protection when using the stand.
6. The desk clamp base open maximum thickness is 2.2 inches; the phone clamp open width is 2.3 to 3.5 inches. Please carefully check the size of your device before use.
7. Please do not load more than 5lbs.
8. Disassemble carefully, do not lose parts.
9. Please place the product out of reach of infants when not in use.

For any problems and issues please contact us at the first time. We'll help you within 24 hours.
CUSTOMER SERVICE EMAIL: Contact@KDDservice.com