

Zorro Pro

2.4G Wireless Gaming Mouse

Instruction Manual

1

Product Manual:

Package Content

2.4G Wireless mouse - 01
2.4G Wireless receiver - 01
Micro USB charging cable - 01
Manual - 01

Compatible Platforms

PC or Mac
Win98SE/Me/2000/XP/
VISTA/WIN 7

Installation & Use


2.4G Version

1. Install the wireless receiver, connect the receiver to the computer's USB port.
2. Install the mouse. This product has built-in lithium battery. You need to set the bottom switch to On position.


The charging cable is included in the package. When the cursor is delayed, please insert the charging cable into the USB port to charge the mouse. Please try not to use the mouse while charging.

2.4G Version+Bluetooth Version

This version includes 2.4G version and Bluetooth. All features of the version & connection method please refer to the steps of the previous two versions.



3



4

As show in the images

1. Left key
2. Right key
3. Wheel button
4. Previous page key
5. Next page key
6. DPI speed switch key
7. Charging port
8. 2.4GHz wireless receiver
9. Switch control button
(OFF-turn off gaming mouse; ON-turn on gaming mouse; ●turn on the colorful lights)

Charging and use instructions

Do not use fast charging cable and fast charging adapter (do not use the adapter above 5.0 voltage and the charging cable current above 2A. It is recommended to use original charging cable provided with the product.

1. When the battery is low, the cursor and the scroll wheel will becomes insensitive, please charge in time.
2. After plugging in the charging cable, the roller part will light up with blue light. When battery is fully charged, the light will turn off automatically.
3. The color of lamp light is 7 chromatic give off light, if need to turn off lamplight you need to slide the button to on position.
4. DPI operates in four levels, 800-1200-1600-3200DPI, increase one time according to the cycle mode.
Note: DPI is not related to light color.
5. To turn off mouse move the switch at the bottom of the mouse to OFF position. To turn on the mouse move the switch at the bottom of the mouse to On position. At this time, plug in the receiver and connect to the computer/laptop by yourself.
6. For the first use, it is recommended to charge the mouse fully before use to extend the battery life.
7. The built-in battery is rechargeable lithium battery, which is inflammable and explosive. Please do not use the mouse in extremely warm environment. Do not dispose the product in fire, battery may explode. Please dispose the product safely.

5

Product specifications

Mouse Type: Wireless
Transmission Range: Up to 10m
Frequency Range: 2.4G+KA8
DPI Switch: 800/1200/1600/3200
Number of Keys: 6
Working Current: 5mA (max.)
Battery Life: About 7 days
Battery Capacity: 600mAh
Charging Interface: Micro USB

Troubleshooting:

If the mouse does not work, the following methods should be used to troubleshoot:

1. Check if the power switch is turned on.
2. Determine if the device has power.
3. Check that the receiver is properly plugged into the USB port of the computer.
4. Confirm hat the receiver is recognized by the computer after it is inserted.

When the wireless mouse moves slowly or fails, it is recommended to use the following methods to troubleshoot:

1. After using the wireless mouse for a period of time, it is found that it cannot be used normally or the cursor does not move. It may be due to low battery. Please put the mouse on charging.
2. Do not leave the USB receiver adjacent to other wireless devices. Such as Wi-Fi, Bluetooth, microwave oven, etc.
3. Do not disassemble the mouse or USB receiver yourself.
4. If you operate the mouse on a metal surface, such as iron, aluminum, copper, etc., it will create a barrier to the transmission of the radio and prolong the mouse response time or temporarily failure of the mouse.
5. Use a dry, soft cotton fabric to clean the mouse.

* If the above method still can not eliminate the fault, please contact the manufacturer.

Disclaimer

The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.