

ENTERTAINMENT

Play a video

- 1.Go to Files
- 2.Select a folder.
- 3.Select a video to play.
- 4.Control playback with the virtual keys.

CAMERA


You may enter the Camera interface by click the Camera App
With the camera function, you can capture photos and take videos.

Capture a photo

- 1.Open the application list and select Camera.
- 2.Before taking a picture, you need to know some settings.

Icon	Description
	Switch to Front/ Rear Camera
	Enable/ Disable Flash
	To Setting
	Take Photo

Place two fingers on the screen
and spread them apart or move
fingers closer together to zoom
in or zoom out.




3.Aim the lens at the subject and tap  to take a photo. The photo is saved automatically to the folder DCIM.

4.Select the image viewer icon at the upper right to view the pictures.

Record a video

1.Open the application list and select Camera. Slide to right for the video mode.



Icon	Description
	Switch to Front/ Rear Camera
	Enable/ Disable Flash
	To Setting
	Take Video



2. Tap  to start recording. The length of the video recording is restricted by the available space on your storage.

3. Tap  to stop recording. The video is saved automatically to the folder DCIM.

4. After recording videos, select the image viewer icon at the lower right to view the recorded videos.

TOOLS

Calendar

With the Calendar feature, you can consult the calendar by day, week, or month, create events, and set an alarm to act as a reminder, if necessary.

To access the calendar, tap Calendar from the application list.

To create an event, tap the date and tap the pop up + icon.

Fill in the fields, and set category, date, time & an alarm. After you finish, select DONE.

You can view calendar in different views, Day, Week, Month and All.

To delete an entry, tap the event to open it, and then tap the icon on the right top corner, then select Delete.



Alarm

From application list, tap Clock, and then select .
Tap the + button on the bottom screen to add alarm.

Tap the numeric pad to set alarm time, and then select AM or PM, when you are finished, tap OK.

Tap the time to change alarm time.

1. Set alarm time, repeat cycle, and alarm ringtone, taps OK after finished.
2. Tap “cancel” to shut down the alarm, and tap “ring again”, then the alarm will stop ringing for a few minutes.
3. Untick the clock to stop using the clock.
4. Long tapping the clock then it can be deleted.

Files Go

Many features of the device, such as images, videos, documents, received attachments and downloaded files or applications, use memory to store data.

With File Go, you can store and browse files and folders in your device, or edit, move, copy files; you can send files to compatible devices as well.

Note: Some files formats are not supported depending on the software of the device.

Some files may not play properly depending on how they are encoded.



SOUND RECORDER

With Recorder, you can record a voice memo.
From application list, tap Sound Recorder.

To record a voice memo, tap .

To end the recording, tap .

To listen to a voice recording that you just recorded, tap .

Calculator

With this feature, you can use the device as a calculator.
The calculator provides the basic arithmetic functions. Tap the virtual numeric and calculation keys to perform a calculation.

CONNECTIVITY

Wi-Fi

With Wi-Fi, you can connect to the internet or other network devices anywhere an access point or wireless hotspot is available.

Activate the Wi-Fi feature

- 1.From application list, tap Settings.
- 2.Turn on the Wi-Fi inside the Network& Internet interface

Find and connect to Wi-Fi

- 1.Once the Wi-Fi feature is activated, the device automatically search for available Wi-Fi connection.
- 2.Select a network.
- 3.Enter a password for the network (if necessary).
- 4.Select Connect.



Bluetooth

Find and connect to Bluetooth

- 1.Once you need to use the Bluetooth, you should open Bluetooth option and find other devices which also need to open Bluetooth .
- 2.Select a found device
- 3.Choose pair
- 4.Select pair and use Bluetooth .

Care & Maintenance

Use only manufacturer-approved accessories. Use general accessories may shorten the life of your device or cause device to malfunction.

Do not use or store the device in dusty, dirty areas.

Do not store the device in hot or cold areas.

Do not store your device near magnetic fields.

Do not store your device with such metal objects as coins, keys and necklace.

Other Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference, and
- (2)this device must accept any interference received, including interference that may cause undesired operation.



Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all



tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1.0 cm from the body.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

Google, Android, Google Play, YouTube and other marks are trademarks of Google LLC.



GATOR6

GUIA RÁPIDA



INFORMACIÓN DE SEGURIDAD

Seguridad En El Transporte

Tenga en cuenta todas las leyes y regulaciones de transporte.

Seguridad En Hospitales

El teléfono debe estar apagado cuando se encuentra en un hospital.

Usted tiene que cumplir con las regulaciones pertinentes del hospital y dar vuelta a su teléfono cuando se encuentre cerca de equipos médicos. Cualquier dispositivo de transmisión inalámbrica, incluidos los móviles, interferirá los equipos no está completamente protegida.

Seguridad Aeropuerto

Recuerde seguir todas las regulaciones tanto de aeropuertos como de vuelos de forma segura.

Llamadas De Emergencia

Asegúrese de que su teléfono móvil está encendido y en un área de servicio. En la pantalla de inicio, presiona la tecla del teléfono y marcar el número de emergencia. Comuníquese con su proveedor de servicio para un listado completo de números de emergencia locales.

Uso De La Batería

Para un mejor rendimiento y duración de la batería, se recomienda que cargue la batería totalmente antes de utilizar el teléfono móvil por primera vez y que inicialmente completos de dos a tres ciclos de carga.



FUNCIONES PRINCIPALES



Tecla	Instrucción
1.Menu principal	Haga clic para regresar a la pantalla de inicio
2.Tecla Volver	Presionar para Volver atras
3.Tecla Menu	Presionar para acceder al menu
4.USB	Puerto USB
5.Encendido	Mantener presionado para prender/apagar. Apretar tecla para bloquear/iluminar pantalla
6.Puerto auricular	Puerto de Auricular
7.Tecla Volumen+	Presionar para subir volumen
8.Tecla Volumen-	Presionar para bajar volumen
9.Camera	Camera
10.Flash	Flashlight
11.Alta Voz	Alta Voz
12.Ranura SIM/microSD	Ranura SIM / microSD



INTRODUCCIÓN


Instalación De La Tarjeta SIM

Advertencia : Mantenga la tarjeta SIM fuera del alcance de los niños, La tarjeta SIM y sus contactos se dañan fácilmente debido a los arañazos o dobleces . Por favor tenga cuidado al llevar, instalar o sacar la tarjeta SIM.

Nota : Por favor, póngase en contacto con su proveedor de servicio de telefonía celular directamente para obtener su tarjeta SIM .

Insertar La Tarjeta SIM

1.Retire la bandeja que tiene SIM y microSD instaladas. Para quitar la bandeja de SIM use la herramienta de extracción de SIM.



2.Introduzca la tarjeta SIM y, si es necesario, una tarjeta microSD.

3. Coloque la bandeja en la ranura apropiada y asegúrela.

Cuando inicialmente encienda el teléfono, habrá una serie de pasos para configurar las funciones básicas. Por favor complételos uno por uno.



Insertar SIM

Insertar su tarjeta SIM para que el teléfono pueda registrarse en la red.

Seleccione El Idioma

Mientras que en la primer pantalla de bienvenida , por favor seleccionar su idioma.
Desde el menú ingrese a Ajustes – Idiomas.

Selección De Red Wi-Fi

Este proceso permite al dispositivo conectarse a internet. Haga clic en la red Wi - Fi que desee que el dispositivo se conecte. Tenga en cuenta que las redes Wi-Fi no seguras pueden conectarse directamente y sin seguridad, mientras que cualquier otra red Wi - Fi que requieren una contraseña para la conexión brindaran mayor seguridad para sus datos, se recomienda que se conecte a una red Wi - Fi para comprobar si hay actualizaciones del software antes de comenzar a utilizar su unidad.

Bluetooth

Su teléfono ofrece las siguientes selecciones: VisibilidadBluetooth / Dispositivo emparejado / Transferencia de archivos / Nombre del dispositivo / Almacenamiento de archivos Bluetooth Ayuda.

Puede ingresar la función correspondiente de acuerdo a su necesidad.

Adhiera Su Cuenta

Iniciar sesión en su Cuenta de Google con el fin de mantener las cuentas simplificadas con los servicios de Google. Su Cuenta de Gmail se utilizará para algunos



programas de Google que incluyen : Google Play Store , Google Drive , Google + y Google wallet. Si usted no tiene una cuenta de Google , haga clic para crear una nueva cuenta . En este paso se puede también configurar la información de pago si así lo desea.

CONFIGURAR EL BLOQUEO DE PANTALLA

Puede configurar el bloqueo de pantalla para proteger su dispositivo por PIN, patrón o contraseña.

Restaurar Aplicaciones & Datos

Puede restaurar las aplicaciones y los datos que se han guardado de otro dispositivo anterior . Usted puede también configurar el teléfono como un dispositivo nuevo.

Servicios De Google

Haga clic para añadir o eliminar los servicios de Google que incluyen copia de seguridad , Servicio de Localización , y Google Now.

Advertencia:

Cualquier cambio o modificación que no esté expresamente aprobado por la parte responsable puede anular la autorización del usuario para operar el equipo.

Este dispositivo cumple con la parte 15 de la ISED Reglas. La operación está sujeta a la siguiente dos condiciones: (1) Este dispositivo no puede causar interferencias perjudiciales y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluyendo las



interferencias que puedan causar indeseado operación. Nota: Este equipo ha sido probado y ha demostrado cumplir con los límites de un dispositivo digital de Clase B, según la sección 15 de las normas de la ISED. Estos límites están diseñados para proporcionar una protección razonable contra interferencias perjudiciales en una residencial instalación. Este equipo genera, usa y puede irradiar energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede causar perjudiciales interferencias en las comunicaciones de radio. Sin embargo, no hay garantía de que no se produzcan interferencias en una determinada instalación. Si este equipo causa interferencias perjudiciales en la radio o la televisión recepción, lo que puede determinarse por girando el equipo apagado y encendido, el usuario es sugiere intentar corregir la interferencia por una o más de las siguientes medidas:

- Reorientar o reubicar la antena receptora.
- Aumentar la separación entre el equipo y el receptor.
- Conectando el equipo a una toma de un circuito diferente de aquel al que la receptor está conectado.
- Consultar con el proveedor o un experimentado radio / TV para obtener ayuda

Las pruebas de SAR se realizan en posiciones de funcionamiento estándar aceptadas por la ISED con el teléfono transmitiendo a su nivel de potencia certificado en todas las bandas de frecuencia probadas, aunque el SAR se determina al nivel de potencia más alto, el nivel real de SAR del teléfono mientras se conduce puede ser bastante inferior al valor máximo, en general, cuanto más cerca esté de una antena de estación base inalámbrica, menor será la potencia de salida. Antes de que un modelo



de teléfono esté disponible para la venta al público, debe ser probado y certificado ante la ISEDG que no excede el límite de exposición establecido por la ISEDG, pruebas para cada teléfono se realizan en posiciones y ubicaciones (por ejemplo, en el oído y usado en el cuerpo) exigidos por la FCC.

Para usarlo en el cuerpo, este modelo de teléfono ha sido probado y cumple con las pautas de exposición a RF de la FCC cuando se utiliza con un accesorio designado para este producto o cuando se utiliza con un accesorio que no contiene metal y que coloquen el dispositivo a una distancia mínima de 1,0 cm del cuerpo .

El incumplimiento de estas restricciones puede resultar en la violación de las normas de exposición a RF.

Google, Android, Google Play, YouTube y otras marcas son marcas comerciales de Google LLC.





www.plum-mobile.com

