



Godox R1200 Ring Flash Head Instruction Manual

November 9, 2021November 17, 2021

[Home](#) » [Godox](#) » Godox R1200 Ring Flash Head Instruction Manual 



Contents [[hide](#)]

- [1 Godox R1200 Ring Flash Head Instruction Manual](#)
- [2 Name of Parts](#)
- [3 Usage](#)
- [4 Technical Data](#)
- [5 Maintenance](#)
- [6 FCC](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
 - [7.2 Related Manuals / Resources](#)



Godox R1200 Ring Flash Head Instruction Manual



R1200

GODOX Photo Equipment Co., Ltd.

Add: Building 2, Yaochuan Industrial Zone, Tangwei Community, Fuhai Street, Bao'an District, Shenzhen, China

Tel: +86-755-29609320(8062)

Fax: +86-755-25723423

E-mail: godox@godox.com

godox.com

Made in China



Before using this product

Please read this user manual carefully in order to ensure your safety and the proper operation of this product. Keep for future reference.

Thank you for purchasing a GODOX product.

Ring Flash Head R1200 should be used in combination with AD1200Pro Power Pack, which offers soft and even light effects and shadowless illumination.



Warning

- Always keep this product dry. Do not use in rain or in damp conditions.
- Do not disassemble. Should repairs become necessary, this product must be sent to an authorized maintenance center.
- Keep out of reach of children.
- Stop using this product if it breaks open due to extrusion, falling or strong hit. Otherwise, electric shock may occur if you touch the electronic parts inside it.
- Do not fire the flash directly into the eyes (especially those of babies) within short distances.
- Otherwise visual impairment may occur.
- Do not use the flash unit in the presence of flammable gases, chemicals and other similar materials. In certain circumstance, these materials may be sensitive to the strong light



emitting from this flash unit and fire or electromagnetic interference may result.

- Do not leave or store the flash unit if the ambient temperature reads over 50°C. Otherwise the electronic parts may be damaged.
- Turn off the flash unit immediately in the event of malfunction.

Conventions used in this Manual

This manual is based on the assumption that both the camera and camera flash's power switches are powered on. Reference page numbers are indicated by "p. **".


The following alert symbols are used in this manual:



The Caution symbol indicates a warning to prevent shooting problem. The Note symbol gives supplemental information.

Name of Parts


Body



What's in the Box of R1200



R1200 Ring Flash Head x1



FLB-02
Foldable Bracket x1





UBB-02
Umbrella Bracket x1



Instruction Manual x1

Optional Accessories

This product can be used in combination with the following optional accessories to achieve best photography effects: RFT-21 Reflector for Ring Flash, BD-09A Honeycomb, Light Stand, etc.





Usage

Connect to Power Pack

Insert the power cord plug of flash head into the power socket. Please insert the tail end of the plug into the slot firstly and insert the other end to finish installation. When taking the plug out, hold down the spring and pull out the plug upwards.







Install and Detach the Ring Flash Tube



- 1** Detach the upper shell: push the accessory locking button forward and press it down. Then, pull out the upper shell to detach.

- 2** Take out the tungsten cord.





- 3** Take out the flash tube with two hands.

- 4** Insert the flash tube: match the flash tube in the Tube Socket (note: as there are anode and cathode, the flash tube cannot be inserted if the raised end is aiming at the U-type spring. The tube foot with red sign means anode.).



- 5** Install the upper shell: please hook the upper shell into the buckle before pressing down the top of upper shell.



Cautions

1. Do not short circuit.
2. Do not expose to rain or immerse into water. This battery is not water proof.
3. Keep out of reach of children.
4. Store in dry, cool, ventilated places.
5. Do not put aside or into fire.

Technical Data

Model	R1200
POWER	1200W
Guide No. (1/1 output)	53(with RFT-21 reflector)
100% Light Brightness(lux)(*)	7500
Working Temperature	-10°C ~ 40°C
Modeling Lamp (LED)	4300±200k; 40W
Color Temperature	5800±200k
Dimension	205x205x80mm
Net Weight	1.76Kg

Note: Parameters will be changed by different accessories and distance.

Maintenance

- Shut down the device immediately should abnormal operation be detected.
- Avoid sudden impacts and the product should be dedusted regularly.
- It is normal for the flash tube to be warm when in use. Avoid continuous flashes if unnecessary.
- Maintenance of the flash must be performed by our authorized maintenance department which can provide original accessories.
- This product, except consumables e.g. flash tube, is supported with a one-year warranty.
- Unauthorized service will void the warranty.
- If the product had failures or was wetted, do not use it until it is repaired by professionals.
- Changes made to the specifications or designs may not be reflected in this manual.

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.



However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Read More About This Manual & Download PDF:

Documents / Resources



[Godox R1200 Ring Flash Head](#) [pdf] Instruction Manual
R1200, Ring Flash Head

References

-  [GODOX PHOTO EQUIPMENT CO.,LTD](#)

Related Manuals / Resources

[Sharper Image Lightning Flash Drive 207182 User Manual](#)

Thank you for purchasing the Sharper Image Lightning Flash Drive. Please read this guide and store it for...

[DirecTV H20 Manual](#)

DirecTV H20 Manual

[DirecTV D12 Manual](#)

DirecTV D12 Manual

[DirecTV H23 Manual](#)

DirecTV H23 Manual

[Manuals+.](#)

- [home](#)
- [privacy](#)

