

正面

WOFALA
USER MANUAL

ENC
True Wireless Earphones

Qualcomm
aptX[®] HD

Thanks for your purchasing. We hope this fashionable and high quality wireless earphones could make your life more colorful.

Warm Tip: Please fully charge it with accessory USB Cable when you use it for the first time.

Key Parts

①

USB-C charging port

②

Touch Multi-function Button(MFB)

③

Charging contact

④

Charging case indicator light

⑤

Earphones indicator light

⑥

Microphone

Charging Display

<25%

25%-50%

50%-75%

75%-100%

Charging

Full

Getting Start

①Open charging case and take out both of earbuds , they will turn into pairing mode automatically.

②Active your bluetooth on your smartphone, search for "T1" and click for pairing

※Note :
1.The earbuds will turn off automatically, if they wouldn't pair with any device via Bluetooth after 5 minutes.
2.If the battery is low, they will turn off automatically as well.

Operation Of MFB

③ Play / Pause
Tap MFB(R or L) twice to get music pause or play.

④ Previous Track /Next Track
Long press MFB (R) for 2 seconds for playing next track;
Long press MFB (L) for 2 seconds for playing previous track.

⑤ Volume + Or -
Tap the MFB(R) once to turn up the volume;
Tap the MFB(L) once to turn down the volume.

⑥ Voice assistant (Siri)
Please make sure the earbuds is connecting with the Bluetooth, and then tap the MFB (L or R) three times quickly to active the voice assistant (Siri).

Operation of MFB

⑦ ANSWER OR HANG UP A CALL
Tap MFB (R or L) twice to answer or hang up a phone call.

⑧ Reject An Incoming Call
Long press MFB (R or L) for about 2 second to reject an incoming phone call.

Safety Rules

● Avoid dripping and dropping

● Use original or certified cables

● Never disassemble or modify your earbuds for any reasons to avoid any damages and dangers

● Keep the earbuds dry and do not submerge it in water

● Keep out of reach of children, small parts included may be a choking hazard,and avoid using the LED indicator dose to the eyes of children or animals

● Do not use this headphone during a thunderstorm to avoid irregular function and increased risk of the electric shock.

● Clean with a dry, soft lint-free cloth, do not use harsh chemicals or strong detergents to clean

● The product shall not be exposed to excessive hot or wet

● To avoid hearing damage, do not listen for long time at high volume

● Do not turn the volume so high that you're unable to hear your surroundings

● Do not use earbuds while driving

● You should use with caution or temporarily discontinue using in potentially hazardous situations

Basic Parameters

Bluetooth Name	T1
Chip	Qualcomm QCC3020
Bluetooth Version	V5.0
Frequency Response	2,400GHz~2.4835GHz
Bluetooth Range	≤10m/33ft
Microphone sensitivity	-42dB±1dB
Battery	38mAh for each earbuds
Charging Case	400mAh
Input	DC5V/300mA max
Play Time	4-5hours(per charge); 20hours(plus charging case power)
Charging Time	about 1hours 20 minutes(earbuds) about 1hours 30 minutes(charging case)
Bluetooth Profile	HSP/HFP/A2DP/AVRCP
Weight	about 3.6g(earbuds) about 35g(charging case)

Customer Service

12-Month Limited Warranty

Lifetime Technical Support

Packing list

Charging case

*1pc

Earbuds

*2pcs

Charging cable

*1pc

User manual

*1pc

FAQs/Trouble shooting

Q: The earbuds didn't response when I take them out of the charging case. It couldn't turn on automatically.

A: Please check if there is enough power, if not, please charge it first. If yes, please turn it on manually by long press the MFB (R&L).

Q: I have connected the earbuds with my smartphone successfully, but I couldn't hear any sounds.

A: Please make sure you have turned on the volume of your phone and earbuds properly.
Or, please check if the earbuds have been set to be an audio output equipment. Please refer the user manual of the smart phone for this operation.

Q: Why the connection is unstable, it cuts in and out constantly ?

A: Please make sure there are no obstacles between the earbuds and your Bluetooth device. And please make sure there is no radio or WiFi nearby.

Q: When making a phone call, the other side couldn't hear my voice clearly ?

A: Please turn up the volume of your smart phone and the earbuds. And make sure there is no interference nearby.

双麦通话降噪
无线蓝牙耳机

Qualcomm
aptX[®] HD

双麦通话降噪
无线蓝牙耳机

Qualcomm
aptX[®] HD

反面

WOFALA
产品说明书

双麦通话降噪
无线蓝牙耳机

Qualcomm
aptX[®] HD

感谢您购买本产品，本产品拥有时尚的外观与高品质的音质，希望能丰富您的生活。使用本产品前请仔细阅读并严格遵循使用说明和注意事项并妥善保管，以备查阅。

温馨提示：当您收到本产品后，请在首次使用前先充电。

产品图解

①

USB-C 充电接口

②

触摸式多功能按键

③

充电接触针

④

充电盒指示灯

⑤

耳机指示灯

⑥

麦克风

充电指示灯图示

<25%

25%-50%

50%-75%

75%-100%

耳机充电指示

耳机充电
充满

启动蓝牙

①打开充电盒面盖，取出耳机。耳机将自动进入配对状态

②打开手机蓝牙，搜索设备名“T1”，连接蓝牙

注：
如果耳机处于未连接任何蓝牙设备，耳机将在5分钟后自动关机。
电池电量不足时，耳机也会自动关机

功能说明

可使用多功能按键获得以下某种功能：

③ 播放/暂停/恢复
待机状态下，双击多功能按键（L或R）可开启音乐播放，再次双击暂停播放，再次双击恢复播放。

④ 上一曲/下一曲
播放音乐时，长按右耳（R）多功能按键约2秒可切换至下一曲；长按左耳（L）多功能按键约2秒可切换至上一曲。

⑤ 音量加/减
播放音乐时，单击右耳（R）多功能按键音量增加；单击左耳（L）多功能按键音量减小。

⑥ 启动语音助手（Siri）
蓝牙连接状态下，快速三击多功能按键（L或R），启动语音助手（Siri）。

功能使用

⑦接听来电/结束通话
当有来电时,双击(L或R)多功能按键可接听来电,再次双击可挂断本电

⑧拒接来电
当有来电时,长按任一耳机的多功能按键约2秒可拒接来电

安全事项

● 请勿挤压或者碰撞，避免跌落。

● 请使用原装或认证的充电线。

● 请勿自行拆卸/修改耳机，以防损坏或危险。

● 请保持耳机干燥，切勿丢入水中。

● 远离儿童，以避免有可能伤害儿童的意外情况。

● 请勿在雷电天气使用耳机以防意外情况。

● 请使用干软布擦拭，避免使用刺激性化学物质强力洗涤剂清洗。

● 请勿在严重高温/潮湿/腐蚀性环境下使用本产品。

听力保护

● 请勿长时间在高音量状态下使用，以防损害听力。

● 请勿将声音调整过大以防听不到周围声音。

● 请勿开车时使用。

产品参数

蓝牙名	T1
芯 片	高通 QCC3020
蓝牙版本	V5.0
频 率	2,400GHz~2.4835GHz
蓝牙传输距离	≤10m/33ft
麦克风灵敏度	-42dB±1dB
耳机电池容量	38mAh*2
充电底座	400mAh
输 入	DC5V/300mA max
播放时长	约4-5小时；充电盒每次约20小时
充电时长	耳机约1小时20分 充电盒约1小时30分
支 持	HSP/HFP/A2DP/AVRCP
重 量	耳机约3.6g,充电盒约35g

消费者支持

12个月有限保修

终身技术支持

包装明细

充电盒 x1个

耳机 x2个

充电线 x1条

说明书 x1本

FAQs/疑难解答

问：耳机从充电盒取出后未自动开机

答：请首先检查充电盒电量，若充电盒没电，耳机取出时将无法自动开机。此时可手动开机（手动触摸多功能按键约3秒）

问：连接着蓝牙设备聆听音乐并浏览网页时，网页音频将同时播放。

答：通常状态都会如此，与手机软件有关，可关闭网页音频即可，无需担心。

问：已经和手机连接但是没有任何声音。

答：首先请确保耳机和手机声音均已开启且未设置在最低音量。智能手机有时要求先设置蓝牙耳机为音频输出设备，此操作可查询智能手机使用说明。若使用音乐播放器或其他蓝牙设备，请确保设备支持A2DP音乐文件。

问：打电话时声音不清晰或对方无法听到我的声音。

答：调大耳机及手机音量，靠近手机并确保周围无强烈干扰信号。

问：为什么蓝牙连接不稳定或间歇性断开。

答：请确保耳机与设备间没有障碍物，请确保周围无强烈WiFi或磁场干扰

1

2

3

4

5

6

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

